



Video Insight 7.7 Administrative Guide

© 2020 –Panasonic i-PRO Sensing Solutions Corporation of America
Last updated: July 30, 2020

TABLE OF CONTENTS

SOFTWARE LICENSE AGREEMENT	5
1. INTRODUCTION	7
1.1 SYSTEM OVERVIEW	7
1.2 SOFTWARE COMPONENTS.....	7
1.2.A VI MonitorPlus	7
1.2.B Web Client	8
1.2.C VI Mobile	8
1.2.D IP Server	8
2. PLANNING.....	9
2.1 CONSIDERATIONS BEFORE INSTALLATION	9
2.1.A IP Server and Accessory Software Installation	9
2.1.B Web Hosting Configuration for Web Client.....	12
2.1.C Network Configuration	12
2.1.D Camera Configuration	13
2.1.E Storage Considerations.....	14
2.1.F H.265 Encoding	15
2.2 LICENSING	15
2.2.A Panasonic Camera License Activation.....	15
2.3 CLIENT SOFTWARE REQUIREMENTS	17
2.3.A VI MonitorPlus	17
2.3.B Web Client.....	17
2.4 CLIENT HARDWARE REQUIREMENTS	18
2.4.A Hardware Decoding	18
3. INSTALLATION AND ADMINISTRATION	19
3.1 IP SERVER: INSTALLATION	19
3.1.A Installation without an existing SQL Server Database	19
3.1.B Installation with an existing SQL Server Database	22
3.1.C Initialization	24
3.2 VI MONITORPLUS CLIENT	27
3.2.A Logging In.....	27
3.2.B Adding IP Servers to VI MonitorPlus.....	32
3.2.C Auto Login	33
3.3 ADMINISTRATION	34
3.3.A IP Server Manager (IPSM)	34
3.4 ADVANCED INSTALLATION CONFIGURATION INFORMATION	42
3.4.A Installer: InstallShield	42
3.4.B Server Backup and Restore.....	42
3.4.C Edge Recording	44
3.4.D Rules Manager	48
3.4.E Failover Server.....	65
3.4.F Configure Time Value for Detecting a Disconnected Camera	68
4. VI MONITORPLUS.....	69

4.1	ACCESS AND LOG IN	69
4.2	FULL SCREEN MODE	70
4.3	MENU BAR OPTIONS	70
4.4	TAB: WORKSPACES	71
4.4.A	Save	71
4.4.B	Manage	71
4.4.C	Application Plug-ins	72
4.5	LEFT HAND MENU ICONS.....	73
4.5.A	Servers	73
4.5.B	Cameras	74
4.5.C	Views	74
4.5.D	Maps.....	74
4.6	LIVE VIDEO	75
4.6.A	Using Views	77
4.6.B	Details Pane	80
4.6.C	Fisheye Cameras	83
4.6.D	NVR Live Video	85
4.6.E	Vehicle Incident Detection feature	86
4.6.F	Cycle Views feature.....	90
4.6.G	Embedded Analytics support for i-VMD Cameras.....	92
4.7	RECORDED VIDEO	94
4.7.A	Playback	95
4.7.B	Analytics	96
4.7.C	Bookmarks	97
4.7.D	Video Clips.....	100
4.7.E	Playback support for NVR Cameras.....	103
4.7.F	Video Clipping support for NVR Cameras.....	104
4.7.G	Panasonic Arbitrator Cloud Export	105
4.7.H	Multiplex Video	106
4.7.I	Region of Interest Motion Search (ROI).....	107
4.8	TAB: MODULES	111
4.8.A	Access Control.....	111
4.9	TAB: SYSTEM	116
4.9.A	Licensing	116
4.9.B	Event Viewer Details	116
4.9.C	System Log	119
4.9.D	Server Statistics	120
4.9.E	Options.....	121
4.10	TAB: ADMINISTRATION	131
4.10.A	Servers Setup.....	131
4.10.B	Camera Properties	141
4.10.C	Views Setup.....	153
4.10.D	Facility Maps Setup	154
4.10.E	Users & Groups	159
4.10.F	Modules.....	162
4.10.G	NVR Enrollment and Integration.....	166
4.10.H	User Audit Video Logging.....	169
4.10.I	User Audit Reports	170

5.	WEBCLIENT	172
5.1	LOGGING IN	172
5.2	LIVE VIDEO.....	172
5.2.A	<i>Camera Manipulation</i>	173
5.3	FACILITY MAPS.....	174
5.4	LAYOUT DIRECTORY.....	174
5.5	RECORDED VIDEO	175
5.5.A	<i>Creating Clips</i>	176
5.5.B	<i>Watermark Verification</i>	177
5.6	HIGH SPEED MODE.....	177
5.7	ACCESS CONTROL	178
5.8	ADMIN FEATURES	180
5.8.A	<i>Servers</i>	181
5.8.B	<i>Cameras</i>	183
5.8.C	<i>Views (formerly known as Layouts)</i>	184
5.8.D	<i>General Settings</i>	185
6.	VIDEO INSIGHT SUPPORT RESOURCES.....	188
6.1	REMOTE SUPPORT.....	188
6.2	CONTACT US	189
7.	APPENDICES	190
7.1	APPENDIX A: IP SERVER PORT LIST	190
7.2	APPENDIX B: .AVI FILES WRITE/MODIFY PERMISSIONS SETTINGS.....	191
7.3	APPENDIX C: CONFIGURING AN IQEYE CAMERA USING OPTIONAL CONTROLS.....	192
7.4	APPENDIX D: SECURE SYSTEM GUIDELINE.....	193
7.5	APPENDIX E: THE INDEPENDENT JPEG GROUP’S JPEG SOFTWARE NOTICE.....	202

SOFTWARE LICENSE AGREEMENT

IMPORTANT – READ CAREFULLY BEFORE ACCESSING THIS SOFTWARE: This license agreement (“License Agreement”) is a legal agreement between the user (referred to herein as “You” or “Licensee” and meaning either an individual or a single entity) and Panasonic i-PRO Sensing Solutions Corporation of America, and its suppliers (collectively, “PIPSA” or “Licensor”) for the Software (the “Software”). BY USING OR ACCESSING THE SOFTWARE, LOADING THE SOFTWARE OR ALLOWING THE SOFTWARE TO BE LOADED; OR UTILIZING ANY DEVICE OR OTHERWISE UTILIZING THE SERVICES OR FUNCTIONALITY OF THE SOFTWARE, YOU AGREE TO BE BOUND BY THE TERMS OF THIS LICENSE AGREEMENT. IF YOU DO NOT AGREE TO THE TERMS OF THIS LICENSE AGREEMENT, YOU MAY RETURN THE SOFTWARE TO YOUR PLACE OF PURCHASE FOR A FULL REFUND.

1. GRANT OF LICENSE.

a. Overview of the License Agreement. This License Agreement describes your rights to use or otherwise utilize the Software. This License Agreement does not entitle You to any ownership rights of the programming code. The Software is licensed, not sold. The Software is protected by copyright and other intellectual property laws and treaties. PIPSA owns the title, copyright, and other intellectual property rights in the Software. You may not rent, lease, or lend the Software or transfer the License Agreement to another user.

b. System Limits. You may use the Software with one unique system identified by its Mac address. Each unique system requires a separate License Agreement.

2. TERMINATION. Without prejudice to any other rights, PIPSA may terminate this License Agreement if You do not abide by the terms and conditions herein, in which case you must destroy all copies of the Software and/or return the Software to PIPSA and all its component parts.

3. TRANSFER. You may move the Software to a different server.

4. LIMITATION ON REVERSE ENGINEERING, DECOMPIATION AND DISASSEMBLY. You may not reverse engineer, decompile, or disassemble the Software.

5. CONSENT TO USE OF DATA. You agree that PIPSA and its affiliates may collect and use any technical information You provide as part of support services related to the Software. PIPSA agrees not to use this information in a form that personally identifies You.

6. LIMITED WARRANTY. Because of uncertain or unknown conditions and incidental hazards under which the Software is used, PIPSA does not warrant or guarantee that any particular result will be achieved. PIPSA disclaims all liability and responsibility for damages or other loss caused by any independent supplier/installer of the Software or other third-party. The sole and exclusive warranty provided by PIPSA is that (1) the media on which the Software is furnished will be free of defects in materials and workmanship; and (2) the Software substantially conforms to its published specifications (the “Limited Warranty”). The Software is warranted only for its initial installation. This warranty shall survive inspection of, payment for and acceptance of the Software, but in any event, shall expire ninety (90) days after the date you receive the Software, unless prohibited by law. Any supplements or updates to the Software, including without limitation service packs (if any) or hot fixes provided to You after the expiration of the ninety-day Limited Warranty period are not covered by any warranty or condition, express, implied or statutory. Except for the Limited Warranty as set forth herein, PIPSA provides the Software and support services (if any) “AS IS” AND WITH ALL FAULTS. THERE ARE NO OTHER WARRANTIES (NOR REPRESENTATIONS) HEREUNDER OR ELSEWHERE MADE BY PIPSA, EXPRESS OR IMPLIED, AND ALL OTHER WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SUITABILITY AND FITNESS FOR A PARTICULAR PURPOSE, OF GOOD AND WORKMANLIKE PERFORMANCE, ALL WITH REGARD TO THE SOFTWARE AND THE PROVISION OF OR FAILURE TO PROVIDE SUPPORT SERVICES, ARE DISCLAIMED BY PIPSA AND EXCLUDED FROM THIS AGREEMENT. ALSO, THERE IS NO WARRANTY OR CONDITION OF TITLE, QUIET ENJOYMENT, QUIET POSSESSION, AND CORRESPONDENCE TO DESCRIPTION OR NON-INFRINGEMENT WITH REGARD TO THE SOFTWARE. NO AFFIRMATION WHETHER BY WORDS OR ACTIONS BY PIPSA, ITS AGENTS, EMPLOYEES OR REPRESENTATIVES SHALL CONSTITUTE A WARRANTY.

7. Limited and Exclusive Remedy. PIPSA’s sole responsibility and Your exclusive remedy for any nonconformance or defect in the Software is expressly limited to the replacement of the Software or the refund of the license fees, if any, as determined by PIPSA, in its sole discretion, to the extent PIPSA confirms that the Software possess such a defect. As a condition precedent to any remedy described herein, or otherwise available to You, You shall seek and accept PIPSA’s reasonable effort to replace the allegedly defective or nonconforming Software. In furtherance of such undertaking, if You reasonably believe that the Software contains a defect or nonconformity for which PIPSA is responsible, You shall inform PIPSA immediately by telephone at (713) 621-9779 and by providing written notification to PIPSA within forty-eight (48) hours of discovery. All returned Software shall be shipped at customer’s expense. This Limited Warranty is void if failure of the Software has resulted from accident, abuse, misapplication, abnormal use, or a virus. Any replacement Software will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer.

8. NO CONSEQUENTIAL OR OTHER DAMAGES. NOTWITHSTANDING ANYTHING TO THE CONTRARY, EXPRESS OR IMPLIED, (1) PIPSA’S LIABILITY FOR ANY CLAIM OR ACTION OF ANY KIND ARISING OUT OF, IN CONNECTION WITH OR RESULTING FROM THE MANUFACTURE, SALE, DELIVERY, RESALE, TRANSFER, USE OR REPAIR OF THE SOFTWARE OR SERVICES RENDERED BY PIPSA UNDER THIS LICENSE AGREEMENT SHALL NOT EXCEED THE PRICE, IF ANY, YOU PAID FOR THE SOFTWARE OR \$5.00, WHICHEVER IS GREATER; AND (2) PIPSA SHALL IN NO EVENT BE LIABLE FOR SPECIAL, INDIRECT, PUNITIVE, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR CONTINGENT LIABILITIES ARISING OUT OF THIS LICENSE AGREEMENT OR THE FAILURE OF THE SOFTWARE TO OPERATE PROPERLY, INCLUDING BUT NOT LIMITED TO ANY DAMAGE OCCASIONED BY DELAY, DOWNTIME, LOST BUSINESS OPPORTUNITY, LOSS OF CONFIDENTIAL INFORMATION, LOSS OF PRIVACY, LOST PROFITS OR OTHERWISE (NOTWITHSTANDING THE CAUSE OF SUCH DAMAGE AND WHETHER OR NOT CAUSED BY

PIPSA'S NEGLIGENCE, FAULT OR STRICT LIABILITY). CUSTOMER ASSUMES THE RISK FOR AND INDEMNIFIES PIPSA FROM AND AGAINST ALL LIABILITIES FOR ANY LOSS, DAMAGE OR INJURY TO PERSONS OR PROPERTY ARISING OUT OF, CONNECTED WITH OR RESULTING FROM THE USE OF OR INABILITY TO USE THE SOFTWARE, THE PROVISION OF OR FAILURE TO PROVIDE SUPPORT SERVICES, OR THE POSSESSION, USE OR APPLICATION OF THE SOFTWARE, EITHER ALONE OR IN COMBINATION WITH OTHER PRODUCTS. PIPSA ASSUMES NO RESPONSIBILITY OR LIABILITY, WHETHER EXPRESS OR IMPLIED, WHETHER IN TORT OR IN CONTRACT, AS TO THE CAPACITY OF THE SOFTWARE TO SATISFY THE REQUIREMENT OF ANY LAW, RULE, SPECIFICATION, OR CONTRACT PERTAINING THERETO, INCLUDING, BUT NOT LIMITED TO, ANY CONTRACT BETWEEN ANY CUSTOMER OF ITS PRODUCTS AND PARTIES WITH WHOM SUCH CUSTOMER HAS CONTRACTED.

9. INDEMNIFICATION: YOU AGREE TO PROTECT, INDEMNIFY, HOLD HARMLESS AND DEFEND PIPSA FROM AND AGAINST ANY CLAIMS, DEMANDS, LIENS, CAUSES OF ACTION, JUDGMENTS, LOSSES AND LIABILITIES OF ANY NATURE WHATSOEVER ARISING IN ANY MANNER, DIRECTLY OR INDIRECTLY OUT OF OR IN CONNECTION WITH OR IN THE COURSE OF OR INCIDENTAL TO (1) YOUR WORK OR OPERATIONS WITH THE SOFTWARE REGARDLESS OF CAUSE OR OF THE SOLE, CONCURRENT OR CONTINUING FAULT OR NEGLIGENCE OF PIPSA OR ITS EMPLOYEES OR AGENTS; OR (2) ANY BREACH OR FAILURE TO COMPLY WITH ANY OF THE PROVISIONS OF THIS LICENSE AGREEMENT. YOU AGREE TO PROTECT, INDEMNIFY, HOLD HARMLESS AND DEFEND PIPSA FROM AND AGAINST ANY CLAIMS, DEMANDS, LIENS, CAUSES OF ACTION, JUDGMENTS, LOSSES AND LIABILITIES FOR INJURY TO OR DEATH OF YOU, YOUR AGENTS OR EMPLOYEES OR ANY EMPLOYEE OR AGENTS OF ANY CO-VENTURER, CONTRACTOR, SUBCONTRACTOR OR PERSONS AT YOUR WORK LOCATION ARISING IN ANY MANNER, DIRECTLY OR INDIRECTLY, OUT OF OR IN CONNECTION WITH OR IN THE COURSE OF OR INCIDENTAL TO YOUR WORK OR OPERATIONS WITH THE SOFTWARE, REGARDLESS OF CAUSE OR OF ANY FAULT OR NEGLIGENCE OF PIPSA OR ITS EMPLOYEES OR AGENTS.

10. SEVERANCE: Should any provision of this License Agreement, or a portion thereof, be unenforceable or in conflict with the laws of the United States of America or of any state or jurisdiction which governs any transaction between PIPSA and You, then the validity of the remaining provisions, and any portion thereof, shall not be affected by such unenforceability or conflict, and this License Agreement shall be considered as if such provision, or portion thereof, were not contained herein.

11. UNLAWFUL PURPOSE. Use of the Software for any unlawful purpose or in any unlawful manner, use for any improper or unintended use, or use by anyone other than you are strictly prohibited and constitutes a material breach of this License Agreement.

12. APPLICABLE LAW. This License Agreement is governed by the laws of the State of New York without regard to its conflict of laws principles. PIPSA and Licensee hereby agree that exclusive jurisdiction of any, controversy, claim, suit or proceeding arising out of or relating in any way to the Software or this License Agreement or the breach, termination or invalidity thereof shall lie within the courts of the State of New York or within the courts of the United States of America located within New York. PIPSA and Licensee consent to venue and jurisdiction within the Courts of New York, New York.

13. NO WAIVER: Failure to enforce any or all this License Agreement in a particular instance shall not act as a waiver or preclude subsequent enforcement.

14. ENTIRE AGREEMENT. This License Agreement (including any addendum or amendment to this License Agreement which is included with the Software) constitutes the entire agreement between You and PIPSA relating to the Software and any support services, and this License Agreement supersedes all prior or contemporaneous oral or written communications, proposals, and representations with respect to the Software or any other subject matter covered by this License Agreement. To the extent the terms of any PIPSA policies or programs for support services conflict with the terms of the License Agreement, the terms of the License Agreement shall control.

15. This Software is of the U.S. origin and may be subject to the U.S. export control laws, including the U.S. Export Administration Act and its associated regulations. Licensee agrees that it will not export, re-export or import, directly or indirectly, the Software except in compliance with all applicable laws and regulations.

Rev 01/20

1. INTRODUCTION

Video Insight is a leading developer of enterprise-class Video Management Software. Our vision is to provide powerful, user-friendly software that will run on "off-the-shelf" hardware based on IP technology. We have developed our solution from the ground-up, making us one of the few pure-play IP video management software providers.

Video Insight's suite of products was created to protect clients by providing intelligent, easy to use IP security solutions. Our extensive effort has resulted in products that are flexible and powerful enough for any situation, yet still very cost effective.

Our software boasts the largest number of camera integrations available on the market. Users can access their Video Insight surveillance systems on mobile devices, through the web and on Microsoft Windows clients over internal networks or the Internet.

Video Insight can intelligently and efficiently monitor security throughout your organization.

Key features of this version are:

- Updated, easy to use interface
- Support for over 4,100 cameras models
- Alarm Monitoring
- Facility Maps
- Synchronized Playback

This document is intended for use by advanced users and system administrators.

1.1 SYSTEM OVERVIEW

The Video Insight Enterprise Suite provides a solution for many different scenarios. You can use it for basic unattended monitoring or mobile remote viewing by patrolling security personnel. At its core is Video Insight IP Server, which powers the software platform.



The Video Insight application suite runs over an ethernet network, meaning cameras, security personnel, and servers do not have to be co-located.

There is no limit to the number of IP Servers that can be utilized to manage the growing needs of today's IP camera video surveillance needs.

1.2 SOFTWARE COMPONENTS

The Video Insight Enterprise Suite consists in three main components used to monitor live and recorded video: VI MonitorPlus, Web Client and VI Mobile. These three clients can be used to connect to IP Server at no additional charge.

1.2.A VI MonitorPlus

VI MonitorPlus is a Thick Client that provides full access to all cameras and access control points within an organization or multiple locations. It features a centralized management and configuration interface for an extended range of video monitoring resources, designed to meet System and Security Administrators' needs.

VI MonitorPlus receives video from the server in the camera's native format. Transferring video in the camera's native format is a file server operation *that does not burden the IP Server CPU* as a video decompression operation would.

1.2.B Web Client

Web Client accesses IP Server via Microsoft Internet Information Services (IIS) hosted on the same server as the IP Server. It currently supports HTML5-compatible browsers such as: Google Chrome, Internet Explorer 11+, Mozilla Firefox and Microsoft Edge, among others.

The Web Client can access and manage live and recorded video and Facility Maps; it can also create clips and download recorded video. *Unlike VI Monitor Plus, Web Client connects directly to the cameras to view live video.*

1.2.C VI Mobile

VI Mobile is a free app available in the App Store for iOS users and Google Play for Android users. VI Mobile gives users access to live and recorded video as well as access to Facility Maps.

1.2.D IP Server

IP Server is the hub of the Video Insight IP Video Management Software (VMS). It supports over 4,100 different camera models from 150 different camera manufacturers. It runs as a Windows service and supports both 32-bit (x86) and 64-bit (x64) Windows environments.

IP Server connects directly to the cameras and can record video locally or write directly to NAS or SAN devices.

2. PLANNING

Getting the most out of the hardware using IP Server software requires planning. Understanding the needs of the environment will help shape the final installation solution. Evaluate and plan the integrations necessary for the most effective installation.

2.1 CONSIDERATIONS BEFORE INSTALLATION

Before beginning the installation process, it is necessary to determine the key system requirements.

Will the system:

- Require multiple-server configuration?
- Utilize a shared SQL environment?
- Utilize a shared network storage solution?
- Be attached to Active Directory or Lightweight Directory Access Protocol (LDAP)?

If the system is going to be a single, standalone installation of IP Server, opting to use the basic installation process is recommended.

If Microsoft SQL Server is already present in your server or environment, then *only IP Server* is required to be installed. Otherwise, the downloadable package includes Microsoft SQL Server Express 2012 as the database of choice. Either way, IP Server Enterprise requires a fully functioning SQL database as part of its platform

2.1.A IP Server and Accessory Software Installation

Video Insight software supports both 32-bit and 64-bit operating systems; some features, however, are limited to use within the 64-bit client only. Make sure to download the correct version for your operating system.

NOTE - Administrator-level access to the server is required during the installation and troubleshooting.

Review the following items prior to beginning the installation process:

- [Storage Considerations](#)
- [Database Considerations](#)
- [Network Configuration](#)

The Storage and Bandwidth calculator is available online to gauge your platform's needs: <http://www.video-insight.com/storage-and-bandwidth-calculator>

(1) IP SERVER ESSENTIAL REQUIREMENTS

IP Server is at the heart of the Video Insight platform. It runs on industry-standard hardware and works with 32-bit and 64-bit versions of the following Microsoft operating systems.

- Windows Server 2019
- Windows Server 2016 Standard
- Windows Server 2012 and R2
- Windows 10 Pro, Enterprise, and Education

IP Server requires Microsoft .NET Framework 4.5+ and Microsoft Internet Information Services (IIS) with "static content" enabled. Because Video Insight hardware and software integrates with the latest Windows updates, the operating system must be updated, with all current Windows updates applied.

Required hardware for installation of IP Server is determined by a variety of factors including the number of cameras, the resolution of those cameras, the number of frames per second, as well as the number of days of required video storage.

(2) GPU SUPPORT

Video Insight software supports NVIDIA graphics cards. Additionally, Intel QSV is supported for displaying video within VI MonitorPlus.

The following GPUs are currently supported:

Intel GPUs	Nvidia Graphics Cards
<ul style="list-style-type: none">• Intel QSV• Intel HD Graphics, 3rd, or later generation• Intel Core processor-based platforms	<ul style="list-style-type: none">• EVGA GeForce GTX 750Ti SC 2GB• EVGA GeForce GTX 950 2GB• EVGA GeForce GT 1030• EVGA GeForce GTX 1050 2GB• EVGA GeForce GTX 1050Ti 2GB• EVGA GeForce GTX 1060 3GB• EVGA GeForce GTX-1080 8GB• EVGA GeForce GTX 1650/1650Ti• EVGA GeForce GTX 1660/1660Ti/1660 Super• EVGA GeForce RTX 2060/2060 Super• EVGA GeForce RTX 2070/2070 Super• EVGA GeForce RTX 2080/2080Ti/2080 Super• EVGA GeForce RTX 4000
For On-board H.265 support, Intel HD Graphics 4th generation processor or higher is recommended.	For hardware decoding with an additional graphics processor, the Nvidia EVGA GeForce GTX 950 2GB card is the minimum recommendation.

NOTE - Only one GPU is used for hardware decoding with IP Server. If two properly installed GPUs are detected by the operating system, IP Server will only use one.

Activating Intel QSV

If a graphics card is installed in addition to the On-board Intel graphics card, the primary display will be used as hardware decoding.

If Intel QSV is used as the primary GPU, please make sure BIOS setting has been configured properly to use this specific GPU.

If the additional graphics card is set as the primary display, change the On-board Intel graphics card to primary by connecting it to the monitor. Check the Intel Download center for the correct On-board Intel graphics card driver.

After the above is configured, VI MonitorPlus will detect the On-board Intel graphics card, verifying that the card supports automatic hardware acceleration and use when available.

If both Intel GPU and Nvidia GPUs are available, VI MonitorPlus will use the fastest GPU as default.

(3) ACTIVE DIRECTORY PREREQUISITES

- Active Directory server with users and groups configured.
- Active Directory can be configured with IP Servers that use a localized, independent, database for each server or within a shared database environment.
- Administrator user account with administrator-level credentials in both the domain and on the Active Directory server (do not use an individual account).

NOTE - Alternatively, an account created with proper read/write access for Active Directory integration would be appropriate if the local Administrator account is used to install and modify IP Server during the initial setup process. This allows modifying the registry of the IP Server, granting other Active Directory user scopes and security objects the necessary permissions for accessing video storage in both read/write modes.

- The IP Server host is part of the Domain.
- IP Server must be able to communicate with all domain controllers via port 389 or 636. Port 389 cannot be modified. Port 636 is used for SSL encryption.
- IP Server configuration must be done while logged into the domain with a valid domain account.

Video Insight recommends importing users as a group instead of adding users individually. The group must be created in Active Directory prior to import. Customizing Groups to suit the individual needs and policies of the organization installing IP Server is done easily.

To configure the IP Video Enterprise service to run as an Active Directory account:

- Click the Start button.
- Enter *services.msc* and then press Enter.
- Locate the IP Video Enterprise service.
- Right-click and select Stop.
- Right-click and select Properties.
- Select the Logon tab.
- Select the second option for the account.
- Provide an Active Directory account with minimal rights. A basic domain user account should be sufficient.
- Click the General tab and then select Start.
- Click OK.

NOTE - Restart the IIS Admin service if using Web Client.

(4) FAILOVER SERVER OPTION

In the event a network outage or hardware failure prevents a server from recording camera video, the IP Server Failover Server feature will enable another server to take over the recording capabilities of the offline server. When configured with a shared SQL Database as part of a cluster, the Failover Server feature minimizes video loss and enables continuous live streaming video.

To use the Failover Server feature, the following criteria are required:

- Complete setup of two identical servers with the same hardware configuration.
- A shared Database installation; see IP Server's "Installation with an existing SQL Database".
- A license and a serial number or activation key for each server.

(5) DATABASE CONSIDERATIONS

IP Server saves configuration settings, user names, camera information and event logs in a Microsoft SQL database. When IP Server starts, it reads its settings directly from the assigned database.

IP Server saves all *video recordings* to its local hard drive, SAS/NAS storage device so video recordings are still accessible in the case of a SQL database failure.

The following table can be used to determine whether a local or shared database is required:

Local Database	Shared Database
Small centralized organization with 1-3 servers	Large regional organization with many servers
Use VI MonitorPlus client and built-in User Manager	Use Active Directory/LDAP
Disaster recovery and backup for each server's database	Disaster recovery and backup for one database
Failover server functionality is <u>not</u> desired	Failover server functionality is desired
Cameras will not move from one server to another	Cameras will move from one server to another at final configuration
Avoids unnecessary exposure of SQL database to the network	Exposure of SQL database to the network in a secured network environment

(6) FACTORS AFFECTING PERFORMANCE

Any system is the sum of its parts. A mismatched sub-system or component can have a negative effect on the entire system. Video streaming can only be as good as the cameras and underlying network. Best practices for IP video solutions indicate cameras connected to and powered over Ethernet or separate VLANs for cameras.

2.1.B Web Hosting Configuration for WebClient

Operating system requirements for hosting the Web Client interface vary according to the version used on the server. As a reference, the following Microsoft Operating systems are currently supported:

- Windows Server 2019
- Windows Server 2016 Standard
- Windows Server 2012 and R2
- Windows 10 Pro, Enterprise, and Education

Operating System Roles and Features that should be available prior to installation are:

- Microsoft .NET Framework version 4.5+ or later
- Microsoft IIS v 6.0 or later

Necessary Microsoft IIS Components for full functionality of Web Client:

- ASP and ASP.NET
- ISAPI Filters
- ISAPI Extensions
- Default Document
- Directory Browsing
- Static Content
- Windows Communication Foundation Non-HTTP Activation
- HTTP Logging
- Basic Authentication

NOTE - Video Insight highly recommends updating each of the above features *to their latest stable version* via the Microsoft Update Services, prior to their installation.

2.1.C Network Configuration

Network Configuration is *extremely important* when implementing an IP video solution. IP cameras use considerable bandwidth to deliver video data between the camera and the server. Different cameras will require different amounts of bandwidth based on factors such as resolution and frame rate.

Accessing video from VI MonitorPlus, Web Client, VI Mobile and Video WallPlus increases the amount of required bandwidth.

(1) LOCAL AND WIDE AREA NETWORK

Video travels over a network, meaning infrastructure plays a big part in the overall performance of the Video Insight solution. A slow network can create bottlenecks that result in a slow frame rate, jittery video, and packet loss. Avoid devices on your local network with a port speed of less than 100 Mb/s.

The following network issues can cause cameras to drop a connection, or otherwise go offline:

- Camera is using a dynamic IP address instead of static IP address
- Another service or network device is running at the same time with the same IP address, causing a conflict.
- Another service or network device is broadcasting substantial amounts of data
- Multiple applications pulling a stream from one camera (some cameras limit the number of streams)
- Power output of a switch is less than required by the total number of cameras. The power output of a switch must be greater than the sum of the power requirements of the attached cameras. Refer to the relevant equipment manuals or specification sheets for hardware power requirements.

NOTE - Due to potential dead zones, transmission speed and/or outside interference with Wi-Fi signals, Video Insight *does not* recommend using Wireless Networking to connect video cameras.

If an organization using IP Server has more than one site location or multiple installations, it shall rely on an Internet Service Provider (ISP) for connectivity between the sites. The performance expectation from the ISP will depend on their network infrastructure, its utilization by their customers, and their cost/quality ratio.

For better results, consider creating a link with a 50Mbps +/- connection between the two site locations, with occasional video browsing. Streaming video remotely to a desktop client requires basic broadband. Streaming to a mobile device requires 4G service or Wi-Fi.

(2) EXAMPLE ROUTER CONFIGURATION

Video Insight recommends using a router if the IP Server is connected to the internet.

Small Office/Home Office (SOHO) routers provide a simple hardware firewall that protects the computer, preventing all inbound traffic from accessing the network and computers except for the traffic specifically allowed through the firewall.

Follow these steps to configure IP Server and the router for remote access:

1. Assign a static IP address to the IP Server.
2. SOHO routers typically use DHCP to assign an IP address to devices connected to them. Choose an address outside of the DHCP range.
3. Configure the SOHO router to forward ports 80 and 4011 to the IP Server.
4. To test the IP Servers configuration by accessing the Web Client externally, open any compatible Internet browser and enter `<http://<external> IP>/videoinsight` into the address bar (URL).

For help on assigning a static IP address or forwarding ports, review the router's documentation or consult with a Network Administrator.

For more information on configuring most SOHO routers in the market, visit <http://www.portforward.com>. Video Insight does not endorse or support the information found on this website.

NOTE - Many SOHO routers will not allow a connection to the external IP address when the IP Server is behind a firewall.

2.1.D Camera Configuration

Video Insight supports a vast array of cameras from many manufacturers. Additional camera support is included with each software release. Please refer to our website for the latest list of supported cameras.

Video Insight supports the Open Network Video Interface Forum (ONVIF) standard, Version 1.02, and Profile S.

(1) CAMERA AUDIO

IP Server is capable of recording audio along with the capturing of video recording when used with the appropriate and desired peripherals. While configuring audio recording is a possibility, it is often over-looked that necessary and desired changes be made on the camera itself for audio recording to function within IP Server's video recording process.

(2) BODY WORN CAMERAS (BWC) AUDIO

For Body Worn Cameras, synchronized audio and video are currently available only for 64-bit Windows OS environments. For 32-bits environments, however, recorded video *does not* have audio capabilities.

(3) COMPATIBLE AUDIO CODECS

The following codecs are found to work well with IP Server and are most commonly used by known camera manufacturers:

L8 @ 8K (Uncompressed 8-bit audio)	L16 @ 16K (Uncompressed 16-bit audio)
G711 ULAW and ALAW @ 8K and 16K	G726 40/32/24/16
AAC Low Complexity (*) Bitrate is 128kbps or less	AMR Audio

(4) FACTORS AFFECTING CAMERA IMAGING WITHIN VI MONITORPLUS

- Bit Rate - a higher bit rate usually provides better picture quality.
- Resolution - a higher resolution usually provides better picture quality.
- Format - some picture formats, such as AVI, incorporate better algorithms that more accurately represent the video capture. The most basic, but bandwidth heavy MJPEG, was industry-standard for many years. Since then, other video codecs have been used, including H.264 and H.265.
- Firmware - outdated firmware can impair camera functionality.
- Location - unless intended for such use, placement in dark or obstructed locations, or in places affected by adverse weather, will not result in useful pictures.
- Number of cameras connected to Server - The higher the number of connected cameras, the greater the load on Server resources.

2.1.E Storage Considerations

The amount of storage required for recordings depends on the number of cameras, the Codec, Frames per Second (FPS), resolution of the images and the percentage of pixel change.

Video Insight provides flexibility in terms of camera storage options:

Record Always	Requires significantly more storage space because video is constantly recorded.
Motion Only	Requires less storage space than Record Always because video is recorded only when motion occurs in the camera's field of view.
Schedule	Allows both Record Always and Motion Only within specified schedules.

The amount of storage needed is determined by the bit-rate of each camera and how much of that will need to be saved. For example, a 1.3 Megapixel camera set at 10 FPS, can be configured to stream video at 1.5 Mb/s and, if the camera is recording motion at 50% of the time, then we can estimate we need 7GB of storage per day.

Access the VI Storage Calculator at <http://www.security.us.panasonic.com/storage-and-bandwidth-calculator>

Video Insight supports all storage that Windows can address. In addition to the size of the storage, it is necessary to confirm the storage system can handle the amount of video otherwise video can be lost when the storage is overloaded.

To calculate the maximum storage throughput, it is assumed that all cameras will write simultaneously and add up all camera bitrates. Because most storage systems refer to maximum simultaneous write speeds in megabytes, divide the total camera traffic by 8 to convert it to MB. For example:

Assume the IP Server has 100 cameras streaming at 3 Mb/s or a total of 300 Mb/s and it is expected that they are to record 50% of the time.

The storage system must be able to write 37.5 MB/s at its maximum. Video Insight has developed a storage speed test application to confirm an IP Server's capability. This is available on the www.downloadvi.com website. Click on Tools. Under the Utilities section, the Hard Drive Speed Test will be found.

Supported types of storage:

- NAS
- SAN
- RAID 5, 6, & 10
- JBOD (with custom camera configuration, per camera)

(1) FILE MANIPULATION RULE (RULES MANAGER)

A feature that allows users to back up their files to other locations such as standard file servers, NAS or SAN can be configured using the Rules manager. This feature takes the task of remembering to backup important video recordings on the local server and automates it. File Manipulation can also move or delete videos.

2.1.F H.265 Encoding

H.265 and its use within IP Server is contingent upon hardware and IP Server version numbering. At the time of this introduction, v6.3.7 is the official base for use of H.265 with IP Server.

H.265 is the latest video compression standard which is based on H.264, driven by ever increasing demand for high definition and the rapid development of imaging technology, UHD standards for ultra-high definition include 4K UHD and 8K UHD to meet the trend in today's television and video surveillance market where 4K UHD equals 3840 x 2160 (8.29 megapixels), and UHD equals 7680 x 4320 (33.18 megapixels).

If the criteria for hardware and software has been met, then the use of approved H.265 IP Cameras should function without any *known* limitations now.

	VI MonitorPlus	Web Client	VideoWall+	VI Monitor for Mac	VI TV+	VI Mobile iOS	VI Mobile Android
Live	Yes	No (* ¹)	Yes	Yes	Yes	Yes	No
Playback	Yes	No	-	Yes	Yes	Yes	No
Video Clip	Yes	No	-	Yes	-	Yes	No
Snapshot	Yes	No	-	Yes	-	-	-
ROI	Yes (* ²)	-	-	-	-	-	-

(*¹) Live video can be shown in Low mode. (*²) ROI motion search for H.265 is supported by v7.1.1 or later.

✓ Limitation: The features that use H.265 decoder in server side, server-side motion detection or LPR etc., are not available for H.265 camera if a server does not support H.265 decoding.

2.2 LICENSING

Video Insight's licensing structure is simple: one camera requires one channel license, and one server requires one server license. Our floating licenses mean there is no need to tie a licensing seat, IP address or MAC address to a camera.

Cameras offering multiple camera views only require one channel license. Separate video streams from the same camera do not require a separate license.

Video Insight offers encoders, such as the VP16, that allow up to 16 analog cameras with only one license. Please contact us for more information on specific licensing requirements.

I-Pro, Panasonic, and Advidia cameras come free to use with an express license. This license provides the ability to add up to 32 cameras without requiring an unlimited enterprise license.

For BWC, Panasonic and Advidia camera license come free to use with an express or enterprise license.

2.2.A Panasonic Camera License Activation

Video Insight offers a bundle license for Panasonic iPRO camera made in October 2014 or later. To generate a Panasonic camera license for the Video Insight serial number registration process, please follow the instructions found in [Tab: Administration: Panasonic Licensing](#).

2.3 CLIENT SOFTWARE REQUIREMENTS

2.3.A VI MonitorPlus

VI MonitorPlus is a Client application designed to manage the resources of an IP Server environment within a facility or a geographical location. It runs on industry-standard hardware and works with 32-bit and 64-bit versions of Microsoft Windows 10.

2.3.B Web Client

To view the Web Client on the hosted server, the following HTML5-compliant browsers are known to function as needed:

- Microsoft Internet Explorer 11+
- Google Chrome
- Microsoft Edge
- Mozilla Firefox

NOTE - Other HTML5-compliant browsers may work; however, support is currently provided only for the browsers listed above.

2.4 CLIENT HARDWARE REQUIREMENTS

Because video decompression is performed *on the client* side, VI MonitorPlus hardware requirements are different from those of IP Server's.

VI MonitorPlus requires additional system memory, video memory and graphic processing capacity where large numbers of cameras are viewed, or while processor-intensive compression protocols are used.

PC Desktops and Laptops

Component	Minimum	Recommended (H.265 Cameras)
Processor	Intel Core-based platforms (1 2.4 GHz dual-core); 4th Gen Intel HD Graphics.	6th Generation or later, Intel Core processor (1 3.1 GHz Quad-Core+)
Memory	8GB	8GB+
Video	512 MB	1GB+
Network	100 Mb/s	1GB/s+
Resolution	1600 X 900	1920 X 1080

Small Form Factor computers (Intel NUCs)

Component	Recommended
Processor	Intel Core i5-4250U 1.30GHz
Memory	4GB RAM (Device supports up to 16GB)
Video	HD Intel 5000 Graphics Card
Network	10/100/1000GB NIC

NOTE - Video subsystem must support Microsoft DirectShow 9 or higher.

NOTE - Intel NUCs are NOT recommended for IP Server installations.

2.4.A Hardware Decoding

For optimum use of H.265 and H.264 codec capable cameras, the following are the minimum recommended practices:

- 4th generation Intel HD Graphics Intel Core processor-based platforms.
- GPU: Nvidia GTX 750Ti, 950, 1050, 1050Ti and 1060 (750Ti supports only H.264).
- Where a second graphics card is installed alongside the On-board Intel graphics card, it is necessary to configure the system BIOS to force-use the second graphics card as the primary display.
- Separate graphics cards and On-board Intel graphics cards connected to the monitor.
- Verify the correct driver for the On-board Intel graphics card with those found on Intel's website
- IP Server will detect whether the On-board graphics card supports hardware acceleration automatically and use the card when it is available. IP Server only enables it during live and recorded video playback and streaming for 4k or higher resolution.
- For all other instances that use server-side motion detection, thumbnails, snapshots or mobile device connectivity, the use of low speed (JPEG) hardware acceleration is due to asynchronous limitations.

Hardware decoding configuration for H.265 and H.264 is done within VI MonitorPlus. The following items must be selected:

- Enable hardware decoding in Option > Performance is required. If the CPU does not support the HW codec and the GPU does not exist, it will not display properly within VI MonitorPlus.
- "Highest Performance" is for video streaming where the display provides multiple camera views using GPU-heavy codecs such as H.264 and H.265.

3. INSTALLATION AND ADMINISTRATION

The installation process will install the following items:

- IP Server
- VI MonitorPlus
- SQL Server Express
- ASP .NET Framework
- Web Client

The administrator can select and deselect the software components required based on the needs of the system. This includes SQL database location and credentials.

NOTE - IIS, .NET Framework 4.5, and SQL Server Express are all registered trademarks of Microsoft corp. IIS and .NET Framework are installed through the Microsoft Operating system on which they are provided. Not all Microsoft Operating systems offer IIS capabilities, and some older systems are limited in their functional use. It may be necessary to upgrade the operating system completely or install a brand-new operating system entirely if there are any issues during the installation process.

The Video Insight Client Applications connect directly to the IP Server, not to the cameras or the database, requiring the Administrator to forward only three TCP ports for remote access by default. The Client applications can be used to view live and recorded video from a single or multiple IP Servers.

3.1 IP SERVER: INSTALLATION


3.1.A Installation without an existing SQL Server Database

Follow the steps below to install IP Server with Microsoft SQL Server for the first time. This option will also install VI MonitorPlus and Web Client as part of VI Enterprise Server.

Download the proper installer (32-bit or 64-bit) from DownloadVI.com.

Launch the executable installer as Administrator, then click Next.

Click Cancel to exit the process.




Select “I accept...” to agree to the terms, then click Next to continue.

Click Back to return to the previous screen or Cancel to exit the process.



Select all the components in the Features Selection list and then click Next.

Click Back to return to the previous screen or Cancel to exit the process.




The default credentials are displayed for the SQL installation; these can be changed according to each specific configuration.

Click Test Connection to validate the correct SQL configuration.

NOTE - If SQL Server is hosted on another server, the SQL Server field can be modified to match that server’s IP address or DNS hostname.


Click Next to continue.

Click Back to return to the previous screen or Cancel to exit the process.



Select the Start Menu location to create the program's shortcuts, then click Next.

Click Back to return to the previous screen or Cancel to exit the process.




Select the Install location where the IP Enterprise software will be installed.

To accept the default destination folder, click Next.

To choose another destination, click Change and manually locate the desired folder in your hard drive.

Click Next to proceed,

Click Back to return to the previous screen or Cancel to exit the process.




Once all steps have been completed, click Install to start the installation process.

During this phase, a series of informational screens will appear to inform that the installation process is underway.

After IP Server has installed itself, the initialization window will appear.

Ensure to have easy access to the Serial number provided by the sales agent for this installation of IP Server.

Click Back to return to the previous screen or Cancel to exit the process.



3.1.B Installation with an existing SQL Server Database

Use the following steps to install IP Server for the first time in an environment with a preexisting Microsoft SQL Server instance. This option also installs VI MonitorPlus Client and Web Client.

Download the proper installer (32-bit or 64-bit) from DownloadVI.com.

Launch the executable installer as Administrator, then click Next.

Click Cancel to exit the process.



Select “I accept...” to agree to the terms, then click Next to continue.

Click Back to return to the previous screen or Cancel to exit the process.

Select all the components in the Feature Selection list except SQL Server 2012 Express and then click Next.

Click Back to return to the previous screen or Cancel to exit the process.

NOTE - If TLS protocol is enabled in your platform, please contact our Support Team for assistance during this phase.
See [Contact Us](#) for more details.



The default credentials are displayed for the SQL installation; these can be changed according to each specific configuration.

Click Test Connection to validate the correct SQL configuration.

NOTE - If SQL Server is hosted on another server, the SQL Server field value shall match it is IP address or DNS hostname.

Click Next to continue.

Click Back to return to the previous screen or Cancel to exit the process.

Select the Start Menu location to create the program's shortcuts, then click Next.

Click Back to return to the previous screen or Cancel to exit the process.

Select the Install location where the IP Enterprise software will be installed.

To accept the default destination folder, click Next.

To choose another destination, click Change and manually locate the desired folder in your hard drive.

Click Next to proceed,

Click Back to return to the previous screen or Cancel to exit the process.

The screenshot shows the 'SQL Configuration' window of the IP Enterprise Server installer. It has a title bar with 'IP Enterprise Server' and a close button. The window contains two sections for SQL accounts. The first section, 'SQL Admin Account', has fields for 'SQL Server' (set to 'localhost'), 'SQL Username' (set to 'sa'), and 'SQL Password' (masked with dots), with a 'Test Connection' button. The second section, 'SQL VUser Account', has fields for 'SQL Username' (set to 'VUser') and 'SQL Password' (masked with dots), also with a 'Test Connection' button. A note at the top explains that these credentials are for a dedicated Video Insight database. At the bottom, there are navigation buttons: '< Back', 'Next >', and 'Cancel'. The 'InstallShield' logo is in the bottom left corner.

The screenshot shows the 'Start Menu Location' window of the IP Enterprise Server installer. It has a title bar with 'IP Enterprise Server' and a close button. The window prompts the user to 'Select the Start Menu Folder in which you would like to create the program's shortcuts'. Below this, there is a text input field containing 'VI Enterprise'. Underneath the input field is a list of existing folders: 'Accessories', 'Administrative Tools', 'Chrome Apps', 'Google Chrome', 'Intel® Media Server Studio 2017', 'Maintenance', 'Stack Technologies', 'Startup', 'WebPlugin3.0.0.3', and 'WebPlugin3.3.28543.0'. At the bottom, there are navigation buttons: '< Back', 'Next >', and 'Cancel'. The 'InstallShield' logo is in the bottom left corner.

The screenshot shows the 'Choose Install Location' window of the IP Enterprise Server installer. It has a title bar with 'IP Enterprise Server' and a close button. The window states: 'Setup will install IP Enterprise in the following folder. To install in a different folder, click Browse and select another folder. Click Next to continue.' Below this text, there is a 'Destination Folder' section showing a folder icon and the path 'C:\Program Files\VI Enterprise'. To the right of this path is a 'Change...' button. At the bottom, there are navigation buttons: '< Back', 'Next >', and 'Cancel'. The 'InstallShield' logo is in the bottom left corner.


Once all steps have been completed, click Install to start the installation process.

During this phase, a series of informational screens will appear to inform that the installation process is underway.

After IP Server has installed itself, the initialization window will appear.

Ensure to have easy access to the Serial number provided by the sales agent for this installation of IP Server.

Click Back to return to the previous screen or Cancel to exit the process.



3.1.C Initialization

IP Server *needs to be activated* to function properly. For this, there are *three options* available:

Activate or Upgrade license online	This can be completed on a server with an active internet connection and permission to connect to port 30000. If online activation fails, try the next option: Activate by phone.
Activate by phone	Call the phone number displayed. Give the representative your serial number. If you do not have one, the representative will ask you for a hardware code. If the account is in good standing you will be given a 16-digit activation code. NOTE - Available in the <i>United States only</i> . Please contact the sales agent or vendor where you purchased IP Server Enterprise.
Demo Mode	Grants the user the ability to use a full-featured version for up to 60 days, with a maximum of 99 cameras. Once the 60-day period has expired, the software will no longer record or display live images. IP Server will fail to start until a valid serial number is provided, or activation code is used. Re-installation is not required.

To initialize IP Server, follow the steps below:



Run the Installation program and click Next.

IP Server Enterprise Edition - Initialization Wizard

IP Server Enterprise Activation

Serial number *

☐ **Activate or upgrade your license through the internet**
On a machine with an internet connection, activate the IP Server by entering the serial number and press the Next button. This will upgrade your license to most recent amount.

☒ **Activate by phone**
On a machine with no internet connection, use the 'Activate by Phone' method. Please be prepared with the following information:
Hardware Code: **FB0166A2A334**
Call Technical support at: (713) 621-9779 Monday – Friday, 9:30AM to 6:30 PM CST
Activation Code:

☐ **Demo mode**
If you are unable to perform either of the two above methods, then enter the system in 'Demo Mode'. You can configure and activate the system at your earliest convenience.

* The serial number is found on the product package and on the sales receipt.

Cancel < Back Next >

Where prompted, enter the five-character, alpha-numeric serial number provided at the time of purchase.
Click Next.

NOTE - Clicking Cancel will abort the installation and the server will not start automatically.

IP Server Enterprise Edition - Initialization Wizard

IP Server Enterprise Registration

Please register your product by filling out the form below. Registered users receive one year of technical support and product updates. If you have an internet connection, select "Register Now". If your information changes, you can update the information at any time. If you do not have an internet connection, please uncheck the box "Register me later" and press the "Next" button.

Product Information

Serial Number:
Product Version: **7.6.1.70**

User Information

Authorized Phone Number: * City:
Name: * State: Zip code:
Company: Country:
Address: Email: *

* Required field

☒ Register me later ☐ Register Later ☒ Register Now

Cancel < Back Next >

Select *Activate by Phone* and call +1-713-621-9779 (USA only) if there is a problem activating the software with the provided serial number, or select Demo mode, to start recording immediately. (Toll charges may apply.)

Enter any relevant user information.

The Administrator has the option of registering the product now or waiting until a later date. Select the best option.

IP Server Enterprise Edition - Initialization Wizard

Server Configuration

Server Identification

Server Name: **IP Server** Version: **7.6.1.70**
IP Address: **192.168.0.1**

Database Information

SQL Server Location: **localhost** Test DB Adjust

Video Storage

Video data storage path: **F:\video** Browse

* Note: If using a Network Drive, use the UNC path (e.g. \\fileshare...)


Cancel < Back Next >

Verify the configuration for IP Server. If there is a need to modify the configuration, select make changes, and click Next.


Otherwise, click Next to accept the default values.

Server Name	The default is "IP Server - " and the detected IP address of this server. You can change this to a more friendly or meaningful name. Do not use special characters.
IP Address	This is the selected server's IP address and should not be changed.
Version	The current version of the software.
SQL Server Location	The location or IP address of the database server. 'localhost' indicates that the database and Microsoft SQL Server are local to the host computer. An IP address in this field indicates the Microsoft SQL Server is hosted on another computer. To test the connection, click Test DB. Click Advanced to modify the database connection string values: Database Name, IP Address, SQL Server User ID, and Password.
Video Data Storage Path	The location where all the recorded video is saved. The default is the local OS drive (i.e., C). The video folder is created automatically after the server configuration is completed. It is possible to save video to other locations, for example: <ul style="list-style-type: none"> • Alternate local drive: <i>For example, D:\video</i> • Shared drive: <i>For example, \\ShareHost\share\HHSvideo</i>

NOTE -. Recording to a shared location requires a User account with write permission to the shared drive, otherwise recordings will not be saved.




Add cameras using Auto Discover if needed.



Cameras, when initially added through this method, will be at their default values.

Further customization of camera settings is necessary.



Click OK.

IP Server will now run as a service on the operating system. A user desktop can be logged out of, without hampering the video recording capabilities.

3.2 VI MONITORPLUS CLIENT

3.2.A Logging In

Open VI MonitorPlus by double-clicking the corresponding desktop icon for the application.


The Login window will be displayed (*see below*).



Field	Description
User Name	User Identification for IP Server account.
Use Window Fields Account	Enable/Disable use of Windows account to log in.
Password	Password for IP Server account.
Connection Type	<div>Drop-down list with three options:<ul style="list-style-type: none">• Primary Server: access the Main Server on a single connection.• Multiple Servers: simultaneously access a List of Servers after a single login.• Use Configuration File: load login parameters from an external file.</div> <div>NOTE - VI MonitorPlus' Login Interface automatically changes its layout according to the selected Connection Type; the above image shows the interface for Primary Server. <i>See below for more information on all three Connection Types and their respective fields and options.</i></div>
Server Name	Name of the Server.
Host or Address	IP Address of the Server.
Port	Port of the Server.

(1) USER NAME, PASSWORD AND USE WINDOWS ACCOUNT

The left side of the Login Interface shows the basic fields for accessing the server(s).
By default, the User Name and Password for the main IP Server account is used.




User Name
Administrator

☐ Use Windows Account

Password
.....

When checking the Use Windows Account box, the user will be asked to enter the corresponding Windows-based credentials, overriding IP Server's account.



User Name
LOCAL_PC01\administrator


☒ Use Windows Account

Password
.....

(2) CONNECTION TYPE: PRIMARY SERVER

When Primary Server connection is selected, VI MonitorPlus will only display the primary server name on the Server Name box, with the ability of modifying both the Host or Address and the Port fields values.

NOTE - Primary server can be a database server. With the primaryserver, a shared database can be connected to pull in all servers.




Connection Type
Primary Server

Server Name	Host or Address	Port
(Test Build)IP Server -10.10.	10.10.6.16	4051

(3) CONNECTION TYPE: MULTIPLE SERVERS

The Multiple Servers option allows to connect to more than one IP Server instance using *only one login account*.

The interface shows a list of available servers, with the possibility to select or deselect them individually as needed.



Connection Type
Multiple Servers


Server List

<input type="checkbox"/>	Server Name	Address	Port	
<input type="checkbox"/>	10.231.3.39	10.231.3.39	4011	
<input type="checkbox"/>	(Test Build)IP Server -10...	10.10.6.16	4051	
<input type="checkbox"/>	10.211.1.3	10.211.1.3	4011	
<input type="checkbox"/>	10.1.3.39	10.1.3.39	4011	
<input type="checkbox"/>	10.10.6.169	10.10.6.169	4011	


Navigation icons: up, down, left, right, add (+), delete (-).

(3A) SELECTING SERVERS FROM THE LIST


Select/Deselect servers *individually* by clicking on the corresponding check boxes.




When the Server List is highly populated, the Scroll Bar on the right can be used to find specific servers within the list.



Use the Arrow buttons on the right to reposition the selected server across the list (*Up/Down*).




Select/Deselect *all* servers by clicking on the top check box, besides the Server Name title.




(3B) ADDING A NEW SERVER TO THE SERVERS LIST

Click on the plus icon [+] (*see right*).




A new blank row (in blue) will be displayed on the Servers List, and a pop-up window with the data entry for the new server will open next to the [+] button. Here, enter the IP Address or Name and the Port Number of the IP Server to connect to.

Click Update to add the new server or Cancel to exit the operation.



Optionally, click Test to confirm the connectivity. If successful, the Status field will display the new server's name.

NOTE - If the server cannot be found, an error message will be displayed on the corresponding row.




(3C) MODIFYING A SERVER

On the Server List, select the row for the server to be modified and click on the pencil icon (*see right*) to open the pop-up form containing its data.

Edit the information where needed and click Update to save the changes or Cancel to close the window and exit.


Optionally, click Test to validate the connection with the server before updating.



(3D) DELETING A SERVER

Select the row for the server to be deleted and click on the [X] icon on the right to delete it.

NOTE - This operation cannot be undone.





(4) CONNECTION TYPE: USE CONFIGURATION FILE

The Use Configuration File option allows to retrieve and use an external file (.isl format) containing a specific set of connections to one or many IP Server instances.

After selecting the option from the Connection Type drop-down list, click on the yellow icon [...] next to the Configuration File field to open a Windows Explorer session; search for the corresponding file and open it.

Once the filename has been retrieved, click Login to start using VI MonitorPlus.


NOTE - The .isl file is generated by VI MonitorPlus, using the Export Profile option from the System > Options > Connections > Specify Each Server interface.



NOTE - For more information on creating an Exported Server List, see [Use Server Profiles](#).


(5) LOG IN

Once the User Name and Password have been entered, and the Connection Type defined, click Log In to access VI MonitorPlus.




(5A) ERROR MESSAGES

If the User Name and/or Password are incorrect, the application will display an Error Message.



Likewise, if the application is not able to establish a connection with one or more servers, a message will inform the failed attempt indicating the server's IP address and Port number.



3.2.B Adding IP Servers to VI MonitorPlus

In a large organization, it is possible to utilize more than 20 video surveillance servers across multiple locations.


It is also possible to add a lengthy list of servers at one time using the Import feature. For this, an exported list of servers is needed prior to importation. The file format used by IP Server is a proprietary “.ls/” file.

NOTE - For more information on creating an Exported Server List, see [Use Server Profiles](#).


Select System --> Options and then click Connections.

Select Import From Profile.


Enter the filename or click Browse to go to the location of the saved “.ls/” file.




Select the .ls/ file to use with VI MonitorPlus.
Click OK.



NOTE - If the file is unreadable or not found *an error will appear*. If the import is successful, the full list of servers will display in the Known Video Servers grid.



A popup window indicates that VI MonitorPlus needs to be restarted for changes to take effect.




This process is accomplished by clicking the Logout icon on the upper left corner of the main dashboard


3.2.C Auto Login

The Auto Login option disables the log in window and opens VI MonitorPlus directly using the pre-configured User Account.

To activate it, open the “System” option from the Main Menu, then select “Options”.




In the System Options window, click on the “Startup” tab, then go to the “Login Options” section.



Check the “Enable Auto Login” box and enter the User and Password in the corresponding fields.

You can also check the “Verify Active Directory login” box if the User account is associated to a Windows Server profile in your network.



NOTE - Do not Log Off; instead, close all windows and shut VI MonitorPlus down; reopen VI MonitorPlus and the application will go directly to the main view overriding the Log In window.

3.3 ADMINISTRATION



3.3.A IP Server Manager (IPSM)

The IP Server Manager (IPSM) application is used to manage and troubleshoot advanced server settings. It is installed at the same time as IP Server. It provides access to many necessary administrative functions of IP Server:

- Monitors the IP Server and presents visual status cues for each server.
- Provides a Diagnostic version of the IP Server Manager for troubleshooting and system optimization.
- Manages IP Server network connections.
- Manages licensing and registration.
- Manages Lightweight Directory Access Protocol (LDAP) and Active Directory configuration.

(1) ACCESSING IPSM

The IPSM icon resides in the Windows System Tray. *It has two states:*

	ON: IP Server is functioning properly, streaming video to clients, recording video and reporting to Health Monitor Cloud (if configured). Hover the mouse cursor over the icon in the taskbar to view the server's IP Address.
	OFF: IP Server is not functioning. No video recording or streaming available.

Right-click on the IPSM icon to open the IP Server options menu:



To manage the IP Server service, configure and utilize the IPSM, select Server Configuration.

Select Start IP Server, Stop IP Server, or Restart IP Server to start, stop or restart the IP Server service.

Select Exit IP Server Manager to terminate the IPSM application and remove the icon from the Windows System Tray.

NOTE - Terminating the application prevents clients from remotely restarting the IP Server service. Select About Video Insight to display version information, technical support information, and legal terms.


(2) CONFIGURING IP SERVER

Right-click on the IPSM icon in the Windows System Tray and select Server Configuration to open the IP Server Manager.

The Service Controls Status field displays the IP Server service status.

Click Start, Stop or Restart to start, stop or restart the IP Server service.



Clicking on Close removes the IP Server Manager dialog box; it does not stop the IP Server service from recording video if functioning cameras are connected to the IP Server.



- Options - Configure options specific to IP Server.
- System Log - View the current system log.
- Network Options - Configure connection options.
- Diagnostics - Stop the IP Server service and run the diagnostic version.
- No Cameras - Run Diagnostics with cameras not started.
- Update Activation - Update the IP Server activation for use with the serial license.
- LPR Activation - Activate LPR Features
- NVR Activation - Activate Panasonic NVR Support
- VI TV+ Activation - Activate Vi TV+ Support

To exit the IPSM application, click Exit IP Server Manager. This closes the IP Server Manager in the Windows System tray only, but the IP Server service continues to run in the background, so video capture continues.

NOTE - Stopping the IP Server service prevents clients from remotely restarting the IP Server service.



(2A) IPSM: OPTIONS

Clicking on Options will display the Auto Restart Options dialog box. This dialog box offers several settings aimed at mitigating some organizational and server environment settings that could interfere with the IP Server service.


Auto Restart

Restarting the service can refresh camera connections and video streaming and alter CPU performance by releasing used resources, providing the ability to automatically restart the service for a specific day and time.

This flexibility allows the Administrator to schedule IP Server service without impacting business hours recording.

To set an Auto-Restart schedule, follow the steps below:

- Check the Enable box.
- Select the Restart Day or days.
- Select a Restart Time.
- Click OK.




Delay Service

Delaying the IP Server service start is a viable option if the server has many additional services running.

The IP Server service may have trouble initializing without services such as the Microsoft SQL database service already running.

IIS loads the localhost IP Address (<http://127.0.0.1>) if it is not able to resolve the hostname of the IP Server.


To set a startup delay, check the Enable Startup Delay box and click OK.



Options

For environments where both an Analog and an IP Server are installed on the same server, with resulting high bandwidth usage, there is an option to restrict the Analog server's resources consumption.

Enabling this feature will stop the communication between Analog and IP servers. As a result, no live streaming or recording will be performed by the IP server when the timeout threshold is reached.



EXAMPLE - in a scenario with the timeout enabled and set to 30 seconds, there is a VI MonitorPlus Client layout comprised of both analog and IP camera images. For 30 seconds, both streaming and recording are managed by the IP Server. When 30 seconds have passed, the analog cameras will stop streaming and recording due to this feature. Changing the layout will restart streaming and recording for all cameras until the timeout is reached again.

To set an analog video timeout:

- Check the Enable Analog Video Bandwidth Timeout box.
- Select the Timeout in seconds.
- Click OK.

(2B) IPSM: SYSTEM LOG

Clicking on System Log will bring up the System Log dialog box. The System Log documents warnings, errors, security, and informational messages related to various system functions.

Time	Message	Source
09/28/2015 10:48:16 AM	Video Server started at 10:48 AM - 9/28/2015	Initialization
09/28/2015 10:48:14 AM	Warning: Server has started in Demo mode.	Initialization
09/28/2015 9:39:46 AM	Video Server was shut down at 9:39 AM - 9/28/2015	Board Close
09/28/2015 9:20:56 AM	Video Server started at 9:20 AM - 9/28/2015	Initialization
09/28/2015 9:20:52 AM	Warning: Server has started in Demo mode.	Initialization
09/18/2015 11:25:36 AM	integranetwork.com\Administrator has logged in at 11:25 AM - 9/18/2015 - Monitor	CommandChannel.GetServerClass
09/18/2015 11:08:50 AM	integranetwork.com\Administrator has logged in at 11:08 AM - 9/18/2015 - Monitor	CommandChannel.GetServerClass
09/16/2015 12:10:17 PM	integranetwork.com\Administrator has logged in at 12:10 PM - 9/16/2015 - Monitor	CommandChannel.GetServerClass
09/16/2015 9:58:29 AM	Could not find a part of the path 'c:\video\10.10.4.167-368213251'.	System.IO__Error.WinIOError(20:2519:1)
09/15/2015 4:37:22 PM	Video Server started at 4:37 PM - 9/15/2015	Initialization
09/15/2015 4:37:21 PM	Warning: Server has started in Demo mode.	Initialization
09/15/2015 4:37:06 PM	Video Server was shut down at 4:37 PM - 9/15/2015	Board Close
09/15/2015 4:37:06 PM	Restart Request	CommandChannel.RemoveCamera
09/15/2015 4:36:04 PM	Video Server started at 4:36 PM - 9/15/2015	Initialization
09/15/2015 4:36:03 PM	Warning: Server has started in Demo mode.	Initialization
09/15/2015 4:35:38 PM	Video Server was shut down at 4:35 PM - 9/15/2015	Board Close
09/15/2015 4:35:38 PM	Restart Request	CommandChannel.RemoveCamera
09/15/2015 4:35:26 PM	integranetwork.com\Administrator The servers properties were updated 4:35 PM - 9/15/2015	CommandChannel.UpdateServer
09/15/2015 3:40:15 PM	Could not find a part of the path 'c:\video\10.10.4.123-1681860417'.	System.IO__Error.WinIOError(20:2519:295055)
09/15/2015 3:25:15 PM	exported video from CameralID: 5:05 AM 8/18/2015 : 5:38 AM - 1779160282,	CommandChannel.FileExport

NOTE - Only some messages may appear, depending on User level and Overall Server Configuration.


(2C) IPSM: NETWORK OPTIONS

Click on Network Options to display the Network Options dialog box.

This dialog box is used for selecting the network scheme when a server has dual NIC cards or changing the communication port of the server.

It is also possible to change Active Directory and LDAP settings.

NOTE - If the Communication Port is changed, it must also change the command port in Server Properties within VI MonitorPlus.




The Multi-Network Card Support feature allows the user to use multiple NIC cards without configuration issues related to how the TCP/IP bindings within Windows server affect the flow of traffic.

To utilize this feature, click the Advanced button. A new window appears.

Here, the Administrator selects a specific internal IP address for public-facing (internal network facing) connectivity for the IP Server.

This is the IP address that is viewable from within VI MonitorPlus, as well as the IP Address that will be associated with IIS and the Web Client.

NOTE - This feature is best utilized with virtual environments, or with computers that have multiple NIC cards. It will force the registration of the MAC address that is associated with the IP Address that is provided by the administrator.




(2D) IPSM: DIAGNOSTICS

Clicking Diagnostics displays the Video Server Diagnostics interface.

This interface is used for troubleshooting most service-related issues.

Server Settings can also be configured within VI MonitorPlus, with exception to testing the SQL database connectivity, and altering the SQL database connectivity.

NOTE - The IP Server service stops when Diagnostics is launched. To reactivate video recording and functionality, *restart IP Server manually*.




Server name	Server name previously entered. <i>It is not editable</i> . To change the name of the server, click Server Settings and configure in the left pane or from within Server Properties.
IP Address	Server's IP address and should not be changed if multiple clients will connect regularly to the IP Server.
Port	Port used by the VI MonitorPlus to control the IP Server. This port is referred to as the Command Channel Port. See list of ports for more information on ports used by the software.
Version	Software version of the IP Server. It should be the same as VI MonitorPlus to avoid errors.
Licenses	Maximum number of cameras allocated to the IP Server's serial number. Using only Video Insight Encoders, Advidia and / or Panasonic cameras on the system should reflect a value of zero.
Used	Number of cameras used against the license associated with the IP Server. If using Panasonic, Video Insight or Advidia cameras and/or encoders, no license will be used or deducted if other camera manufacturers are used and licensed with IP Server.
Available	Number of camera licenses available to add to the server.
Cameras	Cameras associated with the specific IP Server, including the Camera Name. The grid area of the Diagnostics interface is read-only. It displays all cameras, the last video write-time, the recording status, and the time the last video image was received from a camera.
Time of last write	Last time video was recorded to a file by IP Server. A time of 12:00:00 AM indicates that a camera may have Recording turned Off, or that it is not recording due to a Motion-Only recording type.
Last image received	Last moment in time video was received by the IP Server. A time of 12:00:00 AM is indicative of a camera that may be offline or not accessible. Common connectivity issues can be: incorrect credentials, network, bandwidth, or the IP Server service is not running. Visit the online FAQ section for more information on why a camera could be offline.

NOTE - Remember to start the IP Server service after exiting the Diagnostics application.

Testing SQL connectivity and Changing the SQL Database location.

There are two additional features for troubleshooting within IPSM that are not available within VI MonitorPlus. To test the connectivity with SQL Server, select the IP server found on the left-hand side of the screen:

Click Test DB to test connectivity to the database.




The database test passes when the server makes a successful connection to the database. If the IPSM is not able to connect, the test will display: "Error: Database version is not correct."

Either the SQL database did not respond, or the IP Server has an outdated version of the SQL tables. There are several reasons why the database test may have failed. See the online [FAQs](#) for reasons for and potential solutions to the failure.

NOTE - Incorrect database information may cause test failure. To update or confirm the information, click Advanced.

- Database: Enter the database name. The default database name is InsightEnt.
- IP Address: Enter the IP address or the hostname of the SQL (database) server.
- User ID: The default user ID for the *InsightEnt* database is "sa" unless opting to use the VIUser credentials entered during the setup process.
- Password: The default password for the InsightEnt database is V4in\$ight/ if using the default "sa" account in legacy systems. Otherwise, the password will be as selected during the setup process.




(2E) IPSM: NO CAMERAS

Another troubleshooting option is the use of Diagnostics that do not display live-video feeds for cameras associated with the IP Server.

This option does not consume any bandwidth, which might be useful when troubleshooting connectivity issues, or in environments with heavy network latency.

The No Cameras option is similar to the alternative System Log within VI MonitorPlus. Camera-related features and information such as Live View and Time of Last Write will not be available after this diagnostics version is started.

NOTE - See IPSM Diagnostics for more information on running diagnostics.




(2F) IPSM: UPDATE ACTIVATION

The Update Activation option is used to update the Activation type (e.g., *transitioning from Demo to purchased licensing scheme*) or when the serial number used is upgraded with additional licenses.

NOTE - See [Installation](#) for more information on changing the activation type.

Click OK to confirm the number of licenses currently available.

When upgrading the license type from Express to Enterprise, Enterprise tab should be selected. Next, click OK.



(2G) IPSM: LPR ACTIVATION

The Update LPR Activation option is used to update the LPR Activation.



To use the LPR feature, the USB dongle is required.

Enter Activation Code.

To validate the license, click Test.

Once IPSM confirms the provided license information, click OK.

Restart IP Server, then the license will be activated.




(2H) IPSM: NVR ACTIVATION

The Update NVR Activation option is used to update the NVR Activation.


Enter Activation Code.

To validate the license, click Test.



Once IPSM confirms the provided license information, click OK.

Restart IP Server, then the license will be activated.



NOTE - If License type is Express, NVR will not be activated.

3.4 ADVANCED INSTALLATION CONFIGURATION INFORMATION

3.4.A Installer: InstallShield

By default, the Setup_x64.exe installer for IP Server Enterprise places files into the *C:\Program Files\VI Enterprise* folder location and the Setup_x86.exe installer places into the *C:\Program Files(x86)\VI Enterprise* folder location.

NOTE - It is not possible to use a 64-bit installer to install into a 32-bit Operating System.

In instances where it may be necessary to know where packages are installed, they can be found in the local directory:
C:\Users\YourUsername\AppData\Local\Downloaded Installations.

3.4.B Server Backup and Restore

IP Server can be backed-up manually. It is important to note that the reinstallation of IP Server requires the same version of software for reinstallation from backup due to differences in each database version. Therefore, it is recommended to maintain a backup of the IP Server installation software with the system backup.

If slightly different version is used, there may be a minor error during the installation, which may require Technical Support's assistance. In other cases, where different sub-versions are used, it may not be possible to restore IP server completely without a great deal of work.

With that observation, it is important to note the specific version used at the time of back up, and then any subsequent upgrades from that version to the current download to minimize any potential problems with the restoration process.

(1) BASIC IP SERVER BACKUP PROCESS

The IP Server can be backed-up with a minimum of effort. The steps below are provided with the assumption that SQL is located on the local server. It may be necessary to modify the steps to meet the needs of any custom installation done based on your organization's configuration.

On the host IP Server:

1. Open VI MonitorPlus.
2. Go to Help > About.
3. Note the version number of VI MonitorPlus /IP Server in use.
4. Go to <http://www.downloadvi.com> and find the matching version number of IP Server.
5. Download the matching version of IP Server / VI MonitorPlus.
6. Save the downloaded file to a safe location. (i.e.: a USB drive, a NAS device, another server, etc.).
7. Open the system's Start menu and choose Run.
8. Type: services.msc
9. Locate "Microsoft SQL service".
10. Right-Click and choose Stop.
11. Browse to My Computer > Local Disk C > Program Files > Microsoft SQL Server > MSSQL.1 > MSSQL > DATA
12. Copy Insightent.mdf and Insightent_log.ldf
13. Save these to a safe location. (i.e.: a USB drive, a NAS device, another server, etc.).
14. Return to the system's Start menu and select Run.
15. Type: regedit
16. In the new window that appears, browse to HKLM>Software>Video Insight.
17. Right-click the Video Insight folder and choose Export.
18. Save this file to the same location as the other files listed above.

(2) BASIC IP SERVER RESTORE PROCESS

Restoring an IP server from a backup, when following the procedures above, is an almost effortless process. If the steps above were followed, there should be no issues with a reinstallation of the IP server software, SQL database and/or the registry keys required for reinstallation. If a problem does arise, our Technical Support team is available during the hours listed at the end of this document.

To restore IP server, follow these steps:

1. Go to Start > Run
2. Type: services.msc
3. Find "Microsoft SQL service"
4. Right-Click and choose Stop.
5. Locate the files saved during the backup process and copy InsightENT.mdf and InsightENT_Log.ldf
6. Browse to My Computer > Local Disk C > Program Files > Microsoft SQL Server > MSSQL.1 > MSSQL > DATA
7. Paste InsightENT.mdf and InsightENT_Log.ldf and replace the existing files of the same name (if they exist).
8. Locate saved files and double-click the Registry export file. This will re-install the registry keys.
9. Locate services.msc again.
10. Find "Microsoft SQL service"
11. Right-click and choose Start.
12. Reinstall the IP Server software with the same version number.
13. Reboot the computer after the installation is completed.

Congratulations. IP Server has been restored.

3.4.C Edge Recording

Failover Edge Recording, sometimes referred to as “Edge Storage,” “Local Storage” or “On-Board” camera recording, is a feature of a camera designed to record video directly onto an SD card or other type of memory card physically installed on the camera-instead of a separate NVR or storage device.

Edge Recording, first released in IP Server v6.3.7 is to be used as a temporary bridge between the immediate need to capture video footage in case of a temporary IP server failure and the need to expand to a larger, fully redundant failover system. It is compatible with Panasonic iPRO and Advidia Cameras only at the time of this publication.

NOTE - Edge Recording does not work in conjunction with the IP Server Failover server. In other words, If Edge Recording and Failover server are used at the same time, ALL VIDEO RECORDING FOR NON-EDGE CAMERAS WILL BE LOST. i.e. The video recording feature will not work on IP Server.

(1) OVERVIEW

Fail Over Edge Recording, when used with Video Insight’s IP Server, allows for a temporary loss of connection between the IP Server and the camera without losing critical video captured during that time.

The camera will begin recording video after detecting a connection loss with the IP Server.

Once the connectivity between the IP Server and IP Camera is re-established, the IP Server will download the recorded video automatically. After the video is downloaded from the camera’s SD Memory Card, then and only then will it be available for playback within VI MonitorPlus.

Necessary Considerations:

Failover Edge Recording was designed in response to the growing demand for reliable access to recorded video during a temporary NVR failure, or temporary loss of network connectivity between the NVR and the IP Camera.

Because of the loss of recorded video during critical times, Failover Edge Recording technologies have developed as a result. Yet, to prevent video loss, it should be stated that it is also necessary to assess the overall network equipment needs in order to achieve the greatest success and results with Failover Edge Recording.

Example:

During a temporary power outage, it is common to supply UPS battery backups for all servers in a server closet that supply power to the NVRs and mission critical computing devices.

However, for Failover Edge Recording to be truly successful, it is necessary to ensure that the total power consumption of any network switch responsible for powering Failover Edge Recording IP Cameras be taken into consideration as well.

Otherwise, without the use of a battery backup system to power IP Cameras using Failover Edge Recording technology, then the capture of Video Recording is negated and lost- even if the NVR remains functional during the power outage.

In the event of an unforeseen power outage, any camera that is not connected to a power source will not provide Failover Edge Recording due to a lack of power to the PoE switch. Thus, a lack of power to the PoE switch means a lack of power to the Edge Recording camera.

It is important to provide a battery backup system to the switch, or alternatively wire the cameras to get power from an alternative power source in the event of a power failure for Edge Recording to function as it is designed.

Configuration Description

The differences between normal IP Camera configuration and Failover Edge Recording configuration are the addition of some type of memory card and the confirmation of changes within the IP Camera for Failover Edge Recording to occur.

A basic outline of the process is as follows, in the necessary order for successful setup of Failover Edge Recording:

- Phase 1: Camera-Side Configuration
- Phase 2: IP Server Configuration
- Phase 3: Verification of communication between IP Camera and IP Server

(2) PREREQUISITES FOR EDGE RECORDING FUNCTIONALITY

The following items are required for the successful deployment of Failover Edge Recording. Any deviation outside that which is described in these prerequisites can cause a failure in Failover Edge Recording and a loss of critical video data.

(2A) REQUIRED HARDWARE

For long-term successful deployment of Failover Edge Recording:

- An appropriately sized SD/SDHC/SDXC memory card to match recording storage needs
- Panasonic branded IP cameras running firmware v2.50 or later (Subject to change in future releases of IPServer)
- Functioning network equipment
- Necessary battery backup systems to power IP Cameras and/or POE switches in the event of a power outage

(2B) REQUIRED SOFTWARE

Prior to configuration of Failover Edge Recording:

- Video Insight's IP Server running at software version 6.3.6.4 or later
- SD Memory card is installed into the IP Camera

(3) SETUP AND CONFIGURATION

The following steps are to be followed in order. Once the initial setup has been confirmed functioning, other changes within the camera can be made.

Consideration to the following steps are necessary for ease of installation:

- The camera is connected to the network and powered on
- The camera is set to its default values with firmware v2.50 or later
- The camera has a new SD Card installed and is ready to be formatted

If any of the three criteria are NOT followed, then Failover Edge Recording will not successfully be implemented.

(3A) CAMERA CONFIGURATION

With the assumption that the SD Card has been installed, and the camera has been connected to the network, it may be necessary to first access the camera's web page to set the default Administrator account.

Administrator registration
Enter the user name and password of the administrator.

User name (1 to 32 characters)

Password (8 to 32 characters)

Retype password

Note:
(1) Distinguish between upper- and lower cases.
(2) Entry of the following is not allowed as a user name: 2-byte characters, and 1-byte symbols * & ; \.
(3) Entry of the following is not allowed as a password: 2-byte characters, and 1-byte symbols * &.
(4) For the password, use two or more types of characters from alphabetic characters, numbers, and symbols.
(5) Keep the user name and password at hand so as not to lose.
(6) It is recommended to change the password periodically.

Enter a username and password to access the camera being used with Edge Recording. Be sure to remember this information as it will be critical for accessing the camera settings and features in the future.



A confirmation message will show once the new administrative account password has been set.


PAUSE HERE. DO NOT REBOOT THE CAMERA.

Next, minimize the browser window for the IP camera.

NOTE - Reopen the browser to confirm the correct configuration and access between IP Server and the Camera.


(3B) IP SERVER CONFIGURATION

Add camera through normal process, as described in the Installation section.



After a camera is added to IP Server, open Camera Properties and select the Recording tab.

Select Enable Edge Storage found on the bottom right-hand side of the screen, under the Video File Storage section.



Click on Save; Restart VI MonitorPlus AND Video Insight's IP Server.

NOTE - Wait until IP server is running again before proceeding.

(3C) COMMUNICATION VERIFICATION

The process of verification of communication between IP Server and IP Camera is crucial to determining the efficiency of Failover Edge Recording. This step will help make troubleshooting easier in the event of an unlikely Edge Recording failure.

After the IP Server has restarted, open the camera's Management interface within the internet browser window that was minimized at the end of Step 1, and proceed as follows:



On the next page, Select Setup.

On the Setup page, the green button labelled Basic should be highlighted by default.

Select the SD Memory card tab at the top of the screen.

On the SD Memory card page, verify the following:



SD Memory card:

USE *must* be selected if it is not already.



Overwrite **MUST** be ON if it is not already.

Recording Stream 1:

This is set to H.264 (1) by default.

It is possible to select one of the four available H.264 settings. * *see notes below for more information*


SD memory card information: Format the installed SD Card

** *see notes below*

This page provides an easy way to determine if the IP Server has successfully connected to the IP Camera with Failover Edge Recording enabled. Verify that the Save Trigger (under Recording Stream 1) is greyed out and displays the phrase Network failure.

Network failure *should* appear, as displayed on the left. This is confirmation of a successful connection with the IP Camera and Failover Edge Recording.


If Network Failure IS visible, reboot the camera by doing the following steps:



Select Maintenance (on the left)



Select Default reset tab



Find Reboot from the list of options presented and then select Execute. (The reboot process takes 2 minutes.)

Congratulations! Edge Recording is now configured!

NOTES:

* The image above depicts only the first selection for H.264 configuration settings as an example. It is recommended that the owner's manual be read for the specific camera used with EDGE Recording to better understand how this specific section will affect the captured video recording while implemented by Edge recording.

** If the SD Card has been installed and never formatted, it is recommended that a full formatting of the card be done the first time Edge recording settings are configured to ensure that video is captured.

*** If Network Failure is *NOT* visible now, then IP server is not communicating with the camera. It is recommended that the camera be removed from IP server and that the camera be defaulted to original factory condition and the steps above.

3.4.D Rules Manager

Rules Manager provides necessary automation of certain tasks to help the Administrator or any desired features range from sending email to a specific email address after a video camera detects motion, to moving video files from one location to another for the purposes of server maintenance and long-term storage.

Rule Creation Process Cheat Sheet

Basic Steps	Trigger Events	Action Events
<ol style="list-style-type: none">1. Open VI MonitorPlus2. Click the Administration tab3. Click on the Rules icon4. Select the + icon for new rule creation5. Select Add Trigger OR Add Action	<ol style="list-style-type: none">1. When the new Trigger selection window appears, select the trigger desired for activation2. Provide the necessary information for that trigger to become active3. Click OK4. Move to Action events section below the Trigger events section5. Select Add Action	<ol style="list-style-type: none">1. After the new Action Events window opens, select the desired resulting action event.2. Provide the necessary information within the Action being used3. Click OK4. Restart IP Server5. Test rule for verification

These are the most basic steps required for the creation of a rule that will increase the productivity, security, and further enhancement of the Video Insight IP Server Enterprise suite.

(1) BASIC CONCEPTS

In most scenarios, a rule is made up of two parts: Triggers and Actions.

A trigger can be as simple as motion detection on a camera. A subsequent action can be to take a snapshot of the image and to email it to a specific email address. The rule itself, in basic terms would be written as: When there is motion on a specified camera, take a snapshot and send that snapshot to a specific email address.

(2) CREATING A RULE

To start the process of rule creation, it is best to open VI MonitorPlus and select the Administration tab at the top of the screen. Then, once the Administration tab has been selected, click on the Rules button in the navigation menu.

Creating a rule takes many considerations, but it can be broken into four specific areas:

- Rule Properties
- Schedule
- Trigger Events
- Action Events

To create a New Rule, click the + symbol to the right of the Rules bar.



(3) RULE PROPERTIES

Once the Rule creation process is started, give the new rule a unique name and a description.

During Rule creation, it is important to be mindful of instances where VI MonitorPlus might be connected to more than one IP server. If VI MonitorPlus is connected to multiple IP Servers, it is necessary to verify the name of the server where the rule will be applied so that a newly created rule does not inadvertently damage another server.

Enable Rule: Sometimes a rule loses its usefulness or causes a conflict with other rules.

Name: Provide a descriptive name.

Server: Select the server from the drop-down where the rule will apply.



NOTE - To determine which rule might be contributing to a problem, the ability to disable or re-enable a rule manually is available. This allows the Administrator the temporary ability to troubleshoot or configure other items within IP Server.

(4) SCHEDULES

Schedules are a necessary tool provided to perform certain maintenance and functional tasks within the operational use of IP Server.

The default condition for all Rules is to *run always*. This means that no Schedule is necessary if there is no need for an Action to occur unless it is to occur at a specific time of day.

(4A) SCHEDULE SETUP

Add Schedule

When the Rules manager tool within VI MonitorPlus opens, and the Add Schedule button is selected, a new pop-up window will appear.

This new pop-up allows the user to provide a name for the schedule, the frequency which it runs, the days that it will run, and the times that it will run.

NOTE - It is recommended that the name of the schedule serve as a reminder for the trigger and action events for later troubleshooting, if necessary.

Please refer to the documentation below regarding use of the scheduled days.

It may be necessary to create multiple schedules for events that overlap the 11:59 pm to 12:00 am threshold.

Select the appropriate number of times the rule will run. This is critical for the long-term success of the rule, without errors.

One Time - The Rule will work only once, and it will not be repeated at any point in time unless manually triggered by the user.

Daily - The Rule will run either every Weekday, every Weekend Day, or every Day, at the specific times selected, as long as it is active.

Weekly - The Rule will be executed on a specific set of Days of the Week, during the selected time interval.

Monthly - The Rule will run either Once (by selecting a specific Day), or during a specific occurrence of Days and Weekdays in a Month. within the selected Time interval.

After all the necessary criteria is provided in the fields above, click on OK. The schedule is now complete.

(4B) MULTIPLE SCHEDULES

The most common occurrence for multiple schedules is usually tied to tasks that occur on a weekly or monthly basis according to the need of the IP Server Administrator.

If a series of actions is required multiple times per day, multiple schedules can be created within the same rule.

It is important to note that the Default for all created rules is for them to run at *all times*. Adding a schedule to a rule that runs always may prove the rule to be ineffective or result in an undesired effect if added haphazardly.

NOTE - The schedule timer runs on a 12:00 am to 11:59 pm cycle for each day.

This means that each segment of a scheduled task is limited to the specific day of that task and will not overlap with other tasks. It will not span the course of multiple days, even if it appears that it would, otherwise.

Therefore, it is required that multiple schedules be created if there is to be a repetition of actions based on selected triggers spanning the course of many days where the threshold between any two days is required.

(5) TRIGGER EVENTS

Trigger Events are best thought of as a *cause* for an action. Within VI MonitorPlus, Trigger Events occur as the direct result of something that has happened. Once the event has occurred, it will be followed by an action that is designated below:

Trigger Events can be considered as the “IF” in an “If, Then” statement. (*IF Trigger event occurs, THEN do this Action Event*). When creating a rule, the Administrator should first consider what event it is that is occurring that needs to have an action follow it.

(5A) TRIGGER EVENTSETUP

It is important to determine whether the event needs to meet multiple criteria or if it requires only one event to occur prior to an action event.

Knowing that information allows the administrator to determine whether the Trigger event will work as desired with the Action Event that follows.

To keep things simple, it is suggested that the first rule created have as few items as possible. Once it is determined that the rule was successfully created, it will be easier to determine if there is a problem down the line.

EXAMPLES:

- *Single Event (Any)*
IF a Camera becomes unresponsive OR a specific user logs in to IP Server.
- *Multiple Events: (AND)*
IF Camera becomes unresponsive AND specific user logs into the IP Server.

(5B) TRIGGER EVENT OPTIONS

Event Type	Event Description
Access Control Event	Trigger off of an Access Control Entry or Alarm
Alert Button	An alert button appears in the navigation tree
Analytics	Trigger off of a supported Camera's Analytics
Camera Down	Trigger when a specific or all cameras stop responding.
Digital Input	External input device (i.e Alarm)
License Plates	Trigger when a License Plate is found
SDK Input	Receive data from a TCP Port
▶ User Login	Rule triggers when a user logs in.
Video Motion	Motion is detected on a specific camera

Selecting Add Event results in a new window appearing within VI MonitorPlus. The window offers the following options to select from. A description of what each Event Type does is explained in the chart below in a little more detail.

(5C) TRIGGER EVENT DEFINITIONS

Trigger	Description
Access Control Event	Triggers an Access Control Entry or Alarm
Alert Button	Triggers when an alert button appears in the navigation tree
Analytics	Triggers from a supported Camera's Analytics *
Camera Down	Triggers when a specific camera stops responding or all cameras stop responding
Digital Input	Triggers based on external input device *
License Plates	Triggers when a license plate is found *
SDK Input	Triggers based on receiving data from a TCP port *
User Login	Triggers when a user logs into the IP Server
Video Motion	Triggers when motion is detected on a specific camera *


** Items with an asterisk, listed above, require that the device has the capability of the function itself. Please refer to the device manufacturer's user guide for information on how to utilize its functionality for best results.*

(6) TRIGGER INPUT REQUIREMENTS

Access Control Event

Access Control Events allows to trigger an Action based on a valid entry or on a door alarm

Define a unique Reference Name; select a Door from the Door Name drop-down list and, for Access Type, select either Alarm or Entry.



The screenshot shows a configuration window titled "Access Control - Events and Alarms". Below the title is a descriptive text: "The following allows you to trigger an action based off of a valid entry or a door alarm." There are three input fields: "Reference Name" with the value "Access Control Event", "Door Name" with a dropdown menu showing "1501 case O2", and "Access Type" with a dropdown menu showing "Alarm".

Alert Button

This type of Event only requires a unique Reference Name, which will be displayed in the Alert Buttons menu at the top right of the main application window.



The screenshot shows a configuration window titled "Alert Button Event". Below the title is a descriptive text: "The reference name defines what name will appear on the button. This button will appear in the 'Alert Buttons' menu at the top right of the main application window." There is one input field: "Reference Name" with the value "Alert Button".


Analytics

Camera Analytics are used for camera "training" in areas that require enhanced security functionality.


Define a unique Reference Name, select the Camera from the drop-down list and the Analytic Rule to be applied, if available.

Cameras that can enhance their capabilities over time may offer a variety of functions based on their set of features.

To use this feature, open the Camera Properties for the selected camera and check the "Capture VCA Event" box in the "General" tab, "Additional Options" section.



The screenshot shows a configuration window titled "Video Analytic Event". Below the title is a descriptive text: "This event will occur whenever the selected Video Analytic event occurs." There are three input fields: "Reference Name" with the value "Analytics", "Camera" with a dropdown menu showing "10.10.4.11 - Model: Panasonic WV-S2111", and "Analytic Rule" with a dropdown menu.




The screenshot shows the "Additional Options" section of a configuration window. It contains three checkboxes: "Enable Secondary Stream" (unchecked), "Capture VCA Events" (checked and highlighted with a yellow box), and "Capture Graphics Objects" (checked). Below these is a "Joystick #" field with the value "0" and a plus/minus button.

Camera Down

The Camera Down Event relies on multiple variables to be triggered. Most commonly, this trigger becomes active when a camera cannot be logged into by the IP Server or becomes unresponsive due to a network outage.

It is helpful for early detection of issues that might not be immediately noticed by the Administrator.

Define a unique Reference Name for the Event and select the Camera(s) to be monitored from the list.



Camera Down

This event will occur whenever one of the checked cameras goes down.

Reference Name


Camera(s) ☐ 10.10.4.11 - Model: Panasonic WV-S2111L (10.10.4.11)

Digital Input

Some manufacturers provide cameras with the ability to enhance their functionality using Digital Input/Output devices within VI MonitorPlus.

Most commonly, a microphone is used with a camera via Digital Input/Output to record conversations within its range.

Define the unique Reference Name for the Event, then select the Camera from the drop-down list of available devices, its Port, and the Trigger Type.



Digital Input Event

This event will occur whenever a camera gets a Digital Input (DI) signal. Make sure the camera has the DI port properly wired, and configured.

Reference Name

Camera

Port ID

Trigger

Condition met when switching from Off to On

Note: This is only supported on certain cameras that support digital inputs.

License Plates

License Plate Recognition (LPR) Events occur when a license plate that is either in or not in the Group listed below is detected by a specific camera.

It requires a unique Reference Name, a Trigger Condition (license plate *IS* or *IS NOT* in the Group below), the corresponding License Group and the Camera that will detect the event.

Additionally, when an Entry is detected, a Notification message can be sent to All Users connected to the server or to selected User or Groups defined from a list.

The screenshot shows a configuration window titled "License Plate Recognized". It contains a text box for "Reference Name" with the value "License Plate Recognition". Below it is a dropdown for "Trigger Condition" set to "License plate IS in the Group below". There are also dropdowns for "License Group" and "Camera". A section titled "Notify Clients on Entry" has four radio button options: "Disable Notification" (selected), "All users connected to this server.", "Selected user(s) listed below.", and "Selected group(s) listed below.". Below these options is a large empty text box. At the bottom right are "OK" and "Cancel" buttons.

SDK Input

SDK Input Events allow the IP Server to interface with other software and hardware manufacturers connected to the same network; they indicate that IP Server is receiving data from the connected SDK device/software.

The value for Port Number must be *unique* to the server, as well as the Reference Name.

This is only used by software and hardware developers and for testing purposes.

The screenshot shows a configuration window titled "SDK Event". It includes a text box for "Reference Name" with the value "SDK Input" and a "Port Number" spinner box set to "1". A note at the bottom states: "* For more information see the SDK documentation".

User Login

User Login is for notifications to groups of Admins or higher-access-level Users who need to monitor a system for unusual access rights, or for routine use of IP server.

A unique Reference Name must be provided, as well as the selection of Clients and Users to be monitored (*see list of options in the image*).

When a User logs into the system, it is recorded into the IP Server System Log files.

The screenshot shows a configuration window titled "Login Notification". It has a text box for "Reference Name" with the value "User Login". Under the "Clients" section, three checkboxes are checked: "VI MonitorPlus Logins", "Web Client Logins", and "Mac / Mobile Logins". Under the "Users" section, the "All Users" radio button is selected. Below it, the "Specific Users" section has a list box containing "Administrator", "TestUser", and "joep", each with an unchecked checkbox.


Video Motion

Motion Events occur when there is motion detected on a camera.

NOTE - The level of motion that triggers this event can be configured in the Camera Setup module of VI MonitorPlus.

This event requires a unique Reference Name and to select either a single specific Camera or All cameras in the network.

Motion Events are recorded in the IP Server System Logs and can be utilized by an Action Event.



(7) ACTION EVENTS

Action Events are operations and actions resulting after a Trigger Event occurs, based on their criteria.

Below is a list of available Action Events. Not all action events will function with all trigger events. Refer to the Functional Relationship Guide further below this section for a complete reference of Trigger Event and Action Event interactions.

(7A) ACTION DEFINITIONS

Actionable Input	Description
Door State	Change the state of the door.
Digital Output	Send a digital output on a specific port.
Execute a program	Send a program to a specific user running VI MonitorPlus to execute.
HTTP Command	Send an HTTP command to a specific device.
TCP Message	Send ASCII message to TCP socket.
Email	Email a custom message.
Email AVI clip	Email AVI file to a specific user.
Email Flashback Image	Email Flashback image.
Email Snapshot	Email a snapshot of an image to a specific email address.
Action Event Log	Create an action event for the Media Player.
Alarm Window	Displays alarm window for client within Workspaces and Message Display.
Audio Alert	Audio alert for a specified VI MonitorPlus Client.
File Manipulation	Copy, Move or Delete files.
Instant Replay	Pop up a 30-second review of recorded video on a specific camera.
Live Window	Pop up window for displaying a live camera feed.
Message instruction	Message instruction for the VI MonitorPlus Client.
Move PTZ Camera	Move a PTZ camera to a specific location.
Record	Set a recording type.
Record with Audio	Create a video file with audio included.
Switch Audio	Switch viewing field to a specific camera, capable of audio recording.
Switch Camera	Switch VI MonitorPlus 's main layout to a camera view.
Switch View	Switch VI MonitorPlus 's main view to a specific view.
Time Lapse Recording	Create time-lapse recordings (very low frame rate).
Monitor Points	Mask / unmask monitor points.

(7B) ACTION EVENT SETUP


On the Rules Manager Rule Creation page, the Actions section provides the option to customize actions that will take place *AFTER* a trigger is received by the server. Not all actions require a trigger to function, yet all actions will be affected by any triggered schedules. Be very careful when selecting specific time-related triggers as they may have an adverse effect on subsequent Actions.

Action events can be used to further enhance a linear chain of events, which result in the action becoming a trigger for a second action, and so on. Please refer to the definitions for each Action below the Action Event Setup procedures.

Action Event Creation


The process of creating an Action comes after a Trigger Event is created. To create an action that is used with a trigger, click the Add Action button.

Add Action



The screenshot shows a window titled "Actions" with a subtitle "Actions - To be Performed when the Rule Executes". It contains a table with two columns: "Action Name" and "Action Type". To the right of the table are three buttons: "Add Action", "Remove", and "Properties".

A larger Add Action window appears. This window provides a comprehensive list of the available actions that can be taken.



The screenshot shows the "Add Action" window. On the left, there is a list of "Possible Actions to be Performed" with columns "Action" and "Action Description". The "Action Event Log" action is selected. On the right, there is a section titled "Action Event Log" with a text box containing the description: "Action Event Log will allow you to view the camera at a specific event. When this action is triggered, it will log the event in the Action Database". Below this, there are three fields: "Name" (set to "Action Event Log"), "Camera" (a dropdown menu set to "Fisheye"), and "Action Text" (an empty text box). At the bottom right are "OK" and "Cancel" buttons.

Select the desired action to be taken.

NOTE - Depending on the action it is necessary, in most instances, to provide some additional information for the specific action for it to function properly.

When completed, click OK

(7C) ACTION EVENT EXPANDED DEFINITIONS

Door State is a function of Access Control trigger events. Its function as an action is designed to act as a timer for a noticed change in a door status over a period of time.

Additionally, it can be used to automatically change Access Control door status from locked to unlocked or vice versa.

The 'Set Door State' window has a title bar 'Set Door State'. Below it is a description: 'This feature sets the state of a door when triggered.' There are two sections: 'General Information' and 'Door Information'. In 'General Information', the 'Name' field is 'Change Door State' and the 'Interval' is '10' seconds. In 'Door Information', the 'Door' field is empty and the 'Door State' is 'Unlock'.

Digital Output is an Action event which works to aid in the enhancement of a security device with the use of additional input from that device. This is an Action Event that relies on a specific trigger and acts as a trigger.

The 'Digital Output' window has a title bar 'Digital Output'. Below it is a description: 'Digital Outputs (DO) are signals sent from the Video Server to a specific camera to engage other devices. Sirens or flashing-light alarms are examples of DO devices.' There are four fields: 'Reference Name' is 'Digital Output', 'Camera' is '10.10.6.106 - Advitia - Model: A-44-IR', 'Port ID' is empty, and 'Duration' is '10' seconds.

Execute a Program is designed to force a program on a computer to also start once the corresponding trigger value is assigned to it.

For example, a program could be started when a specific user login trigger is activated, saving time for the user on their machine.

The 'Remote Execution' window has a title bar 'Remote Execution'. Below it is a description: 'The following allows you to send a program to be executed by a specific user on a remote Monitor Station.' There are two fields: 'Reference Name' is 'Execute Program' and 'Executable Name *' is empty. A note says: '*Note: The executable file should be placed in the <Program Files>\VI Enterprise\Enterprise Service\upgrade folder'. There is a section 'Recipients' with three radio buttons: 'All users connected to this server.' (selected), 'Selected user(s) listed below.', and 'Selected group(s) listed below.'. Below the radio buttons is a large empty text area.

HTTP Command is designed to work with certain camera and hardware manufacturers to issue commands to those devices using specific Hypertext Transfer Protocol.

Some of these devices have the capability to receive an HTTP command from remote locations to modify the functional use of different portions of its internal software.

The 'HTTP Command' window has a title bar 'HTTP Command'. Below it is a description: 'This action sends an HTTP Command to the given URL.' There are three fields: 'Name' is 'Send HTTP Command', 'HTTP Command' is 'http://', and 'Optional Variables' is empty. There are also fields for 'User' and 'Password'.

TCP Message gives the user the ability to send a pre-written message to a remote computer and specific port where the sent message is intercepted at the remote receiving end.

This can be read by the Administrator of the receiving computer and utilized for enhanced security purposes.

Email messages can be sent after the IP Server has been properly configured for using SMTP Services with an email provider.

This feature will send specific information to a group of users of a specific user. The message and subject line can be customized to accommodate the needs of an email filter, if necessary.

Email AVI clip allows the IP Server Administrator to capture a certain specified amount of recorded motion and clip it into a file of desired file size chosen by the administrator.

It will then email that file to a user, user group, or all registered users so that the triggered event details can be observed and recorded at a convenient location.

TCP Message

This action sends an ASCII message to a TCP socket signalling occurrence of this event.

Name

TCP Message

IP Address

Port

4020

Message body:

Email Action

E-mail notification can be sent to any user set in the User Manager when the task is running. Email requires access to an SMTP Server (set in Server Configuration).

Name

Email Message

Recipients

Users

Groups

Delete

Add

From Address

Send Email Every

10

Second

Email Subject and message (Optional)

Subject

Message

Email AVI Clip

Video clips can be e-mailed to any user set in User Manager when the task is running. Email AVI Clip requires access to an SMTP Server (set in Server Configuration). Be aware of e-mail attachment size-limits imposed by some e-mail hosts.

Name

Email Video

Camera

10.10.6.106 - Advidia - Model: A-44-IR-V2

Email From

Recipients

Users

Groups

Delete

Add

Email Options

Limit Clip Size

1000

kB

Subject

Email Flashback Image gives the administrator the ability to send an email with an image at the beginning of a series of motion events which is a series of framed snapshots combined to give a range of motion over time, without the need to review the full video file.

Associate this feature with only a specific camera, as it cannot be used to select multiple cameras. This is most commonly associated with motion event triggers.

Email Flashback Image

A Flashback image provides the best Flashback image when the task is running. Email Flashback requires access to an SMTP Server (set in Server Configuration).

Name

Camera

Email From

Recipients

☒ Users

☐ Groups

Delete Add

Email Options

Subject

Send Snapshot is used to send a single image file at the start of a motion event to a specific email address.

It can send a single image capture at specific intervals so that it is easy to determine a point in time when something that appears to normally be static, has moved.

This is most commonly used with motion event triggers.

Send Snapshot

A Snapshot is emailed at a regularly scheduled interval.

Name

Camera

Snapshot Interval Minutes

Recipients

☒ Users

☐ Groups

Delete Add

Email Options

Email From

Subject

Action Event Log is used with motion event triggers, but it can also be used with any trigger where logging is desired for specific information.

When used, it will place a specific message into the log notes.

Action Event Log

Action Event Log will allow you to view the camera at a specific event. When this action is triggered, it will log the event in the Action Database

Name

Camera

Action Text

Alarm Window sends a notification to each person logged in to VI MonitorPlus and is actively using the client. Alarm Windows can be used to alert security guards very quickly of any motion in an area, by displaying a specific camera where motion is detected.

The ability to designate specific users or groups is available.

The second criteria are the Message Body, which can list the name of the camera, location of where the camera is, or anything desired to be added for the intended purpose of notification and instruction.

Audio Alert will cause a chime to sound on ALL VI MonitorPlus clients logged into an IP Server, or the ability to specify a specific end user for administrative purposes. This is most commonly used with the user Login Trigger.

File Manipulation is used to move video files from one location to another after a specific time-period has passed.

This is most useful as a maintenance tool enhancement when used in conjunction with a NAS drive or another backup device.

Alarm Window

This feature sends an Alarm Window notification to each Monitor Station. Each Alarm Window has a window as well as a message.

Name

Alarm Window

Camera

10.10.6.106 - Advidia - Model: A-44-IR-\

Destination

☒ All users connected to this server.

☐ Selected user(s) listed below:

☐ Selected group(s) listed below:

Message body:

This will create an audio notification on the Monitor Station signalling the occurrence of this event.

☒ All users connected to this server.

☐ Selected users listed below:

☐ Administrator

☐ mblackwood

☐ q

☐ qa

File Copy, Move or Delete

The ability to move, copy or delete video after a certain period of time.

Name

Scope

☒ Server
☐ Camera

Cameras

☐ 10.10.6.106 - Advidia - Model: A-44-IR-V2 (10.10.6.106)
☐ 10.10.6.120 - Advidia - Model: A-54 (10.10.6.120)
☐ 10.10.6.122 - Advidia - Model: A-54 (10.10.6.122)
☐ 10.10.6.123 - Advidia - Model: A-54 (10.10.6.123)
☐ 10.10.6.124 - Advidia - Model: A-54 (10.10.6.124)
☐ 10.10.6.125 - Advidia - Model: A-54 (10.10.6.125)
☐ 10.10.6.128 - Advidia- A-34 - Firmware: V5.1.2 build
☐ 10.10.6.130 - Advidia - Model: A-34 (10.10.6.130)
☐ 10.10.6.181 - Advidia - Model: A-200 (10.10.6.181)

Task

Copy video to another location

after

3

days

☒ Standard

Destination

* Use UNC naming convention. (i.e \\StorageServer\Location1)

☐ Coldstore

IP Address

Port

1042

Folder

(Optional)

Instant Replay is most commonly used with motion event detection for desired cameras.

It can be used to bring to the immediate attention of security or police officers’ motion that is occurring It shows the last 30 seconds of recorded motion event.

It requires that a user, a group of users, or all users be selected.

Instant Replay

This action launches a camera's Review Thirty Second window in associated Monitor Stations. This action waits for a user-defined interval before resending triggers to Monitor Stations.

Name

Instant Replay

Camera

10.10.6.106 - Advidia - Model: A-44-IR-V2

Interval

30

Second

Recipients

☒ All users connected to this server.

☐ Selected user(s) listed below.

☐ Selected group(s) listed below.

Live Window will pop-up a display window containing live camera feed for a specific camera.

It can be used to bring the attention to the center of the VI MonitorPlus window for viewing of an event that may need immediate action taken.

Live Window

This feature triggers all connected Monitor Stations to pop up a window with the selected camera's live feed. This action waits for a user-defined interval before resending triggers to Monitor Stations.

General Information

Name

Live Window

Camera

10.10.6.106 - Advidia - Model: A-44-IR-V2

Interval

10

Second

Recipients

☒ All users connected to this server.

☐ Selected user(s) listed below.

☐ Selected group(s) listed below.

Copyright 2020 – Panasonic iPro Sensing Solutions Corporation of America

61

Message Instruction is used to send specific messages after a trigger event is fired.

It can be used with Access Control, LPR, Motion Events, Camera Outages, or any other trigger.

It appears within VI MonitorPlus as a pop-up window and can be closed by the receiving user.

Message Instruction

This action creates a message instruction on the Monitor Station signalling the occurrence of this event.

Name

Message Instruction

Recipients

☒ All users connected to this server.

☐ Selected user(s) listed below.

☐ Selected group(s) listed below.

Message body:

Move PTZ Camera, once triggered, Move PTZ Camera can force a PTZ camera to return to a specific, pre-defined, focal point.

When used with Access Control Door access, a PTZ camera located near that door can be forced to turn and capture a headshot of the individual triggering the door access code.

PTZ

PTZ cameras can be controlled through Task Manager to go to specific presets for a specified period of time.

General Information

Name

PTZ Movement

Camera

10.10.6.181 - Advidia - Model: A-201

Duration

10

Second

Movement

☒ Go to preset

☐ Cycle presets with interval of

5

seconds

Record, when triggered, can force a camera to record if it is normally not set to record anything at all, or has another restriction imposed upon it.

The creation of a new file can be forced, and other limitations can be imposed based on the needs of the rule creator.

This action is used with a wide number of trigger events and can have a variety of results based upon the needs of the rule creator.

Record

Any combination of cameras can be set to any record type, and for a specified period of time.

General Information

Name

Record Action

Record Type

Record Always

Cameras

☐ 10.10.6.106 - Advidia - Model: A-44-IR-V2 (10.10.6.120 - Advidia - Model: A-54 (10.10.6.122 - Advidia - Model: A-54 (10.10.6.123 - Advidia - Model: A-54 (10.10.6.124 - Advidia - Model: A-54 (10.10.6.125 - Advidia - Model: A-54 (10.10.6.128 - Advidia- A-34 - Firmware: V5.1.2

☒ Sort alphabetically

Select All

Advanced Options

Create New File

Never

Stop Recording at:

End of Schedule

Copyright 2020 – Panasonic iPro Sensing Solutions Corporation of America

62

Switch Audio allows the user to listen to only a single audio source.

If a pre-configured trigger activates this action, the resulting effect is that a pop-up window appears with the specific camera which is streaming audio and all other audio sources are muted.

This will allow the user to isolate video and audio to a specific source and give cause to action if necessary.

Switch Audio

This action switches the Monitor Station to switch to a selected camera's audio.

Name

Switch Audio

Camera

10.10.6.106 - Advidia - Model: A-44-IR-V2

Interval

10

Second

Recipients

☒ All users connected to this server.

☐ Selected user(s) listed below.

☐ Selected group(s) listed below.

Switch Camera functions in a way that will add another way to bring immediate attention to a specific camera where motion is occurring.

This feature will return to the view of whatever image was in place prior to its injection on the screen.

This is good for random spot checks on various cameras, so that a completely random timing interval can be used based on the trigger of a motion event

Switch Camera

This action switches the main layout of associated Monitor Stations to a specific camera. This action waits for a user-defined interval before resending triggers to Monitor Stations.

Name

Switch to Camera

Camera

10.10.6.106 - Advidia - Model: A-44-IR-V2

Interval

10

Second

Recipients

☒ All users connected to this server.

☐ Selected user(s) listed below.

☐ Selected group(s) listed below.

Switch View can force users that are logged in to use a predefined View.

A specific time interval can be assigned to that View.

This is most useful with Access Control, LPR, and motion event triggers.

No trigger event is required for use with the Switch View.

Switch View

This action switches the main view of all connected instances of VI MonitorPlus to a specific view. This action waits for a user-defined interval before resending triggers to VI MonitorPlus.

Name

Switch to Layout

View

camera tour test demo (Video Insight Demo)

Interval

10

Second

Recipients

☒ All users connected to this server.

☐ Selected user(s) listed below.

☐ Selected group(s) listed below.

Time Lapse Recording causes a camera to take a single-frame snapshot at desired intervals for any designated camera or cameras.

The video output playback frame rate can be adjusted to help manage how quickly playback appears.

NOTE: To record a Time Lapse video, it is a requirement to turn OFF Proprietary format.

The screenshot shows the 'Time Lapse Recording' configuration window. It includes a title bar, a descriptive text block, and several input fields. The 'Name' field is empty. The 'Record' section is set to '1' frame(s) per 'Day'. The 'Playback' section is set to '1' frame(s) per second. Below these are two lists of cameras, each with a checkbox. The first list is titled 'Cameras' and the second is titled 'Cameras' (though the label is partially obscured). The cameras listed include various models and IP addresses, such as '10.10.6.106 - Advidea - Model: A-44-IR-V2 (10.10.6.106)' and '10.10.6.120 - Advidea - Model: A-54 (10.10.6.120)'. The window has a dark theme with orange accents.

Monitor Points, when used with certain Access Control input devices, can be triggered to Mask or Unmask a specific function of a device.

It is an on-off switch for a two-way input device.

Depending on how the device is configured, Masking the device will force it to do the opposite of whatever configuration it holds.

Unmasking the device will revert it to the original state. Most commonly used with schedules and Access Control triggers.

The screenshot shows the 'Monitor Points' configuration window. It includes a title bar, a descriptive text block, and several input fields. The 'Name' field is set to 'Mask / Unmask Monitor Points'. The 'Action' dropdown is set to 'Mask'. Below these is a section titled 'Select Monitor Points' with a large empty text area. The window has a dark theme with orange accents.

(7D) BEST PRACTICES

When using the Rules Manager, keep the following aspects in mind to help achieving the best end results in customizing this software.

The default for rules created within the rules manager is to run always. Using the schedule will impact certain rules in a way that may not be intended.

- Keep it simple - When creating a new rule, keep things simple so that, in the event of a problem, it can be resolved easily.
- Document, Document, Document - When a rule is created, keep notes as to WHY the rule was created, WHICH steps the intended rule is supposed to perform, WHAT software and hardware devices are supposed to be affected, and HOW it is expected to function when it is run.
- Create only one rule at a time - During the creation of a rule, let it run a full course to verify that it is working as it is intended to function. Once that rule has successfully run its full course, then add a second rule. Let it runs its course completely. Verify that both rules are still functioning as desired. Remember rules two and three, then add a fourth rule.
- Multiple simple rules can create a complex outcome - When viewing rules as a step-by-step process, the creation of very complex rules can result in a variety of desired outcomes. Each rule that is created requires a trigger and an action. Actions can be used as trigger events when used in a sequence of rules.
- Troubleshooting - If a rule does not function as desired, disable each rule one-at-a-time to eliminate the possibility of a rule conflict. Sometimes two rules will fail logically, causing a conflict for one or more subsequent rules. Concentrate on the process and flow of the rule and verify that nothing is wrong with the rule syntax due to amalgigned.


3.4.E Failover Server

(1) INTRODUCTION

VI IP Server supports Automated Failover at no additional software cost. When utilizing the Video Insight Shared Database configuration, a physical or virtual server can be designated as a Failover. This server will monitor the other servers and inherit the cameras of a failed one.

For example, if there are 5 servers with one designated as Failover, when one of the 4 stops writing information to the SQL database, the Failover Server will assume the role of the failed one and all camera traffic will now be associated with that server. Once the failed server is put back into service, the Failover Server will move the cameras back to their original location.

(2) FAILOVER OVERVIEW




When utilizing a Failover Server, a shared SQL database must be configured. Note that a Failover Server should work only for one server as an alternative. Thus, after activating a Failover Server, a down server will be required to recover promptly so that system can be returned to normal operation.

(3) REQUIREMENTS

To use the Failover Server feature, the following criteria must be met:

- Two functional IP Servers with the same hardware configuration, or a secondary server with greater storage capacity. (Virtualized systems can also be used. It is recommended that the virtualized servers are on two different pieces of hardware.)
- Shared SQL Database installation; see IP Server installation with an existing SQL installation.
- At least one license and a serial number or activation key for each server.

(4) SYSTEM STRUCTURE



(4A) RECORDING DURING FAILOVER PROCESS

If a Failover Server has its own storage, a video recorded by it will not be moved to an Active Server after recovering a failed one. Thus, having the same hardware configuration is required since a server cluster feature is used.

In case of using three or more servers, shared storage is also recommended so that all recorded videos during Failover can be accessed by VI MonitorPlus after recovering.

(5) ACTIVATION SEQUENCE OF A FAILOVER SERVER


The example below provides a basic sequence for activating a Failover Server. The value of interval for checking whether a server is alive is configurable (See the Technical Support Knowledge Database for details).

1. The minimum amount of time for switching to the failover server is 11 seconds. During that time, video recording will not occur. This means that there will be a gap in the coverage for recorded video files which will not ever be accessible. The default time for failover to occur is set at 5 minutes by recommendation.
2. SQL Server data recovery - is not recovered if a shared SQL DB is not used.

NOTE - If a shared SQL DB is used for multiple IP Servers in a system, recorded data before and after switching over happens can be monitored and managed seamlessly by VI MonitorPlus.

- 1) A single failover server in a system
- 2) After an active server recovers, a backup server will transfer control back to the primary IP Server.

(6) DESIGNATE AN IP SERVER AS A FAILOVER SERVER




On VI MonitorPlus, click Administration > Servers > Setup and Configuration from the Main Menu.

Select the desired Failover Server from the Left Navigation pane.

Select the Advanced tab.

Check the Designate Server as Failover Server box.

Avoid selecting a server that is actively monitoring cameras.



During an IP Server failure, the transfer of the video recording functionality to the Failover Server will take 5 to 10 minutes.

Upon recovery from the outage, video files recorded on the Failover Server *will not* be transferred to the original IP Server.

The Failover Server will be accessed via VI MonitorPlus while the main IP Server is down.

Once the Failover Server is accessed by VI MonitorPlus, it will show all cameras and images from the offline server. Recording will continue onto the Failover Server or a previously configured Network Share location, if available.

NOTE - It is possible to access Server Properties by right-clicking the server name in the left navigation and selecting Properties, selecting the Advanced tab, and then selecting Configuring a Failover Server.

3.4.F Configure Time Value for Detecting a Disconnected Camera


VI IP Server will detect a camera disconnection. Default time is 10 minutes. Rule manager trigger can be utilized when detecting the disconnection. If detection time need to be adjusted for a system, use the possible configuration below.

Registry: HKEY_LOCAL_MACHINE\SOFTWARE\WOW6432Node\Video Insight\IP Server Ent

Key: MaxSignalGap(String)

Value: msec

After a camera is disconnected, VI MonitorPlus will show a red X on the left side panel and a warning will pop-up.



4. VI MONITORPLUS

4.1 ACCESS AND LOG IN


Open VI MonitorPlus by double-clicking the corresponding desktop icon for the application.

The Login window will be displayed).




NOTE – For more information and details on *Logging into VI MonitorPlus*, refer to: [Logging In.](#)

VI MonitorPlus is the client VMS Application that has three core functions: Live Monitoring, Viewing History and Centralized Management for configuring and optimization of all IP Servers connected to it.



4.2 FULL SCREEN MODE


VI MonitorPlus is designed to work in many environments, while following the guidelines for an easily customized viewing arrangement.



Normal view

The use of the F11 key on most keyboards will force the application into *Full Screen mode*. To exit Full Screen mode, use the Esc button, or press F11 a second time.


This will force the program window to resize itself and provide the user with quick access to the desktop background.






Full Screen view

4.3 MENU BAR OPTIONS

The new VI MonitorPlus user interface has undergone some major redesign because of important feedback from our favorite clients, industry members, and test groups. As a result, VI MonitorPlus has been reshaped to make navigation and control as simple and fluid as possible.



At the top right-hand side of the screen appears a new Menu Bar.


	This icon, when selected, allows the user to logout of VI MonitorPlus.
	The flag icon provides the user with quick access to downloaded files, notifications, and recent changes made to the system.
	This icon allows quick access to any currently configured rules once they have been configured within Rules Manager.

4.4 TAB: WORKSPACES

Workspaces are individual pages, like modern browsers, that allow customizing live and/or recorded video views.

The default Workspace view can optionally be modified to facilitate the access to specific cameras at critical times within large areas to monitor.


4.4.A Save



Open opens a previously saved Workspace within VI MonitorPlus.

Save will allow the user to arrange a series of camera views and save the workspace for easy access at a later time.

4.4.B Manage



Manage - opens a new window, displaying a list of previously saved Workspace views. This feature allows to organize the order of appearance for recently created Workspaces. The user can also optionally select a specific Workspace manager to start at the launch of VI MonitorPlus.


New Workspace - Allows the user to create a new workspace for customization.

Close All - Closes all opened workspaces.

4.4.C Application Plug-ins


VI MonitorPlus allows functionality to install additional Application Plug-ins. Whenever available, the Plug-ins can be executed from the “Application Plug-ins” section in the new Workspace.

This function *requires IP Server 7.2 or later*.




(1) INSTALLING A NEW PLUG-IN

Select Modules from the main menu and select Plug-ins.




Select the Plug-in to add from the list, then click Install.



(2) UNINSTALLING A PLUG-IN

From the Plug-in Manager, select the Plug-in to uninstall from the list, then click Remove.




4.5 LEFT HAND MENU ICONS

4.5.A Servers




Server View provides the Administrator with the capability to view all configured servers and their corresponding cameras in one convenient scrollable menu bar.


NOTE - To display all servers and cameras upon application launch, you can configure the setting to “*Start with Expanded Servers*” listed under System > Options > Startup. The Server View will also reflect the changes made by the user of Resource Groups, where changes have been made.



- Expand the Server by selecting the triangle shape, found on the left of the server name. This action expands the visible area, displaying the names of all cameras associated and controlled by that specific server.
- Applying a double-click to a camera will display the recorded video folder, by date, for that camera. Where “Show video files folders” has been activated in [Application Controls](#), below.




- Selecting the date under the camera view will display all files for the camera when file view has been enabled using [Application Controls](#).
- To collapse the view, click the triangle icon, directly left of the server.



Search

The search option is a reduction filter, which isolates servers to display the camera being searched for on any shared database. Clicking on the three vertical lines exposes four defaulted criteria that a search will search through.

If any of the options is not applicable, unchecking it will help aid in creating a faster search, but may reduce the effectiveness of the search being conducted.




Cycle Views

To cycle or page through cameras in a specific View, select and click the Server in the left tree. Use the Cycle Every option at the base of the workspace to specify a cycle time. This feature will update the cameras, keeping the View count locked. For example, if 8-camera view is selected, you will receive 8 new sets of cameras at the time specified after 30 seconds.

4.5.B Cameras

This view displays all cameras listed on all servers in order grouped by server, or camera groups. Click and drag functionality allows to click a specific camera, add it to a layout or workspace.



The order by which each of the servers shown on the Desktop View can be changed by clicking on Administration > Servers > Cameras (Add/Remove or discover cameras) and followed by manipulating the cameras into the desired order of appearance.


NOTE - Single server environments will often show the Camera View by default. Typing a camera name directly into the search field will conduct a search for a known camera name

4.5.C Views

This option allows the User to see all available Views within each server.




Clicking Views will change the current workspace layout to the selected layout. Searching for a view is possible by clicking on the magnifying glass next to the View menu title.



Clicking the ellipsis menu icon will allow you to navigate into Cycle Custom Views menu. Select the custom View you would like to cycle (rotate in View), set the cycle order by move the Views up and down in the order. You can also choose a time interval in which you wish to update the View in the cycle. The default setting will be selected at 30 seconds. To start the rotating Views, click Start Cycle.

4.5.D Maps

Facility Maps can be configured by clicking Maps found at the bottom of the left navigation menu. To find out more about Facility Maps, navigate to the [Maps section](#) in this document.




To view a facility map within a Workspace, click the map title and it will display in current workspace. This field is also capable of allowing the user to conduct a search for a saved map, is desired

4.6 LIVE VIDEO


By default, VI MonitorPlus displays a list of cameras in the left navigation tree, under the name of any IP Server that VI MonitorPlus connects to.

To view Live Video, select a camera from the left tree to display a camera view. Drag the camera name into an available workspace to see a live image. To add additional cameras, click and drag a new camera to the Workspace area.




Different views can be displayed automatically by using the Cameras Views icons in the Toolbar.

Expanding the Left tree displays all the cameras connected to a specific IP Server, and that server's name.




Dragging one of the cameras into a Workspace will change the Main Layout view to that camera (seen left).



While viewing the Live Video, applying a click-and-drag (left click and pull) across the screen results in a digital zoom.

The screen will be expanded to the zoomed area. (example: left)



Alternatively, Pan-Tilt-Zoom (PTZ) operations can be performed by using the mouse wheel to scroll in or out of the image being displayed.

This action will zoom in from the center of the live image.

With the digital zoom, navigation around an image is possible by grabbing the orange box in the Preview Window at the bottom left or by using the PTZ controls in the Left tree.





To zoom back out and see the entire image, left click, and drag right to left. The digital zoom only affects the VI MonitorPlus application in use. If another user is viewing the same camera on a different computer will not be affected. This does not affect recorded video made during the time of zoom control.

4.6.A Using Views


Views are organized representations of all cameras connected to the IP Server in customizable layouts, allowing to visualize multiple live video streams simultaneously.

Click on “Views” on the Left panel to expand the list of available views; to access any View, click on the corresponding name.




Expanding Views

To expand a single camera video from a View, double click directly on the desired camera frame within the View.




The camera feed will be displayed on top, full-size, covering all the Workspace area.




Returning to Views

To return to the View, right click on the video output and select “Return to View” from the pop-up menu.




Expanded individual views of cameras can also be invoked from a View by right-clicking on the camera's area and opening a pop-up menu.

Select “View in new Workspace” to create and open a new workspace with only the camera's current live video output.






Select “View in new Window” to open a new VI MonitorPlus window containing only the camera's live video.




Behavior with 360° /Fisheye cameras

When viewing 360°/Fisheye cameras from Views, double-clicking on an individual camera display will open a single quadrant view as in a single camera.




Double-clicking the quadrant again will switch back to Dewarp view.


To avoid this, right-click on the view and select “Return to View” from the pop-up menu.



Double-clicking on a 360°/Fisheye camera view header (the top bar with the camera name and IP address) will return to View as well.



If “Show Camera Header” is disabled from System Options, thus hiding the camera view header, use the Right-Click/Return to View option as explained above.




4.6.B Details Pane

The Details Pane provides additional information and options for a specific camera while in Live Video mode.

To access it, click on the Details Pane icon to open a new menu bar on the upper right side of the workspace window.



To close the Details Pane, click again on the same icon (inverted), now located next to the Details title.




While viewing a specific camera within a workspace in Live Video mode, the Details Pane is hidden by default.

Once opened, the Details Pane will display basic information about the selected camera, as well as its corresponding options and controls.

Depending on the type of camera and its features, the available options are:


- Details
- Pan-Tilt-Zoom (PTZ) controls
- Actions
- Auxiliary Functions




(1) DETAILS

This area displays the camera's specific information as it appears in the IP Server database.

Click on More Info or Less Info to toggle the Details view option ON or OFF.



Details OFF



Details ON


Camera Details Values

Manufacturer	Name of the manufacturing company for the displayed camera.
Model	Camera model as it appears in the IP Server database.
IP Address	IP Address of the camera.
Server	Name of the IP Server that the camera is associated with.
Camera ID	This Camera ID is unique only to the IP Server database. It can be used for troubleshooting.
Web Access	Web Access is a URL to access the camera's webpage. Clicking on this link will open a web browser window, where the user will be able to provide access credentials for the camera.

(2) PAN-TILT-ZOOM (PTZ)

This feature is available only when the Details Pane window is selected on a camera with PTZ functionality.

NOTE - Not all 360° Cameras come with PTZ functionality.











	This drop-down menu provides a list of pre-defined and custom camera viewing angles.
	PTZ Preset cycling configuration
	PTZ Prioritization lock
	Customization of Preset PTZ controls: Add a new preset or Delete a preset
	Remote controls for Zoom, Focus and Shutter capabilities, including angles and increase/decrease buttons.
	Adjusts the speed of panning and tilting within the Live Video, using the mouse when Digital PTZ is unchecked
	<p>By checking the Digital PTZ box, functionality of PTZ controls becomes limited only to the use of the mouse.</p> <p>This means that panning and tilting the Live Video feed is not functional until the box for Digital PTZ has been unchecked.</p>

(3) ACTIONS

The Actions feature includes a series of additional controls and options for the Live Video.


Some of these options are not available, depending on the type of camera selected.




	Display camera information on Live Video, including: Resolution, Codec, FPS and Timestamp
	Force Video Recording
	View recent Video History, opening a new window with recorded video streaming and the Timeline for advanced controls
	Capture Image Snapshot
Dewarping View Modes - The following options change the output from a 360° Camera:	
	Fisheye View: It forces the camera to use fisheye view. If Panomorph (Dewarping) is available for the camera, this will represent the dewarped “fisheye” view when activated.
	Quad View: It will display four individual feeds from a fisheye camera, arranged within a workspace as a single image.
	Panorama View: It enables an elongated view that spans across the top and bottom half of the workspace view.

(4) AUXILIARY FUNCTIONS

The Auxiliary Functions area provides extra features for the selected camera, where available.



	Auto Focus activates the camera’s autofocus capability
---	--


4.6.C Fisheye Cameras

The use of Fisheye Cameras and their features such as viewing Live and Recorded video, Pan-Tilt-Zoom (PTZ) controls and Camera Registration are all possible in VI MonitorPlus.

Fisheye Cameras appear on the Left Navigation Tree under their IP Server, identified by the following icons:




To use the Fisheye Cameras advanced view options, click on the corresponding Details Pane (see 4.5.A).




NOTE - Fisheye Cameras with 360° capability support advanced Dewarp View Modes.

(1) 360° CAMERA DEWARP VIEW MODES


The Details Pane for a Fisheye Camera with 360° capability shows the 360 Views options under Actions, enabling the Dewarp View Modes.



FISH EYE



QUAD VIEW




PANORAMA


NOTE - When switching between Dewarp Views on a Panasonic 360 camera, the *Aspect Ratio is maintained*, allowing the fisheye image to be fully displayed in the active layout.

(2) ZOOMING WITH MOUSEWHEEL


It is possible, with a Panasonic 360° camera, to zoom in and out on the live video feed by using the Mouse Wheel when in Fisheye or Quad mode, keeping the cursor within the desired view.



DEFAULT



ZOOM IN



ZOOM OUT

(3) AUTOSAVING LATEST VIEW



When using a Fisheye camera, VI MonitorPlus will save its latest selected view automatically.

This operation occurs on the Client's side whenever changes are made on the Workspace for each specific 360° Camera. view settings are stored physically in the local machine's registry.


This feature also saves the User's last Quad View and Panorama positionings for each quadrant.

When the camera is selected again from any module of VI MonitorPlus, its latest saved view configuration will be displayed by default.


4.6.D NVR Live Video

NVR cameras can be accessed from the left tree, whenever available.

When clicking on any NVR icon, the cameras associated to it will be shown on the Workspace.



To access Live video from a [supported NVR model](#), (see 4.9.G) select the camera from the NVR menu on the Left tree. Video will be displayed like other supported cameras. Camera Properties will be unavailable for NVR cameras setup.



4.6.E Vehicle Incident Detection feature

The Vehicle Incident Detection feature, also known as VID, allows users to track a moving object (such as a car, bus, or train) and register its trajectory, displaying Metadata with geometric shapes overlaying the Live Video.

NOTE - Video Incident Detection is supported only by Panasonic cameras .

Open Internet Explorer and log into the camera's setup URL or web interface.

This URL can be found on the Camera Properties page, listed as *Web Access*.


Ensure your camera is properly positioned to cover the desired view area.

VID supports horizontal lane drawing; align streets and pathways with the view for better results.



To setup a Basic Preset for the camera:

- From the Left Tree, click on the Setup tab (top).
- Select Image/Audio > Image/Position.
- In the Main Panel (right), click on Setup for Preset Position.



In the Position Preset window, click on the Preset No. drop down list and select an available option.

Ensure Preset ID and Auto Focus are both ON.

In the Preset ID (0-9,A-Z) field, create a valid name.

Click Set to create the Preset Position.

Position Preset window details:

- Preset No: [Dropdown]
- Position No: 5
- Preset ID: ☒ On ☐ Off
- Preset ID (0-9,A-Z): VID Position 2.1
- Auto focus: ☒ Auto ☐ Off
- Close button at the bottom.

Click Close (at the bottom).

To access Vehicle Incident Detection:

- From the Left Tree, click on the Setup tab (top).
- Select Alarm > Vehicle Incident Detection.

A Live Video feed image will be shown on the Main Panel (right).

It will show a horizontal red line (Camera Height) and a series of gridlines generated by the camera to be used when defining Lanes.

Main interface details:

- Left Tree: Setup tab selected, Alarm > Vehicle Incident Detection selected.
- Main Panel: Live video feed showing a street scene with a horizontal red line and gridlines.
- Configuration options below the video feed:
 - Camera height: 10.0m(33.5ft) [Dropdown] Auto
 - Traffic lane setup: Lane 1 [Dropdown] Clear All clear
 - *Please set the lane below the red line
 - Detection type: 1(Yellow) 2(Blue) 3(Green) 4(Pink)
 - Wrong-way vehicle: ☒ On ☐ Off
 - Stopped vehicle: ☒ On ☐ Off
 - Correct direction: UP [Dropdown] UP [Dropdown] UP [Dropdown] UP [Dropdown]
 - Detection time of Stopped Vehicle: 10s [Dropdown]
 - Night mode: Priority to monitoring [Dropdown]

To adjust the grid position, use the Camera Height drop-down list and select the desired height.

Camera height and Traffic lane setup controls:

- Camera height: 10.0m(33.5ft) [Dropdown] Auto
- Traffic lane setup: Lane 1 [Dropdown] Clear All clear

To setup a new lane, select Lane 1 from the Traffic lane setup drop-down list. Lanes are defined below the horizontal red line on the video.

Camera height and Traffic lane setup controls (Lane 1 selected):

- Camera height: 3.5m(11.5ft) [Dropdown] Auto
- Traffic lane setup: Lane 1 [Dropdown] Clear All clear

Using the mouse cursor, click and drag a line on top of the video to define the lane area.

Start by defining the vertical height and next the horizontal width.

Draw a straight line then select the opposite corner to complete the lane.

Click “Clear” to delete the current lane.

Click “All Clear” to delete ALL the lanes on the view.

Additional segments can be created by drawing connecting boxes (for example to cover a curved area).

NOTE - Up to 4 Lanes can be defined on a single view, each one with a distinctive color and specific options.


Set the Wrong-way vehicle radio button to On to view onscreen objects (tracking lines) when vehicles traveling in the wrong direction are detected.

You may also enable Stopped vehicle to trigger that event.


Define the Correct direction of the traffic by selecting UP or DOWN on each lane where it applies.

Once configured, any vehicle traveling the wrong direction will be identified by a blue square and a trailing green path line.

NOTE - VID setup takes 10 to 15 minutes to reflect the changes on the received images. Allow sufficient time for the camera to apply the configuration.



Detection type	1(Yellow)	2(Blue)	3(Green)	4(Pink)
Wrong-way vehicle	<input type="radio"/> On <input type="radio"/> Off	<input type="radio"/> On <input type="radio"/> Off	<input type="radio"/> On <input type="radio"/> Off	<input type="radio"/> On <input type="radio"/> Off
Stopped vehicle	<input type="radio"/> On <input type="radio"/> Off	<input type="radio"/> On <input type="radio"/> Off	<input type="radio"/> On <input type="radio"/> Off	<input type="radio"/> On <input type="radio"/> Off
Correct direction	UP	UP	UP	UP
Detection time of Stopped Vehicle	5s			
Night mode	Priority to monitoring			




Next, go to the camera's Live Video in VI MonitorPlus.


Access Camera Properties by right clicking on the camera in View or right clicking the camera node and selecting Properties.

Enable Capture VCA Events and Capture Graphics Objects by clicking the corresponding checkboxes from the General tab.

NOTE - If you are receiving overlay objects in your camera web page, but not on VI MonitorPlus, uncheck and re-check Capture VCA Events and Capture Graphics Objects.





Once in Live mode, expand the Camera Details Panel and select Show Graphic Object Overlay.



To view the On-screen objects, select the camera in the left tree to view it in Live mode. Any event that triggers the Wrong Direction alarm will be detected and shown instantly.

NOTE - Moving the PTZ camera in any direction will reset all VID camera configurations. Please utilize the PTZ Lock feature to prevent this from moving during VID operation.


To restore the VID feature, select the configured preset in the Camera Details Panel.




4.6.F Cycle Views feature

VI MonitorPlus comes with a feature to split multiple cameras outputs into self-cycling Views (*Pages*), displayed automatically after a specific time interval. For example, in a 24-cameras server environment, it is possible to configure a set of three 8-cameras views, each one organized as a single page that skips to the next one after 10 seconds, and so on until it goes back to the first one.

To activate the Cycle Views feature, right-click on the server name shown in the left-side panel, under “Servers”, then click on “View in Current Workspace”.




All the cameras in the server will be displayed in a new Workspace, generated automatically.




At the bottom of the Workspace, a status bar will show:

- Camera View options
- View size options
- Play/Pause button
- Number of visible cameras
- Recorded Video switch button.



Define the size of each view layout by opening the Camera View list at the bottom left of the Workspace and select the desired View.

NOTE - Always select a number that is less than the total of cameras displayed.




The first automatically generated View (Page) will be displayed, using the View layout previously selected from the Camera View list.



The status bar now displays the following:

- Camera View options
- View size options
- Play/Pause button
- Cameras, Page number and Next/Previous page buttons
- Cycle interval (time) options, Start button
- Recorded Video switch button.



Set the paging interval value (Cycle Every field) and click on Start to begin the automatic sequence.


You can also manually go to the next or previous page by clicking on the left/right arrow buttons.

4.6.G Embedded Analytics support for i-VMDCameras


VI MonitorPlus supports Embedded Analytics for Panasonic i-VMD (Video Motion Detection) cameras.

To ensure the feature is active, proceed as follow:


Right-click the camera on the left tree, and select “Properties”




In the Camera Setup window, “General” tab, locate the “Additional Options” box on the right side, and check both “Capture VCA Event” and “Capture Graphic Objects” boxes.




Click on “Save Now” (top right button).



Depending on the settings for the camera, the object detection will appear in the live video streaming, with color coded frames and motion lines.



To turn off the live object detection, open the Details Pane (upper right arrow) and click on the “Hide Graphic Objects Overlay” button.



The live streaming will now appear without the frames and lines.


Click on the “Show Graphic Objects Overlay” button (in the Details Pane) to reactivate the live detection.




4.7 RECORDED VIDEO

VI MonitorPlus comes with the ability to access Recorded Video directly from the Left Navigation tree. This feature is enabled by default. To enable this feature, follow the steps below:

On the Main menu (Top), select “System”, then “Options”.



In the System Options screen, select the “General Tab”; under the Application Control section, make sure the “Show video files folders” box is checked.



Close the System Options screen and exit VI MonitorPlus. To use the feature, run VI MonitorPlus again and test it.

4.7.A Playback

Recorded Video can be accessed and managed using the Playback bar, which is located at the bottom of the workspace screen for any camera that supports this feature.



To switch from Live to Recorded Video, click on the Blue Icon located at the bottom-right corner of the screen.




The Recorded Video bar will be activated showing the Calendar and Playback controls on the left side. In play mode, the left and right single arrows allow navigation of previous and next motion events on the timeline. In pause mode, the double arrows allow forward and backward navigation through each frame on the timeline. On the Timeline in the center, the marker can be used to slide through the video. Video Management controls are displayed on the right side.



To switch back to Live Video, click on the Return icon at the bottom-right corner of the screen.

In the Timeline, the Orange vertical bar (centered) indicates the current position in time of the video. It is also the starting point to begin playing it.

Red areas or spots represent motion detection, and Blue areas or spots represent motion video recording available for playback.



4.7.B Analytics


VI MonitorPlus comes with the ability to enable or disable the display of Recorded Video Analytics directly from the Timeline bar. This feature is available on cameras that support VCA (Video Content Analysis) events.

(1) ENABLING VIDEO ANALYTICS DISPLAY


To activate the Analytics Display feature, follow the steps below:

Open the Properties page for the camera:

- Right-click the selected camera from the Left Navigation Tree and select Properties.
- or:
- Open Main Menu > Administration > Cameras > Configure Properties and select the camera model from the Left Tree.





In the Camera Setup window, General tab, make sure the checkboxes for “Capture Graphics Objects” and “Capture VCA Events” are available and selected, under the “Additional Options” section.




(2) VISUALIZING ANALYTICS

From the Live Video interface, switch to Recorded Video to access the Timeline.



From the Timeline bar, click on the Analytics icon.




The green lines on the Timeline will indicate events captured during the Live video session and processed as Analytics.

4.7.C Bookmarks

VI MonitorPlus comes with a complete interface to create and manage Recorded Video Bookmarks, which can either point to a single frame within the video sequence or include specific time intervals (*start-end*). Bookmarks are used as a reference for further review or analysis.

(1) ADDING A BOOKMARK

In the Timeline, position the starting point of the bookmark aligning it with the Orange indicator.



Click on the Bookmarks icon, then select “Add Bookmark” on the menu.



In the Add Bookmark window, enter the End Time manually or using the Calendar (see below), and the Title and Description of the bookmark.

Click OK when ready.



All fields must be filled.

Warning: Disk space may be compromised if a large capacity of the server is used to secure bookmarks. (Based on the server size.)

A screenshot of the 'Add Bookmark' dialog box. It contains several fields: 'Start Time' (9/26/2018 7:06:00 AM), 'End Time' (9/26/2018 7:16:00 AM with a calendar icon), 'Cameras' (10.10.7.168 - Model: Panasonic...), 'Title' (7AM test), and 'Description' (Ten-minutes test). There are 'OK' and 'Cancel' buttons at the bottom.


When adding a new bookmark, use the Calendar clicking on the corresponding icon, and easily select the End Time from its interface.

Video files are scheduled to automatically delete using FIFO. Bookmarked videos will never be deleted unless done so manually.




When finished, a thick Yellow line will appear on the Timeline indicating the Bookmark interval.

Bookmarked videos will be visible from the timeline.



(2) VIEWING BOOKMARKS


Click on the Bookmarks icon, then select “View Bookmarks” on the menu.




The Bookmark Manager window will show the customizable list of available bookmarks, plus 4 option buttons: Play, Edit, Delete and Close.

Click on any column title to sort the list by its value (descending / ascending).


Adjust any column width by clicking and dragging the vertical separator between column titles to the left or the right.




To activate any of the options, select the desired bookmark from the list.




Click Play to launch the bookmarked video (close the Bookmark Manager to view it).



Click Edit to modify the parameters for the bookmark.




The Modify Bookmark option will allow to change the End Time, Title and/or Description.




Click Delete to remove the bookmark from the list (*confirmation needed*).

Once the bookmark is deleted, the yellow indicator will disappear from the timeline.

This operation cannot be undone.




Click Close to exit the Bookmark Manager and return to the Recorded Video feed.




4.7.D Video Clips

To create and export a recorded video clip from a specific time interval, click the Export Video Clip button, located to the right of the timeline bar.



The Export Video Clip window will open in the foreground. A Camera(s) list according to user's permissions will display in sorted alphanumeric order allowing multiple cameras to be selected.


NOTE - Currently selected camera(s) displayed in the main layout will be auto checked.



Specify the Start Time and End Time for the clip, using the corresponding drop-down lists for each value. The Start and End time can be specified to clip across midnight. Time will be limited to 24 hours. For example, Day 1- 1am to Day 2- 1 am. A displayed warning will appear if the clip duration exceeds 24 hours.

The selected interval will be automatically shown in the timeline within an orange frame.

NOTE - This frame can be adjusted by clicking and dragging it horizontally to manually modify the time interval.





Open the Export To: drop-down list to change the video file format.




When "AVI" or "MPEG" are selected, the application will display a set of Export Options:

- Show Timestamp: Embeds the timestamp in to the exported video.
- Include Watermark: Creates a watermark and embeds it into the video to prevent video tampering.
- Force Compatibility: Forces the video to be exported in MJPEG format.



If “EXE (Executable file)” is selected, the application will ask for a Password to protect the exported file. A self-executable file will be produced.


If “Arbitrator Cloud” is selected, the application will ask for the Arbitrator Cloud’s URL, its Username and Password.



“Save to Folder:” shows the default destination folder and filename for the clip.

Video clips will be exported to a single directory using a standard file path.


Click on the white icon to the right to open the File Explorer window for more options.




The File Explorer window allows *changing both the destination folder and the file name* for the exported clip.

The “Save as type” option will replicate the file type selected from the application’s interface by default.

Click “Save” to confirm or “Cancel” to return.



Click on “Select Region of Interest” to define a R.o.I. for the clip.




Mark the Region of Interest directly on the corresponding window and click “Select” to confirm.

Click “Select Entire Image” to expand the Region of Interest to the maximum allowable size.


The Region of Interest will be displayed back in the “Export Video Clip” window preview.

Click “Cancel” to return.




NOTE – Region of Interest should be disabled when multiple cameras are selected.

Click “Export” to start the file exporting process, or “Cancel” to exit.




Exported files should appear in the Downloads panel while in progress.

The file will start to be downloaded. Click “Cancel” to stop the process.



Once finished, the file will be ready to be played (“Open”)

Once finished, the file will be ready to be played (“Open”) or to be found on its destination folder (“Show in Folder”).



NOTE - Clipped video files are limited in size to be 1.5GB, while exporting. In some rare instances, the file size may be slightly smaller than 1.5GB.

4.7.E Playback support for NVR Cameras


Recorded video for NVR cameras listed in the left navigation tree is available through the recorded mode of VI MonitorPlus.

To access recorded video, click on the camera under the enrolled NVR server.


A new Playback Window will appear displaying the Playback bar along with the Calendar picker and the Export Clip icon.

The Timeline is also visible at the bottom of the window.

Before utilizing NVR Cameras in recorded mode, ensure your [NVR is properly enrolled](#).




Before utilizing NVR Cameras in recorded mode, ensure your [NVR is properly enrolled](#).




To locate recorded video, use the Calendar to select a time and date or use the Forward and Previous File Recording icons on the toolbar.


Selecting Previous Recording or Next Recording will jump the playback to the next recorded segment.



The Export Clip option allows the creation of an external AVI video clip after specifying the start-end time and its export path.



The Timeline can be used to navigate the NVR camera playback within a time interval.



NOTE - NVR Playback support is recommended on a physical client machine, instead of virtual computer environment.

4.7.F Video Clipping support for NVR Cameras


VI MonitorPlus features the option to Export Video clips from NVR Cameras' live streaming.

From the NVR Camera live video view, click on the "Switch to Recorded Video" button (bottom-right).




The Camera Playback view will open in a new window.


Click on the "Export Video Clip".



Select the Start Time, End Time, and file path for the clip, then click on "Export" to begin the operation.




The export clip sequence will begin. Once completed, the "Exporting" window will disappear, going back to the Camera Playback.



NOTE - The Video Clip files will be generated in AVI format.

4.7.G Panasonic Arbitrator Cloud Export

To export files to Panasonic Arbitrator Cloud, use the Export Video Clip menu to send the video clip. First, select the date and time you wish to create a clip. Next, select Arbitrator Cloud from the Export to drop down.



Export Video Clip

Start Time: 13 : 31 : 54

End Time: 13 : 39 : 54

Export To: Arbitrator Cloud

Arb. Cloud URL:

Username:

Password:

Preview Cancel

Enter the correct Arbitrator Cloud URL and authenticate with your Arbitrator Cloud username and password. Select Preview to generate the clip preview for verification. Once connected the Arbitrator Cloud server, you will be allowed to enter in case details along with classifications for the case. This video clip will be stored on your Arbitrator Cloud system for future review along with the details supplied for the case.

4.7.H Multiplex Video

While exporting a clip, there is an option to keep all video in the appropriate layout when making a clip. This is done by selecting Multiplex Video during the file export.

The output will display all involved layouts in a single AVI file, and all views will be shown on the playback. See example image below of AVI playback.



If Multiplex Video is not selected, then the output file will default to the previously selected options located above the Multiplex Video checkbox.

Each recording will be exported individually, until all have completed, before the video is compiled and ready to be presented in this view.

The maximum number of cameras in the viewable area is limited to 16 cameras at the time of publication.

The Save to Folder option can be selected to change the default destination directory for storage.

4.7.1 Region of Interest Motion Search (ROI)

Region of Interest Motion Search (ROI) allows the user to draw a box within previously recorded video view and to monitor changes within that specific area over a desired time frame. This feature enables the user to capture the moment that a change occurred within a visible region on the recorded video.


NOTE - The use of ROI Motion Search does not *require* a hardware-based GPU to conduct searches. When ROI Motion Search is not used with a hardware-based GPU, as outlined in the IP Server requirements, the search results will be performed in software-only mode. This can be very slow. It is highly recommended that a graphics processor, as listed in the Requirements for the hardware decoding (Hardware Decoding) is used for best performance output.

The use of ROI requires a 64-bit OS and VI MonitorPlus installation.

The ROI Motion Search feature compares frames within a recorded video to determine that enough pixilation change has occurred. When combined with the Region of Interest specified with the recorded video frame itself, the search conducted within the recorded video become much more glandular, yielding higher positive search results.

NOTE - It is recommended that ROI is used within a single workspace. Opening multiple workspaces to use with ROI will result in performance degradation and undesired results.


To get started with ROI Motion Search, follow the steps below:



Select a camera with recorded video where an event is thought to have occurred.
Next, select the Recorded Video icon, found in the bottom right-hand side of the screen (see left).
The recorded video timeline appears (see below)



On the right-hand side of the timeline the ROI Motion Search icon appears (see left).
Click on this icon, and the workspace refreshes with a new timespan bar.
In the image below, a Timespan bar appears.



The Timespan bar located between the Start Frame and the End Frame is the timespan in which a search is conducted. The Timespan Bar can be used for quick access to more recent events. To use it, click and drag the time bar to the point in time that the recent event may have occurred.


NOTE - The use of ROI with fisheye cameras has a visual playback limitation. Dewarping and Quad-View features are not processed by IP Server while recorded video is displayed on the screen within the ROI search. Video playback for fisheye cameras will appear in fisheye-view only. ROI video clips made from fisheye cameras will play back in fisheye view only.

NOTE - If it is necessary to conduct a search over a greater span of time, it is an option to use the two calendars above the timespan bar to specify exact start and end times across a period of days.

NOTE - The use of network-bandwidth conserving features, such as Panasonic Smart Coding, can negatively impact the ROI search results where bandwidth settings on the camera are maximized for network efficiency. It is recommended that an acceptable balance between these two features be tested to match the preferences of the administrator prior to production use.

At the time of publication, the ROI Motion Search feature is limited to searching previously recorded video that is accessible within VI MonitorPlus and only within a 30-day range. This limitation is due to the possibility that a search is conducted beyond the scope of available video recordings.


The Start Frame acts as a visual point of reference, used for quickly scrolling through the Timespan Bar. It displays the very first frame from the video recording for use by ROI Motion Search. The End Frame is a visual guide and visual point of reference for quickly scrolling through the Timespan Bar. It displays the very last frame from the video recording used for a ROI Motion Search.




After the selecting the desired start frame, click and drag across the image in an area on the recorded video.

This creates the Region of Interest for searching with the ROI Motion Search feature.

Click on Run Search.



During the search process, the Timespan bar will begin to populate potential hits- found within the frame reference. When the green shaded area extends beyond the Timespan bar, the likelihood that some motion has occurred within the Region of Interest.



The Motion Events section, found on the right-hand side of the screen, will begin populating with clippings of motion events- found within the specified Region of Interest.

To view one of the Motion Events, double-click on one of the visible images. A new pop-up window appears.

This window allows the user to view the specific motion event within a stand-alone player. The player is designed to be compatible by default with any of the required operating systems for IP Server.

Advanced Settings



The table below offers a description of the items that appear within Advanced Settings.

Threshold	Threshold represents the minimum deviation of a value within a pixel, for that pixel to be considered “changed” within the recorded video.
Gain	This adjusts the motion detector’s sensitivity to change.
Window	Represents the number of overlapped video frames that are used to determine if a pixel has changed.
Skip Frames	Motion analysis is done only on key frames
Min Quiet Time	The number of seconds that must pass where no motion has been detected, before a new motion event is created
Event Threshold	The percentage of pixels that must change within the Region of Interest before a new motion is created

4.8 TAB: MODULES

4.8.A Access Control

(1) ACCESS VIEW

(1A) ACCESS VIEW CONFIGURATION


Access View is the user facing interface to Access Control servers that can be implemented into IP Server and VI MonitorPlus. The newly arranged feature set was designed to maximize ease of use and to provide the user with the necessary details of each Access Control event.

This screen will only become relevant when IP Server is integrated with an Access Control server. Otherwise, this screen offers no additional / functional features for the User.

(1B) ACCESS VIEW CONTROLS

Door Information

Door information allows the user to select a specific door, and see which camera is assigned to that door. The default is to show All Doors, which limits the ability to display all doors at the same time in the Live View window below. This is intended to be used as quick access to a specific door where there may be an alarm event that needs to be rectified with human interaction.



LAST ENTRY


Last Entry displays the information pertinent to an Access Control device being accessed. Depending on the depth of Administrative Management used and incorporated into a person's account, the features available here are the display of a photo of the individual that attempted to access the secured area



Seen left, are the person's name, the name of the door that was being accessed (for use with Door Information, above), and the Time of the last attempted/successful/failed entry.

LAST ALARM


Last Alarm provides the user with the type of alarm that triggered the door, the event that triggered an alarm and provides the time that the alarm was triggered.



This is a live feed provided to the user, in the event there is a need for manual interaction, to easily elect to choose the door from Door Information (above) and then select one of the following Actions (see *Actions* image, below).


ACTIONS

Actions are a list of functional items available to the user for controlling a single door, if it is being viewed, or ALL DOORS if All Doors is selected in the Door Information area, seen above. Use caution with any of these tools while viewing ALL DOORS in the Door Information area, above. If access control permissions have not been properly configured, undesired changes can result in some adverse effects on the IP Server.



Admit	Most commonly used with a live guard and a single door with a camera or a camera with a microphone. The Admit button provides manual authorization for entry. Because it is a manual authorization, the action is tracked within the system logs for IP Server
Schedule	<p>This function, when selected, forces the door being viewed* into one of two states. The first state is to force the door being viewed back onto a previously programmed schedule if one is available. If there is no schedule available for the door, then it will force the door into the default setting on the controller card. Usually, the default on controller cards is for Card swipe/pin access depending on the reader card.</p> <p><i>*Important note: This will take any visible door (or ALL doors, if ALL Doors are being viewed) out of Lockdown, scheduled mode if security settings are not properly configured on the access control server.</i></p>
Unlock	<p>This feature will unlock a door being viewed, or all doors being viewed if *All Doors is selected in the drop-down menu within Door Information.</p> <p><i>* Important note: This will take any visible door (or ALL doors if ALL Doors are being viewed) out of Locked or scheduled mode if security settings are not properly configured on the access control server.</i></p>
Lock	This button will lock the door being viewed.
Lockdown	<p>Selecting this button will force all doors to lock. Pressing this button will lock the door being viewed, or *ALL DOORS if viewing All Doors in the drop-down menu above.</p> <p><i>* Important note: This will take any visible door (or ALL doors, if ALL Doors are being viewed) out of Lockdown, scheduled mode if security settings are not properly configured on the access control server.</i></p>

LIVE VIEW




Live View displays a live stream of any camera that might be associated to a specific door, and then chosen from the Door Information drop-down menu.

The ability to pause the live stream is available, and access to the Recent Recordings is also available for quick review of any potential or unexpected security violations.

EVENT HISTORY

Event History provides limited information that is pertinent to the Access View Controls, and the doors assigned to the Access Control server. Information made available are as follows:

- Event History					
	Type ▾	User Name ▾	Details ▾	Door / Device ▾	Time Entered ▾
1	Entry		Monitor Point Secure	mr52 I5	8/07/2017 8:33:29 AM
2	Entry		Door is closed	Front Door	8/07/2017 8:33:26 AM
3	Entry		Monitor Point Secure	mr52 I5	8/07/2017 8:02:02 AM
4	Entry		Door is closed	Front Door	8/07/2017 8:02:01 AM
5	Entry		Door is closed	Front Door	8/04/2017 3:21:13 PM
6	Entry	James Adler	Access Granted	Front Door	8/04/2017 3:21:13 PM
7	Entry		Door is closed	Front Door	8/04/2017 3:16:25 PM
8	Entry	James Adler	Access Granted	Front Door	8/04/2017 3:16:25 PM
9	Entry		Door is closed	Front Door	8/07/2017 8:35:18 AM



Type: This list denotes whether the type of access was an entry or exit, if a second card reader is implemented inside of the secured area.

User Name
Sheridan Admire
Sheridan Admire
Sheridan Admire
James Adler
James Adler

User Name: This is the name of the person that is associated with the access control card/pin number/voice recognition device that has been given or denied access to the secured area.

Details
Access denied - this card is n
Access denied - this card is n
Access denied - this card is n
Door is closed
Door is closed
Door is closed
Access Granted
Door is closed
Access Granted

Details: This provides a running list of items that of more specific events that may have occurred. The scope of this detail information provides a quick view of helpful information that affords the user to discern if an actionable task needs to be performed, or if some sort of maintenance needs to be done. In general, it is a running log of devices, controls, users, and times of events.

Door / Device
Front Door
Front Door
Front Door
Front Door
Front Door
Front Door
Front Door
Front Door
Front Door


Door/Device: A list of the specific device where an event has occurred.

Time Entered
8/07/2017 10:49:32 AM
8/07/2017 10:49:28 AM
8/07/2017 10:49:03 AM
8/07/2017 8:33:26 AM
8/07/2017 8:02:01 AM
8/04/2017 3:21:13 PM
8/04/2017 3:21:13 PM
8/04/2017 3:16:25 PM
8/04/2017 3:16:25 PM


Time Entered: Date and time of recorded event.

(2) LANE VIEWER

Designed to work with MonitorCast, selecting Lane viewer from the Modules Tab opens a window that displays three doors. The purpose of lane viewer is to allow a person (typically security personnel) to monitor for issues that might arise with a specific door or camera. These settings can be modified, in the [Administration section for Lane Viewer](#).



By default, when Lane Viewer is opened, the appearance of three doors/cameras appears.




The first step for configuring Lane Viewer, after it is opened, is to assign a door to one of the views.

Do this by selecting the drop-down menu at the top of the lane viewer display.

After the doors have been assigned to each desired Lane Viewer view window, the configuration is complete.

Each time an individual uses an access badge, or key code for entry, the information that has been associated to that person within the MonitorCast database appears.



When pictures are associated with personnel at the site using MonitorCast, the image of that person is displayed on the screen when the access control card/code is used.

Where no image is associated, a default image stating, "No Image" appears.

4.9 TAB: SYSTEM

The System tab provide administrative functions that will have an effect within VI MonitorPlus. These administrative controls and function do not necessarily have a direct impact on the IP Server itself, and are centered around visual enhancements and User-level personalization for the client interface.

4.9.A Licensing

Licensing, within this section is directly related to single-use instances of H.265 licensing. H.265 licensing is done entirely client-side, on a per-installation basis. Panasonic wishes to respect the terms of the license and has implemented this minor adjustment to the licensing feature to comply with the H.265 licensing agreement.


(1) H.265 ON-LINE REGISTRATION

The registration process does not require the collection of any data that will identify a person. Panasonic does not collect a name, address, phone number, email address or other any other personal information.

NOTE - H.265 Cameras that are not registered will record video, however the video playback of H.265 cameras will not permit the user to view the recording without registration. Registration is required on each computer that VI MonitorPlus is installed and used with H.265 cameras.


To register any qualified Panasonic Camera for H.265 Camera Licensing, navigate to System > Licensing > H.265.

(1A) AUTOMATED REGISTRATION



If the computer registering H.265 has internet access, the automated method of registering is 2 steps:

Step 1: Select the Register Now button.



A new pop-up window appears, confirming that registration of H.265 is complete.

Step 2: Click OK to exit the registration process.

(1B) MANUAL REGISTRATION

For computers using VI MonitorPlus on a closed-network environment, without internet access, the process for registering H.265 was made to be as simple as possible. This process can be done on a cell phone, or by calling Technical Support.

If no Internet Connection is available, use the URL listed below and receive the Activation Code.

<http://www.video-insight.com/h265>

Hardware Code

Activation Code

Step 1: Copy the URL for H.265 registration.

Step 2: Copy the hardware code provided.

Step 3: On a device that does have access to the internet, enter the URL and go to the page for registration.

Panasonic

HOME INDUSTRY APPLICATION PRODUCT SOLUTIONS

Home > H.265

H.265 Activation

Phone: 713-621-9779 | Fax: 713-621-7281
Hours: 9:00 AM - 6:00 PM CST, Monday - Friday

Hardware Code*

Once the webpage loads, continue with these steps:

Step 4: Enter the hardware code for the computer that will use H.265 video playback within VI MonitorPlus

Step 5: Select Submit

Panasonic

HOME INDUSTRY APPLICATION PRODUCT SOLUTIONS

Home > H.265

H.265 Activation

Phone: 713-621-9779 | Fax: 713-621-7281
Hours: 9:00 AM - 6:00 PM CST, Monday - Friday

Registration Code: RAWUPAXTKMA0DW9V

The next page appears with the registration code.

Copy this code and take it to the computer without internet access.

If no Internet Connection is available, use the URL listed below and receive the Activation Code.

<http://www.video-insight.com/h265>

Hardware Code

Activation Code

Step 6: Enter the registration code into the Activation Code area.

Step 7: Click Enter to complete the registration process.

H.265 is now registered. Video recorded on H.265 cameras will playback without any issues.


4.9.B Event Viewer Details

Event Type	Description
Access Control Manager	
AccessAlarm	General notification that access has occurred or access has been attempted.
AccessEntry	General notification that an entryway was opened or closed
DoorAlarmed	Denotes that a door alarm was triggered for the time and date specified. Please verify that the door is functioning properly.
DoorLockStatus	Will signify if a door is locked or unlocked
DoorState	Status of a door - on/off/connected/not connected
IP Server Event Messages	
CameraDown	IP Server is reporting that it does not have access to the camera specified. Please check username, password and network connectivity issues.
CameraMotion	Notification of a motion event. Meaning, motion occurred within the field of view on the camera that has been specified.
CameraRestored	IP Server reporting that it can now connect to the previously downed camera.
ClientMessage	A message was sent from one user to another user.
LiveWindow	Live window was activated by a user, or rule.
IP Server Rules Manager output	
AlarmWindow	This will appear when there is a rule setup to trigger a pop-up window for access control.
ExecuteProgram	Within Rules Manager, if the option to execute an additional program outside of IP server is requested, this will appear within the logs.
InstantReplay	This represents a call by a logged in user to perform an instant replay task.
LPRAlarm	This item appears with the use and activation of LPR services.
MessageAlert	This indicates that a message alert pop-up was triggered and displayed.
SwitchToCamera	During the Tour feature, this indicates changing views between cameras.
SwitchToServer	This indicates that that specific server was selected from the main menu.
SwitchToLayout	This indicates a change in the number of visible cameras.
SwitchToAudio	This indicates the activation of Audio with cameras capable of capturing audio.
License Plate Recognition (LPR) related messages	
LPREvent	This denotes any event that may have occurred with the use of LPR software and cameras. If you are not using LPR functionality, then this message can be disregarded.
Video WallPlus	
ChangeMatrix	This indicates a change in the layout of the monitor views, or matrix.
DBDown	SQL Query failure. Most commonly a temporary SQL connection issue. Please verify that the SQL server is not experiencing any issues.
DBRestored	SQL query connection successful. Seen at IP Server startup as well as after a failed query has been triggered.

4.9.C System Log

System log provides data useful to the administrator searching for specific events.

In this log, the Admin will find the option to select a specific server's logs (if multiple servers are connected to VI MonitorPlus), the type of log, the ability to sort by date, the number of rows to display in the log, the ability to search for a specific keyword, and the ability to download the sorted data once it is found.



Time	Message	Source
10/08/2017 1:19:16 PM	Administrator The server properties were updated 1:19 PM - 8/8/2017	CommandChannel.UpdateServer
08/08/2017 10:23:35 AM	No Security changed information of user Administrator (ID:1) 10:23 AM - 8/8/2017	CommandChannel.UserUpdate
08/08/2017 10:23:35 AM	AdministratorThe User information was updated 10:23 AM - 8/8/2017	CommandChannel.UserUpdate
08/08/2017 10:22:25 AM	No Security granted user user permission to map mc map (ID:2103911954) 10:22 AM - 8/8/2017	CommandChannel.UserUpdate
08/08/2017 10:22:25 AM	No Security granted user user live, playback permission for camera 10.231.2.252 - Advitia - Model: A-34W (ID:89640784) 10:22 AM - 8/8/2017	CommandChannel.UserUpdate
08/08/2017 10:22:25 AM	No Security granted user user live, playback permission for camera 10.231.2.129 - Advitia - Model: A-47 (ID:1791121400) 10:22 AM - 8/8/2017	CommandChannel.UserUpdate
08/08/2017 10:22:25 AM	No Security created a user user (ID:6189675147801937920) 10:22 AM - 8/8/2017	CommandChannel.UserUpdate
08/08/2017 10:22:25 AM	AdministratorThe User information was updated 10:22 AM - 8/8/2017	CommandChannel.UserUpdate
08/08/2017 9:51:26 AM	Video Server started at 9:51 AM - 8/8/2017	Initialization
08/08/2017 9:29:33 AM	Video Server was shut down at 9:29 AM - 8/8/2017	Board Close
08/08/2017 9:20:47 AM	Video Server started at 9:20 AM - 8/8/2017	Initialization
08/08/2017 8:38:03 AM	Video Server was shut down at 8:38 AM - 8/8/2017	Board Close

4.9.D Server Statistics

Server Statistics displays the status of the IP Server Enterprise system.

Overview	Provides a general look at what VI MonitorPlus is connected to. The Overview Tab will display a column for Active Servers and a separate column for Inactive Servers. Within each of these two columns, the total number of serves and cameras will be displayed. This is most useful for Administrators of large, multi-server installations. In addition to the Active and Inactive columns described above, the lower chart provides Server Name, Status, IP Server Version, Server IP Address, Serial Number, Maximum Number of Cameras attached to the server, the number of available cameras, the number of cameras being used, and the bundled licenses associated with the cameras.
Server Status	Provides the Server Name, Status, the processor usage on that server, the total amount of memory available, total amount of memory for the server itself, and the OS Bit Type. Status will display "Offline" or "Online" to indicate the status of a server.
Camera Status	Provides the Camera Name, IP Address, Server Name, Last Image Received, Last Image Written, Resolution Frames , Frame Size, Bandwidth, Format Camera MD (Modified YES/NO), Manufacturer, Model, and Web Access (opens a new browser session).
Storage	Allows the Administrator to select a specific server (where multiple servers are connected) and view the amount of storage being used by each functioning camera. The chart displays Camera Name, number of days of recorded video, the total amount of space used by the camera and the specific folder where data is being written to.
Availability	Provides the Administrator with the Server Name, the percentage of time that the server has been active since installation and activation, the length of time the server has been up, the amount of time the server has been down and the number of failures the server has encountered during the time it has been running.
Online Users	Provides the Administrator with a quick view of the system users that are logged in to any of the attached IP Servers. The chart provides the User Name, the servers that the user is logged in to, the last task that the user performed, and any available actions that the Administrator might be able to make on that user, if available.
Motion Events	Allows the Administrator to select a specific server which provides a list of available cameras on the chart. The information for each camera listed will include the Camera Name, Camera ID, IP Address, Manufacturer and Model. Motion Events information (if exists) is viewable and accessible to the user by double clicking a camera listed on the chart which will then display the number of Motion Events along with the specific dates and times at which they occurred.
Edge Storage	Provides the Administrator with a chart that displays the Camera Name, Start Time (for Edge Recording), End Time (for same Edge Recording) the status of the recorded video and the Percentage Complete of total download of the recorded Edge Video in the event of an unexpected network failure.


4.9.E Options

The Options section provides changes to the way that VI MonitorPlus looks, feels, and operates. The changes made here are more for the general functionality of VI MonitorPlus itself, and not IP Server. For IP Server functionality, please refer to Administration > Servers > Setup and Configuration

(1) GENERAL

This tab gives the user access to various Application Controls, how VI MonitorPlus displays images, how VI MonitorPlus displays PTZ controls, and provides access to licensing the user's computer for H.265 camera use, as per the terms and conditions of the [End User License Agreement](#).

(1A) APPLICATION CONTROLS




Exit Confirmation Selecting this checkbox will force a confirmation window to appear when exiting the menu. During the installation process, it is checked by default.

Show Video Folders This option is incorporated to replicate the legacy Monitor Station video access folders. When checked, it will display a series of folders under each camera assigned to a server to provide the easiest access to recorded video possible.

Block Warning Messages This option allows the Administrator to prevent the occasional pop-up warning boxes that may occur during advanced modification of the IP Server settings. This check box is not checked by default.

(1B) MAIN VIEW LAYOUT



In the center of the screen is an area called Main Window.
The three options checked by default:

- **Show Camera Header**
- **Show Server Name**
- **Show Camera name**


If Show Camera Header is not selected, this feature will not work. If you must select this button, then VI MonitorPlus must be closed and restarted after steps have been completed.

Use DirectX display

Forces the incorporation of the use of DirectX for control of certain video controller within the display for cameras that require DirectX.

Selecting Use DirectX will force VI MonitorPlus to manipulate cameras using a legacy DirectX controller. Please see Microsoft's DirectX support page for more information regarding DirectX and its requirements:
<https://www.microsoft.com/en-us/download/details.aspx?id=35>

Default Size of Camera Image: Default Size of Camera Image modifies the appearance of camera image in each window.



Maintain Aspect Ratio: This camera view setting keeps a proportional relationship between an image's width and height.

Stretch: This setting will stretch the image to fit the viewing window.

Actual Size: This setting will display the camera image in its actual size.

(1C) ON SCREEN CONTROLS



On Screen Controls modifies the appearance of PTZ controls and how they are displayed within VI MonitorPlus.

On Screen PTZ: When selected, this feature enables PTZ controls while hovering over a PTZ camera.


Use Direct X opens a pop-up window that allows the visual use of a PTZ controller with PTZ camera functionality. The visual effect on the screen will appear as Arrows on the edges of the Live View screen, while viewing video on a PTZ camera.

Use PTZ zoom window when available: When this is not selected, there will be no visual controls seen along the edges of the screen. PTZ cameras will need to be moved by use of joystick, or by manipulating the camera with the use of the PTZ controller tools on the left side of the Live View Screen.

Digital Zoom Window: Allow the use of the camera's digital zoom feature, if available. Unchecking this box will disable digital zoom on cameras that may have the option available. This box is checked by default.



(1D) SNAPSHOT OPTIONS



Show camera name when taking a Snapshot: Forces the VI MonitorPlus screen to display a camera name when taking a Snapshot. The default value is selected.

Show date when taking a Snapshot: Displays the date and time when taking a snapshot. The default value is selected.

(2) CONNECTIONS

The Connections screen shows a list of all the servers currently added and allows the administrator, or user, to add or remove servers. The user can change the order of appearance for each of the IP Servers listed (above a single server), and to modify the properties of the server. The user can also map an exported profile, as directed by the administrator.

The user and or administrator can specify the location of a previously created Server Profile.

(2A) SPECIFY EACH SERVER

Is the interface where the Administrator or User will add, remove, and view the properties of the server.

Click Add New to add a new server.


In the new window, enter the *IP Address* for IP Server.

If necessary, change the Port number to reflect the Command Port of the IP Server (Default is 4011).

Click on Test.

If the server connects successfully, a confirmation window will appear. Otherwise, verify the IP Address and the Port number.

NOTE – Server's IP and Port must be set by the user to successfully add a server. Using the *Set to Default* buttons resets the profile information for the selected server to default values



To Remove a server from the display, select the undesired server, and then click on Remove.

(2B) USE SERVER PROFILE

A server profile can be used to share between many installations of VI MonitorPlus where manually entering multiple server connections would prove to be time consuming.

To *Export Server Data*, the user must select a server and click on Export Profile, which will pop up the Export Server Data window.


Here, a file name must be set. Make sure to choose a file name that is easy to remember and still unique to the system.

Any changes made to VI MonitorPlus will require an updated export of recent changes to successfully work across multiple machines. Placing the exported data on a NAS or SAS network share will make the ease of access to these features the easiest for network connected computers.

(2C) DIRECT CAMERA CONNECTION

In some instances, a direct connection to the cameras from a remote VI MonitorPlus on the local Network might be preferable.

Direct Live Video Streaming Support (Multicast) allows to select the cameras to be enabled. It requires a registry key modification ON the specific machine that will be using VI MonitorPlus. It also requires that the camera itself has built-in Multicast capability. (The configuration is in System → Options → Connections).



There are two locations that can alternately be modified within the System Registry.

NOTE - The following registry keys should be modified prior to launching VI MonitorPlus.

For Windows x64 systems, the string value is to be added under this key:

HKLM\SOFTWARE\Wow6432Node\Video Insight\Monitor Station

For Windows x86 systems, the string value is to be added under this key:

HKLM\SOFTWARE\Video Insight\Monitor Station

The new string value is called DirectLiveVideoSupport and the following values can be added depending on the requirements:

- 0 value = Disable, no UI options will appear
- 1 value = Multicast cameras only, list will appear in the UI functions. Only those selected clients will engage directly with the camera
- 2 value = Enable for All cameras


(3) TOOLS



The Tools tab allows some various changes such as XML and registry storage options, facility map alarms settings, and Guard Tours setting.

(3A) OPTIONS STORAGE(FOR OPTION CONFIGURATION

This feature allows the IP Server administrator to customize VI MonitorPlus options and export the modifications that have



been made on one machine and export them to another machine for ease of administration.

The ability to push the settings through GPO (Group Policy Objects) is possible after making all desired changes to the VI MonitorPlus interface, and then exporting the settings to a location accessible by Microsoft GPO within Active Directory. This is considered an advanced feature and is not recommended without proper training in Microsoft Active Directory and GPOs.

(3B) FACILITY MAP ALARM


Open Facility Map (Default: Checked)	This option, when the use of facility maps is in place and corresponding cameras and/or access control devices is used in conjunction with a facility map, will create a pop-up on the facility map displaying the live view of the camera on top of the map when triggered.
Launch Live Window (Default: Checked)	When an alarm is triggered on a facility map, a live window will be displayed with a video image of the area where the alarm has been triggered.
Play Sound (Default: Not Checked)	The administrator can choose to use a .wav file to be played each time a facility map alarm has been triggered. The file can be placed on the machine, locally, or on a NAS/SAS storage device.

(4) LIVE DISPLAY



The Live Display screen provides settings for the visual appearance of the VI MonitorPlus application windows, display names for facility maps, utilize Rules Manager actions, provides access for controlling Layout Tour cycle times.

(4A) LIVE WINDOW




Block Live Window Pop-ups Selecting this option prevents optionally program rules manager tasks, and / or images sent from other users from being displayed during a critical point in time. This feature can negate other desired settings, so use it with caution.	
Live Window Always on top (Default: ON)	In the event a user selects to right-click on a camera and view a single camera display of a specific image, this prevents the live image from being covered by the rest of the VI MonitorPlus application.
Red Outline on Live Window	Selecting this option results in the appearance of a red outline around all motion-sensitive cameras where the server or the camera is reporting motion within the designated video display.
Show Camera Associations (Default: ON)	This feature is a legacy control which, at this point, will not have any effect on any screen. It will be removed in future releases.
Pause main display when live window launches	Prevents the streaming of video at the launch of VI MonitorPlus. It is useful to have this box checked when calling Technical Support as it prevents a spike in network saturation while logged in remotely to the IP Server.
Flash Red on Motion	Selecting this option results in the camera icons flash with a red border when motion is detected by the camera and/or server (dependent upon configuration). This is to enhance the ability to act quickly in camera locations that would otherwise not have much motion and to reduce potential of oversight if not enabled.
Force Record Option	Allows a user or administrator to override “motion only” and other settings and record video as it is being displayed within that moment. it will continue to record video on a selected camera until it has otherwise been turned off.
Allow user to lock down PTZ control:	Enables the hierarchical control of any PTZ camera associated with the IP Server. By enabling this option, an administrator can grant control of any camera to any person. If a subsequent person attempts to take control of the camera during an administrative viewing and use of the PTZ controls, that user will be denied the ability to change camera settings. The default time limit on PTZ camera control is 5 minutes without movement by the higher ranked user. Prioritization of PTZ controls is explained here: PTZ Prioritization

(4B) RULES MANAGER ACTIONS

Rules Manager default values are all unchecked.

These are the available options:

- Block Rules from popping up messages / instructions
- Block rules from switching main layout
- Block rules from launching instant replay window



NOTE - These rules, when activated, can negate the purpose of alerts and notifications set by the administrator.

(4C) FORCE RECORD VIEW




Force Record View Allows user to force record all cameras on the present layout.

Force Record View Button is not available when using the server node for all cameras and does not support NVR force recording.

Force record will be disabled when the user closes the workspace manually or navigates away from the existing view.

- Red means button enabled; white means button disabled. It will show up as disabled until one or more cameras are pulled into the view.
- When force record all button is selected, all cameras currently in the view will be recorded.
- All recorded video will be playable via timeline or left tree.

NOTE- Force Record View CANNOT be used with NVR cameras.



Force Record View uses the cameras list in View to determine which cameras to turn recording on for. It will allow all audio and video to be captured with layout.

Double clicking inside an existing workspace with multiple cameras will not update the record camera selections.



(4D) FACILITY MAP

This feature enables the visible server name for each facility map that has been created.

(4E) OTHER

Here, the user can opt to include a server name for all Layouts by selecting “Include server name for all Layouts.”

Additionally, the Camera Tour Interval can be modified to suit the needs of the person viewing the camera tour.


The user can also change the Cycle Layouts interval. Default value for these settings is 5 seconds.

(5) AUDIO

This screen allows user to decide if it is desired for audio to play with motion notifications, rules, or LPR alarms.

The options provided here are for Motion Notifications and Rules and Alarms. Each section allows for the option of No sound, Default system beep, and the selection of a custom audio file.

(5A) MOTION NOTIFICATION




This section applies specifically to Camera Motion Settings.

If enabled, and IP Server or camera determines that there is motion occurring, causing a sound to play.

The option to choose a custom file is also available.

Using this feature requires that the computer have some sort of audio processing, and audio playback capability, that the audio playback capability is turned on, and that the user understands what the sound being played means in relation to the Motion Settings. in the computer's directory. The accepted file playback type is .WAV. No other file type has been tested.

(5B) RULES AND ALARMS



This section applies specifically to Rule triggers and for customers that use LPR (License Plate Recognition) with VI MonitorPlus.

If a Rule has been created to produce sound under specific instances, or if LPR is triggered, a default sound will play.


The option to choose a custom file is available, if desired.

Using this feature requires a computer with audio processing and playback capabilities; the audio playback capability is turned on, and the user understands what the sound being played means in relation to the Motion Settings.

(6) STARTUP

(6A) WORKSPACE CONFIGURATION

Workspace configuration allows the user to set some visual defaults for viewing live and recorded video.




Startup with video paused	In some low-bandwidth environments, it may be desired to start VI MonitorPlus with video paused. This can allow the user or the administrator to quickly access various features and controls without waiting for video feeds to begin displaying in the main workspace.
Start in full screen mode	Selecting this feature turns on Full screen mode at startup.
Auto upgrade (Default: ON)	When selected, this feature will compare the version of IP Server to the version of VI MonitorPlus that is being used to log into IP Server.
Startup View	When this checkbox is selected, the ability to select a previously created view for startup display is available. If there have been no previously created Views, this feature will not function properly.

NOTE - It is HIGHLY RECOMMENDED that all versions of VI MonitorPlus and IP Server match, to reduce the possibility of IP Server database corruption.


When there is a mismatch between IP Server and VI MonitorPlus versions, a pop-up window will appear, encouraging the user to upgrade accordingly.

(6B) NAVIGATION PANEL



Hide Left Navigation panel on Startup	In some cases, it may be desired to hide the left navigation menu from the user. Selecting this feature turns off the ability to view the left navigation menu. NOTE - If "Hide left navigation panel on startup" has been selected, this feature may override that setting.
Start with expanded servers	Selecting this feature will expand each of the servers that appear in the left column, to display all associated cameras.
Load Navigation panel data in stages	When enabled, this setting loads servers in the left navigation panel before cameras, views, and maps and can improve system performance.
Use Cached data to improve load times	Selecting this feature will retrieve cameras, views, and maps from the last login session cache data to improve loading time on the navigation panel. This setting will also capture the latest data and update the cache for future use.
Start with expanded server groups	If the administrator has created Server Groups, the ability to view them at startup is made available here. If there are no previously created Server Groups on any of the servers, selecting this check box will have no effect.


Login Options



The screenshot shows a dark-themed dialog box titled "Login Options". It contains two checkboxes: "Enable auto login" and "Verify Active Directory Login". Below these are two input fields labeled "User" and "Password".

NOTE - Enabling Auto login is a security risk and should not be enabled without fully understanding the implications and potential results of that action.

Tools Launch on Startup




The screenshot shows a dark-themed dialog box titled "Tools Launch on Startup". It contains three checkboxes: "Launch Lane Viewer on startup", "Launch Facility Map on startup", and "Show Event Viewer on startup". There is also an empty input field to the right of the "Show Event Viewer on startup" checkbox.

- Launch Facility Map on startup allows the user to select a previously configured facility map, and force it to be displayed when VI MonitorPlus is started, after logging in.
- Launch Lane Viewer on startup forces any previously configured Lane Viewer view to be displayed after logging in to VI MonitorPlus.
- Show Event Viewer on startup forces a separate window displaying the results of any previously configured Access Control configuration that has been previously configured.

(7) PERFORMANCE

This option allows users to alter the performance of their machines by changing a few settings. Additionally, it gives the Administrator the ability to change the capability for de-warping, on servers using 360 cameras, or cameras that have images that require the use of de-warping.

These options give users the possibility of increasing the performance of their machines by changing a few settings:



The screenshot shows a dark-themed window titled "Client Performance". It contains a dropdown menu for "Machine Performance" set to "Workstation", a "Video Smoothing" checkbox, and a section for "Reduce display frame rate when there is no motion" with three radio button options: "Always", "Views with more than 2 cameras", and "Never". The "Never" option is selected. At the bottom, it says "Hardware decoding not supported".

Reducing frame rate when there is no motion and down-sampling high resolution images (which can be done at different grades) are the options to be changed.

(7A) CLIENT PERFORMANCE

These settings directly affect the client-side VI MonitorPlus plus. They do not have any effect on IP server unless the client is being used on the IP Server itself. Selecting the desired Machine Performance will affect the CPU usage.

Video Smoothing is expensive for processors and should only be used on machines with significant computing resources.

Reduce frame rate capture can be useful on computers with lower end video cards. The default setting is Never. Selecting Always will produce a “choppy” view of the video being captured but does not have any effect on the video recording itself. This is used to minimize resources and bandwidth consumption on older machines and/or over-utilized networks.


Enable hardware decoding: This feature will enable VI MonitorPlus to use hardware decoding. This will have a positive performance effect on H.264 and H.265 video codecs. If there is no Hardware Decoder the checkbox will not appear.

(7B) DEWARP PERFORMANCE

This feature impacts the IP Server performance when combined with 360° and 180° cameras with dewarping capabilities.

NOTE - If the IP server does not utilize any cameras with dewarped images, this setting will have no effect.

If cameras with dewarping features are available, the user can determine if higher framerates for viewing a steadier playback of live videos are necessary, or if more processing power with a reduction in fluid playback is desired.



4.10 TAB: ADMINISTRATION

The items found under the administration tab will directly affect the IP Server itself. The controls used here will make changes on the IP Server itself, and will be a functional part of how IP Server is utilized within the organization.

4.10.A Servers Setup


NOTE - All items under this tab will result in the modification of the IP Server configuration.

(1) SETUP AND CONFIGURATION

The only exception to this is adding a server to VI MonitorPlus. Without adding an IP Server to VI MonitorPlus, it will not be possible to edit or modify settings with the tools made available within VI MonitorPlus.

(1A) ADD A NEW IP SERVER TO VI MONITORPLUS

To add a new server to VI MonitorPlus, navigate to the Administration Tab and select Server > Setup and Configuration. A new window appears.



Click on the + symbol, and a new screen will appear.

Enter the information requested

- IP Address
- Port Number (default port number is 4011)

Once the information requested has been provided, click Test.

When successfully connected, the Status will change to the name of the server.

Click Add, or if the incorrect IP address was provided, click Cancel and restart.

Once a server has been added, it will appear in the main startup menu when logging into VI MonitorPlus for the first time.

(1B) SERVER CONFIGURATION

Server Configuration

This section provides access to three critical items for ease of management as it applies to the IP Server selected from the left menu window. Those three sections are:




- Server Identification
- Database Information
- Video Storage

Server Identification

Allows the Administrator to change the default server name, view the version number of the IP Server connected to VI MonitorPlus, and view the IP address of the IP server itself.

Only the name of the IP server can be modified in this section.


Database Information



Database Information


This section allows the Administrator to test connectivity with the SQL database, as well as alter the database connectivity parameters.

Video Storage




The Administrator can elect to use a new video storage location by modifying this field to reflect the desired landing point for video collection. This will apply to any NEW cameras

(1C) CAMERAS



The cameras section provides access for the administrator to quickly add or remove cameras, view licensing information as it relates to the total number of cameras available through the licenses and move cameras from server to server in a share database environment.

Licensing Information



- Number of cameras in total that the license supports
- Number of cameras being used against the license
- Number of cameras being used with a bundled license
- Server limitation for number of cameras
- Total number of cameras that can be used on the server with the current license

Add Additional Cameras




The Add Additional Cameras section is the main point for Administrators to add cameras to an IP Server.

Cameras can be added automatically if their passwords are at default or the password is known.

Additionally, Cameras loaded into this screen in a shared database environment can be move to other servers, for ease of administration of multiple servers and many cameras.

Monitored Cameras



The Monitored Cameras section is a tool that displays the cameras that are assigned to the IP Server.

List of functions available to the Administrator are:

- Sort Cameras Automatically
- Move camera up or down in the list
(Select the camera to be moved up or down in the list, and then use the arrow keys to move it to the desired location on the list.)
- Delete a camera
(Select the camera to be deleted, and then click on the Delete button.)

(1D) ADVANCED




The Advanced tab displays for the Administrator three core components:

- Server Options (Basic security and Logging)
- Record Options Enable Binary Recording, Reserve Space for other applications
- Live Display Options Server Timeout

Server Options

The Server Options section provides access to some of the security settings that enhance the overall purpose of having an NVR that can be locked down by feature:

- Enable Security.
- Allow only one login per user.
- Designate Server as a Failover Server.
- Symantec Certificate Validation.
- Enable System Log. (Keep for XX days)
- Enable Tamper-proofing for Recorded Video.
- Retain User Audit Data for XX days.



Record Options

Enable Binary Recording: Allows the access to video being recorded on the fly. It is a very resource consuming feature and should only be used when consistent access and review of video are needed.


When enabled, the Proprietary Video Format (.vida) will be used instead of the standard .AVI file format.

Reserve space for other applications: The maximum amount of space used on any attached storage device used by IP Server. (Default: 5GB)




NOTE - Reserve space may not reflect the actual available disk space on IP Server.

Live Display Options




The Server timeout feature is to prevent unwanted or unintended access to the IP Server through the web client where there is no activity for the desired number of minutes. The default value for this setting is 0, which is powered-off. A recommended value is 20 minutes. After a 20-minute period with no movement in the web client, the user will be automatically logged out.

(1E) CLIENT



The Client tab gives the administrator access to tools that change port numbers (for enhanced security), provide SMTP configurations for sending messages using rules manager, sending a test email to verify that SMTP configuration settings have been entered correctly, and the ability to launch the Group Policy Editor as it applies to an IP Server on an active Directory Domain, where AD credentials are used for logging into VI MonitorPlus and the IP Server itself.

Client Support

A screenshot of the "Client Support" configuration window. It has a title bar "Client Support" and three settings: "Use Data Port" with a value of 4010, "Command Port" with a value of 4011, and "Maximum Connections" with a value of 64. Each value is in a text box with a small up/down arrow icon to its right.

The term Client Support refers to the VI MonitorPlus software client itself.

Network Security can be enhanced by changing the default values for Data and Command ports (4010 and 4011 respectively) to better suit the administrator's needs and any customization of the IP Server.

Maximum Connections is the total number of VI MonitorPlus clients with access to the IP Server. The default value is 64 connections, which is also the maximum recommended value.

NOTE - The Maximum Connections number value can be lowered as a method to slightly increase security on the server. A lower value that matches the exact number of personnel that have access to the server is recommended.


Outgoing Email

A screenshot of the "Outgoing Email" configuration window. It has a title bar "Outgoing Email" and two settings: "SMTP Server" with an empty text box and "SMTP Port" with a value of 25. The "SMTP Port" value is in a text box with a small up/down arrow icon to its right.

Outgoing Email

This section provides access to the SMTP server and SMTP port values. The default SMTP Server port is 25, but most SMTP port services with advanced security use alternative ports. These values can be customized to suit the needs and requirements of the SMTP server.

SMTP Logon Information


A screenshot of the "SMTP Logon Information" configuration window. It has a title bar "SMTP Logon Information" and three settings: "User Name" with an empty text box, "Password" with an empty text box, and two checkboxes: "SMTP server requires authentication" and "SMTP server requires encryption (SSL)".

SMTP Login Information

This section allows the Administrator to enter the required username and password for the SMTP server entered in the Outgoing Email section listed above.

As part of the enhanced security requirements necessary for connecting to SMTP servers, Server Authentication and SSL encryption have been added.

Send Test Email


A screenshot of the "Send Test Email" configuration window. It has a title bar "Send Test Email" and two settings: "Email to" with an empty text box and a "Send" button to its right, and "Email from" with a value of "TestMessage@IpVideoServer.net".

After the Administrator completes the SMTP mail server configuration, a test email will be sent to validate the SMTP connection settings.

If the test email is not received, verify the outgoing email address and password, and send a second test message.

If problems persist, verify the correct account settings.

(1F) ACCESS CONFIGURATION



This tab will function only when IP Server is integrated with Access Control devices. Please contact your Video Insight Sales Vendor for more information about Access Control Integration.

For more information about the Access Control servers that are known to function with IP Server and VI MonitorPlus, please visit <http://www.downloadvi.com/accesscontrol> to find the corresponding product guide.


(1G) CONTACT INFORMATION

Contact Information

The information provided here is not parsed to any Video Insight affiliates, nor is it sent to Health Monitor Cloud. This information is solely for internal documentation purposes of the license holder for IP Server and is *completely optional*.

Server Information

The server information entered here is solely for the purposes of internal documentation for the Administrator. Information here is not parsed to any organization in any form.




The administrator can enter the following data:

- Server name
- Building
- Floor
- Room
- Phone
- Description
- City
- State
- Country

Contact Information

Also, not parsed to any outside organization, it is the contact information for the server.



The administrator can enter the following values:

- Primary Contact (name)
- Secondary Contact (name)
- Police Number
- Notes
- Primary Phone (number)
- Secondary Phone (number)

(2) RESOURCE GROUPS

This function allows the Administrator of large IP Server installations to create customized viewing groups for quickly organizing assets across multiple IP Servers.


NOTE - This does NOT move Cameras or Layouts or Maps from server to server. Its intentional use is to allow a user to easily define a variety of customized viewing possibilities with the available resources listed on multiple IP Server configurations.

This functionality aids in the elimination of the sorting and grouping substantial amounts of data each time a user is added to IP Server, need to access a specific map within hundreds of maps, or whatever the preferred sorting preference might be and can be used to share resources of one IP Server with another user on another machine.


To use a Server Group, the assumption is that there are two or more IP Servers already configured to work within VI MonitorPlus. If VI MonitorPlus has not yet been configured to work with multiple servers, please refer to the section above titled [Login Options](#).

(2A) SERVER GROUPS

Server Groups allow the administrator to group specific IP Servers into categories that are unique to the use and need of the Administrator. This feature was developed with large building campuses in mind, where there may be a need to organize multiple IP Servers for easy visual access.




To create a server group, right-click on the Server Groups located in the left tree, and then select Add Server Group.




All of the server groups accessible will be displayed in the window. Select the servers desired to form the group and give the group an appropriate name.

Once all IP Servers have been selected for the group, click OK.

NOTE: Duplicate group names are not allowed within the same server. The same camera group name can be used on different servers.




The new Server Group will appear in the Enterprise View window of VI MonitorPlus, as seen on the left.



The camera layout is pre-defined by the number of selected cameras.


NOTE: Max camera view is 16.

(2B) CAMERA GROUPS



To create a custom Camera Group, right-click on the Camera Groups title and select Add Camera Group.


A pop-up window appears requiring custom input.




All cameras connected to each IP Server will appear within the window.

Add the desired cameras to the list and give the new Camera Group a name for identification.

The new Camera Group will appear in Enterprise View under Camera Groups.




To create View Groups and Map Groups, the process is a repeat of the above steps, with exception to the final display of the View Groups and Map Groups. Each of these is available only on the original server where the layouts are created.



For the creation of View Groups, select View Groups and then Right Click on Add View Group.


Create a name for the custom view and add the previously created Views to the new Custom View grouping.



Next add the desired Views.

Click OK when done adding new Views to the new View Group.

When complete, the New View Group will appear BELOW the Enterprise View box, on the main menu.




This newly created Group will appear. Selecting View Groups will result in the displaying of the Views that were added to this group.

They will be displayed to the right of the View Group list, as seen left.


(2C) MAP GROUPS

To create Map Groups, select Map Groups, and then Right-click on Add Facility Map Group, as seen below.



Give the new Map Group an appropriate name, add the selected maps that were previously created, and then *Click* on OK to complete the new Map Group.

The new Map Group is found on the Live Tab, at the bottom of the left-hand column




Select the newly created Map Group and you will have successfully completed the creation of new groups.

(3) RULES

Users can add new rules by clicking on the + sign next to Rules in the left side menu.

NOTE - For more detailed construction of Rules, please refer to the Supplemental Rules Manager Guide for a more detailed explanation of each of the rules and features available.



Once rules have been added, users can select them from the menu and the rules information will appear on the right side of the screen.

If no screen is selected, the screen will look like the image on the left.

As the image on the left demonstrates, Rules can be enabled, given a name, and then assigned to a server.

Edit Recording Schedule

General Information

Name:

Type:

Weekly Scheduled Days

☐ Monday ☐ Thursday ☐ Sunday
☐ Tuesday ☐ Friday
☐ Wednesday ☐ Saturday

Scheduled Time

Start:

End:

Schedules, events, and actions can be added by clicking on the Add Schedule, Add Event and Add Action buttons, respectively.

As a user creates a new schedule, the following popup will appear as seen on the left.

Add Event

Possible Events that will Trigger the Rule

Event Type	Event Description
Access Control Event	Trigger off of an Access Control Entry or Alarm
Alert Button	An alert button appears in the Live Window Pop
Analytics	Trigger off of a supported Camera's Analytics
Camera Down	Trigger when a specific or all cameras stop responding
Digital Input	External input device (i.e. Alarm)
License Plates	Trigger when a License Plate is found
SDK Input	Receive data from a TCP Port
User Login	Rule triggers when a user logs in
Video Motion	Motion is detected on a specific camera

Alert Button Event


The numeric 'Button ID' must be unique to this server. The reference name defines what the event will be called.

Reference Name:

Button Type:

Users can set a schedule for the selected rule, choosing the days of the week, specific time, and frequency.

When done, click on OK to save the changes.




When adding an event, the Add Event window will appear.

Users can then select an event among the ones available. All alert buttons will be displayed once configured under the left panel navigation under the header titled Buttons.

(3A) RULES SETUP


This is considered an advanced feature due to its complexity. A more comprehensive guide is available for use in the [Advanced Installation](#) section, above. To enable the rule correctly, restart of IP server and VI MonitorPlus is required.

(4) CONNECTION PROFILES



Connection Profiles allows Administrators to manage user profiles and servers based on the profile that has previously been created.


Connection Profiles are similar to the use of Groups.



To add a new connection profile, click on 'Add Profile' and the Add Connection Profile will be displayed.

Once set, click OK to create a new profile

(4A) HOST SERVER AND KNOWN CONNECTION PROFILES



Known Connection Profiles

This list displays only the servers that are available for creation of Host Server Connection Profiles. If a server does not appear in this list, click on Add Profile, and provide the information being requested.




Profile Details

This section allows the Administrator to create a base for server profiles, which can be added to a network share device for easy access from any server that has permissions and access to that share.

4.10.B Camera Properties

VI Monitor Plus features a complete interface to configure and setup the existing inventory of cameras for an IP Server installation. It can be accessed in 2 different ways:


From the Navigation Tree



On the left navigation tree, Right click on the desired camera name, either under the Servers tab or the Cameras tab. From the pop-up menu, select “Properties”.


The Camera Properties window will open with the selected camera's settings.

From the Administration tab



Open the Administration tab on the Main Menu, select “Cameras” and click on “Configure Properties” The Camera Properties window will open without a selected camera.


The Camera Properties interface is divided into 3 main areas:



- ① Left Panel - Navigation Tree to access and select the available Servers and Cameras, complete with a Search option.
- ② Top Panel - Live Video preview from the selected camera, its Details and Primary and Secondary streams data.
- ③ Control Panel - Includes 5 Option Tabs for detailed Data and Configuration settings for the selected camera.

(1) LEFT PANEL: NAVIGATION TREE


Search - Quickly locates a camera or a group of cameras within the Navigation Tree by typing its name or number in the input box.




Servers - Displays all servers connected to VI MonitorPlus and provides access to the cameras associated to each server.



Cameras - Displays all cameras for all servers connected to VI MonitorPlus without separating them by associated servers.




(2) TOP PANEL: STREAMING




The Name, Model and IP Address of the selected camera are shown at the top of the window with enlarged characters.

Preview - Shows the live video streaming from the selected camera, which can be paused or continued by clicking on the top-right playback button.



Camera Details

- **Camera ID** - Designated unique identification number of any given camera.
- **Video Format** - Specific codec type used by the selected camera.
- **Last Received** - Most recent time a live image was received by the server from the camera.
- **Last Recorded** - Last time a recorded event took place and wrote to the storage location.



Primary Stream

- Resolution - Maximum resolution of the video stream.
- Bandwidth - Camera's Bandwidth usage per second.
- Frame Count - Number of frames per second received from the camera.
- Frame Size - Storage quota for each individual frame received.

PRIMARY STREAM	
Resolution	3072 x 2048
Bandwidth	7136 kbps
Frame Count	10 fps
Frame Size	89 KB

Secondary Stream - Shows the same fields of the Primary Stream window, and it is visible depending on the camera and its availability. When unavailable, the status "Inactive" is displayed instead.

SECONDARY STREAM
Inactive

(3) CONTROL PANEL: GENERAL

General	Recording	Motion	Display	Maintenance
Details				
Camera Name A-65 - Marketing		Server DemoVI		
Manufacturer Advidia		Model Advidia A-65		
Connection Information				
IP Address 10.15.0.126				
User Name admin		Password		
Web Access 10.15.0.126				
<input type="checkbox"/> Shared IP Address <input type="checkbox"/> Alternate Ports				
Camera # 0		HTTP 80		FTP 21
		RTSP 554		
Additional Options				
<input checked="" type="checkbox"/> Enable Secondary Stream				
<input type="checkbox"/> Disable PTZ				
<input checked="" type="checkbox"/> Capture Graphics Objects				
<input type="checkbox"/> Capture VCA Events				
Joystick # 0				
<input checked="" type="checkbox"/> Error Logging				
Log File Path C:\Users\VIDEOI-1\AppData\Local\I...				

Details

- Camera Name - Unique name to identify the camera throughout the application, briefly specifying its brand, model, location, department, features, etc.
- Server - Drop-down list of the available VI servers.
- Manufacturer - Drop-down list of Camera Manufacturers.
- Model - Drop-down list of Camera Models associated to the selected Manufacturer.

Details			
Camera Name	A-65 - Marketing	Server	DemoVI
Manufacturer	Advidia	Model	Advidia A-65

Connection Information

- IP Address - Unique IP address for the camera/encoder.
- User Name/Password - Account data to access the camera settings (where available).
- Web Access - Opens an external web browser session to access the camera.
- Shared IP Address - Check this box to manage specific lenses or cameras attached to an encoder. Some cameras (such as Arecont or Scallop Imaging) have multiple lenses and encoders that connect multiple analog cameras on a single device, such as Advitia VP-16, VP-8, VP-4, etc. Therefore, using this feature will let you specify exactly what to display, whether it be lenses or encoders.
- Camera # - Selects the lens/camera to display on a device that shares an IP address.
- Alternate Ports - Check this box to configure any device connected to the IP Server using custom ports. Default ports are:
 - HTTP: 80
 - FTP: 21
 - RSTP: 554

The screenshot shows the 'Connection Information' window. It has fields for 'IP Address' (10.15.0.126), 'User Name' (admin), and 'Password' (masked with dots). Below these is a 'Web Access' field with a link to 10.15.0.126. There are two checkboxes: 'Shared IP Address' and 'Alternate Ports'. Under 'Shared IP Address' is a 'Camera #' field with a value of 0 and increment/decrement buttons. Under 'Alternate Ports' are fields for 'HTTP' (80), 'FTP' (21), and 'RTSP' (554), each with increment/decrement buttons.

Additional Options

- Enable Secondary Stream - Allows the IP Server to extract the secondary stream of a camera when supported.
- Disable PTZ - Disables the camera's Pan/Tilt/Zoom functionality. PTZ functions are accessed via USB by both on-screen and joystick controls. Both are disabled when the option is checked.
- Capture Graphics Objects - Active when VID or iVMD are being used.
- Capture VCA Events - Active when VID, iVMD or camera-side Analytics are being used.
- Joystick # - Used when using a DCZ joystick to designate a specific camera to a specific number on the joystick list, providing the ability to quickly select a camera from the left tree without having to navigate the left tree at all.

The screenshot shows the 'Additional Options' window. It contains four checkboxes: 'Enable Secondary Stream' (checked), 'Disable PTZ' (unchecked), 'Capture Graphics Objects' (checked), and 'Capture VCA Events' (unchecked). At the bottom is a 'Joystick #' field with a value of 0 and increment/decrement buttons.

Dual Streaming- Allows secondary stream from an IP camera. This setting is located under the General tab and will display data regarding stream details on the Secondary stream panel once enabled.

- When secondary stream is enabled on a camera, any layouts displayed containing 4 or more cameras will automatically display using the second stream, which is often a lower resolution and/or framerate.
- All recordings will be stored using the primary full resolution stream. Secondary stream is used for multi display views over 4 cameras.
- To configure the secondary stream, the user should enable secondary stream checkbox on Camera Properties (as well as manually on the cameras direct configuration).


Example: If you have 15 4K cameras with dual streaming enabled on all, displaying all cameras in a single view layout will result in a lower resolution and frame rate for all cameras. Displaying the primary stream on the cameras without dual streaming will use more bandwidth and processing power with no added benefit on resolution.

Error Logging - Check this box to enable the capture and save errors messages received from a camera into a log text file. This allows Administrators, Technical Support and Development staff to quickly diagnose possible issues with a specific camera.


- Log File Path - Specifies the physical folder/file for the ErrorLog.

The screenshot shows the 'Error Logging' window. It has a checked checkbox for 'Error Logging'. Below it is a 'Log File Path' field with the text 'C:\Users\VIDEOI-1\AppData\Local\...' and a browse button (three dots).

(4) CONTROL PANEL: RECORDING



Settings





- Format - Drop-down list of Video Codec types. H.264/H.265 (default) are recommended for best performance.
- Resolution - Drop-down list of resolution levels provided by the camera.
- Record - Defines the recorded video frame rate during a specific interval of time, depending on the camera's supported properties.
- Quality - Adjusts the camera's bit rate (lower bit rate = lower video quality).
- Time Stamp - Enables/disables the on-video time stamp obtained from the camera's date/time feature.
- Enable Audio
 - Live - Activates audio support during live video streaming.
 - Recorded - Enables audio for recorded video viewing.
- Insert Watermark – Check this box to enable the on-top display of live/recorded video, including: Codec, FPS, Camera Name/Model, etc. This feature might impact the CPU performance.

Recording Type

- Off - No recording enabled.

For audio/video synchronization, it is highly recommended that *Record Always* recording type is used with all audio functions.

- Always - Always recording, enables ability to use motion detection when recording. Events with no motion are not recorded. Enable "Calculate motion detection" by checking the box.



- On Motion Only - Records on motion only, based on camera-side or server-side settings. Check the “Record Always at” box to select 1, 2 or 3 FPS “no motion” video recording rate. If motion is detected, recording will start at the current FPS setting. If a user is recording at 1FPS always, with motion detection set to 10 FPS, the video that contains “no motion” will appear at fast speed. Motion is detected at normal speed during playback.

The 'Recording Type' window shows four radio buttons: Off, Always, On Motion Only (selected), and Scheduled. Below, the 'Record always at' checkbox is checked, with a value of 1 FPS and an option to 'increase to specified FPS on motion'. A 'Motion Buffering' section shows 'Pre-Motion' at 0 seconds and 'Post-Motion' at 3 seconds, both with increment/decrement controls.

- Scheduled - Records using a time schedule. When no schedule is defined, the camera recording is set to off. Enable “Calculate motion detection” by checking the corresponding box.

The 'Recording Type' window shows four radio buttons: Off, Always, On Motion Only, and Scheduled (selected). Below, the 'Calculate motion detection (may increase CPU usage)' checkbox is unchecked. An 'Edit Schedule' button is at the bottom.

Click on “Edit Schedule” to open the Camera Schedule interface:

The 'Camera Schedule' window has a title bar and a close button. It contains two sections: 'Schedule(s) for record always' and 'Schedule(s) for record motion'. Each section has a table with 'Name' and 'Type' columns and buttons for 'Modify', 'Delete', and 'Add'. At the bottom are 'OK' and 'Cancel' buttons.

The Camera Schedule interface allows *adding*, *modifying*, or *deleting* scheduled times for Record Always and Record with Motion times.

The 'Edit Recording Schedule' window has a title bar and a close button. It contains a 'General Information' section with fields for 'Name' (New Schedule) and a 'Type' dropdown menu (One Time, Daily, Weekly, Monthly). Below the dropdown are checkboxes for days of the week (Monday through Sunday). The 'Scheduled Time' section has 'Start' and 'End' time pickers (3:00:00 PM and 4:00:00 PM). At the bottom are 'OK' and 'Cancel' buttons.


The Edit Recording Schedule form is opened by *adding* or *modifying* a schedule, and it allows defining one-time, daily, weekly, or monthly recording schedules, as well as the start and end times for each event.

Video File Storage

- File Path - Physical location where the recorded video will be stored.
- Max Disk Space - Limits de maximum space on disk reserved for the camera.
- Max File Size - Maximum physical size of each recorded video file.
- Delete After - Number of days the video file will be stored before its removal (first in-first out basis).

(5) CONTROL PANEL: MOTION

Motion Zones allow more precise motion detection within captured video recordings. When combining Motion Zone with Motion-Only recording, the camera will ignore certain areas in its line-of-sight.





Detection Type: Camera Side

When available, Camera-side Motion Detection is *recommended to reduce the CPU load* on the server's processors.

- Use Camera Settings - Select this option to use the motion detection settings already configured on the camera.
- Motion Detection (*Entire Image*) - Select this option to activate the *Detection Options (Entire Image)* for the Camera Side detection. The variables are:
 - Event Trigger: Defines the percentage of visual area where change/motion is detected.
 - Sensitivity: Near-far gauge, the higher the sensitivity, the better the accuracy.


Each zone can have its own specific combination of sensitivity and event triggers.




Detection Type: Camera Side

- Detection Options (*Entire Image*) - This area allows the configuration of Event Trigger and Sensitivity values for the entire image motion detection.
 - Event Trigger: Defines the percentage of visual area where change/motion is detected.
 - Sensitivity: Near-far gauge, the higher the sensitivity, the better the accuracy.

A live gauge shows the occurrence of an event that triggers a motion detection, displaying a "Motion Detected" status message in orange letters when this happens; "No Motion" is the default status.




- Motion Zones - This section provides an interface to define specific areas within the video feed where motion detection may be considered more critical for event monitoring.




Motion Zones are off by default, which means the corresponding buttons (Add/Edit/Remove/Clear) are deactivated.

To activate them, check the “Display Motion Level” box on the left, under “Detection Options (Entire Image)”.



To Add Motion Zones, click the “Add/Edit Zones” button and the Motion Zone Configuration screen will open.




Start adding zones by drawing or resizing the desired areas *directly on the video feed*, or by clicking “Add New”.

The Motion Zones table shows the currently defined zones for the camera, with the corresponding settings and values. The selected one appears with orange background and an orange frame on the image.

Zones can be deleted individually by clicking the “Delete” button or cleared from the table by clicking “Clear All”.

Data can also be edited by Pixels or Percent.




Cells on the Motion Zones table *can be directly edited* by clicking on each cell and entering the desired value.




Click “OK” to save the Motion Zones, and the Configuration window will close.

Now, the Zones previously defined *will be shown* on the Camera Properties page.



To delete a specific zone, highlight it with the cursor and click the “Remove” button.

To delete all zones from the table, click the “Clear All” button.



(6) CONTROL PANEL: DISPLAY








Image Rotation

- Rotation – Drop-down list of available image rotation options; only for cameras that support this feature.
- Enable Corridor View – Enables 90° corridor view mode and rotation options below
- Corridor Rotation – Select either left or right rotation for Corridor View.




On-Screen Display - Displays and positions a built-in watermark on top of the live video.



360° Option


- Enable Dewarping – Check the box to activate Dewarping features on supported cameras.
- Mounting Position – After enabling dewarping, select the view orientation from the drop-down list.




(7) EDITING MULTIPLE CAMERA PROPERTIES

Camera properties can change multiple devices at a time.

To modify the camera properties, click on Administration> Cameras> Configure Multiple Camera Properties



Only the compatible format of selected cameras will show options that can be modified.



All system values for the selected cameras will have to match.

Servers can be filtered.

Column headers will allow properties to be sorted.


NOTE: The top grid and NVR servers cannot be edited while multi server cameras can be.

Camera Name	Server	Manufacturer
<input checked="" type="checkbox"/> 10.0.0.10	AZURE-IP Server	TGCC
<input type="checkbox"/> 10.0.0.11	AZURE-IP Server	TGCC
<input checked="" type="checkbox"/> 10.0.0.12	AZURE-IP Server	TGCC
<input checked="" type="checkbox"/> 10.0.0.13	AZURE-IP Server	TGCC
<input type="checkbox"/> 10.0.0.14	AZURE-IP Server	TGCC
<input checked="" type="checkbox"/> 10.0.0.15	AZURE-IP Server	TGCC
<input type="checkbox"/> 10.0.0.16	AZURE-IP Server	TGCC
<input type="checkbox"/> 10.0.0.17	AZURE-IP Server	TGCC
<input type="checkbox"/> 10.0.0.18	AZURE-IP Server	TGCC
<input type="checkbox"/> 10.0.0.19	AZURE-IP Server	TGCC

All camera details must be modified through Step 2: Edit Properties.

A square inside of the checkbox indicates there are 'undetermined' values in the camera selection. Some values are true and other values are false.

A checkmark in the checkbox will enable the value for all selected cameras.



(8) CONTROL PANEL: MAINTENANCE

The screenshot shows the Maintenance Control Panel with the following sections:

- Tabs:** General, Recording, Motion, Display, Maintenance (selected).
- Additional Information:** Warranty, Installed, IDF / Switch, Other.
- Contact Information:** Contact Name, Contact Info.
- Firmware:** Version.
- Service History:** Details, User Name, Service Date. Includes an "Add new service record" box with "Add New" and "Cancel" buttons.
- Actions:** Import from Template, Export to Template.

Additional Information

- *Warranty* – Date of expiration of the camera’s warranty.
- *Installed*- Installation Date of the camera.
- *IDF/Switch* – Physical location of the switch that the camera is connected to.
- *Other* – Additional information deemed relevant for maintenance purposes.

This close-up shows the input fields for Warranty, Installed, IDF / Switch, and Other.

Contact Information

- *Contact Name* – Name of key person(s) responsible for the camera.
- *Contact Info* - Phone number, email, or any information to contact the keyperson(s).

This close-up shows the input fields for Contact Name and Contact Info.

Firmware

- *Version* – Latest Firmware version number / date.

This close-up shows the input field for the Firmware Version.

Service History - This area is used to keep a log of each maintenance-related activity for the camera.

To Add a new service record, start writing on the “Add new service record” box, describing the details of the activity; then, click “Add”.

The information will be displayed on the Service History table, including the *User Name* and the *Service Date*, posted automatically.

The form shows a text area with the text "Adjustments on the Mounting Position performed." and "Add New" and "Cancel" buttons.

Details	User Name	Service Date
Adjustments on the Mounting Position performed.	Administrator	3/5/2019 12:45:10 PM

Actions

Export to Template


Click on “Export to Template” to create an external file with all the basic features and settings of the camera, which might be used to quickly configure similar cameras on separate instances.

VI MonitorPlus will create a new file with the name of the camera by default.

To import settings from a previously configured camera with similar or identical features, click “Import from Template” to open the Select Template window.


Select the desired template from the list; click “OK” and the Properties fields for the current camera will be automatically populated.

Import from Template



4.10.C Views Setup



The left side menu works as in the previous section, with a list of all the existent views and then another with items available to be added to the views.




To add a new view, click on the + sign.

When the user selects a view from the list, it will appear on the screen. Drag and drop the desired cameras into place as they are to appear for viewing on the screen.

Fill in the name and description fields and click Save to save the view.



To organize the View order, select Administration from the menu ribbon, click Views and select Organize. Select the View you wish to organize into order and use the Move Up and Move Down buttons to rearrange the order. For organizations that wish to have the Views listed in alphabetical order, use the Sort A- Z button to order. Clicking the Sort Z-A button will reverse the order of the Views into descending order.




Views can be populated with static images, PDF documents, or URLs to a specific website. To add any of these items, click on the Additional Items link in the bottom left side of the page.

4.10.D Facility Maps Setup



Facility Maps are graphic representations of the facility's assets and their locations inside a building or campus. They may include cameras, views, doors, and alarms, among others, providing real-time access to video feeds, access control and other resources using a user-friendly interface.

(1) CREATING FACILITY MAPS


From the Main Menu, select “Administration”, then “Maps”. This will open the Maps Setup window (see below).



Click on the Plus [+] sign next to the “Maps” header. A New Map interface will open on the right side of the window (see below).




In the New Map area, select the Server in which your Map will appear using the corresponding drop-down list.





Define a Name for your Map.




Select the Image Size (Original or Custom) from the drop-down list.



Click “Load Image” to browse and select the image file from your computer.



Click “Font Options” to open the corresponding window and select the color, family, and size of your Map’s fonts.



Once the Map image is properly positioned, start adding Cameras and other items to it by dragging and dropping them from the Add Item section on the left panel to the map.

Embedded maps can be launched in the workspace window.

Click and drag to embed a new map into the existing map. An overlay of the embedded map will be opened on top of the current map. Other featured items can be added to the map from Add Items.

Click on the pop-out icon to separate the map into a new window. Return to workspace will replace the window back to its original position.




Once positioned on the map, items can be *moved*, *rotated*, and *resized* using the mouse cursor to replicate their position and range.


To Delete an item on the map, right-click your mouse while pointing to the item and select “Delete”.



In addition to Cameras, Views, Maps, Doors, Alarms, Regions and Buttons can also be added to your Map.




Click “Save” to save the new Map on your server, and it will appear on the left panel, under the Maps section. Press “Cancel” if you do not want to save it.



(2) SEARCHING FACILITY MAPS

To search a specific map in your directory, click on “Search” from the left panel, then *type the name of the map* until it shows on the list.

Click on the map name from the list to open it.




(3) EDITING FACILITY MAPS

To Edit or Modify a Facility Map, *click on its name* from the Maps list (left panel) or using the Search option.


Once the map is open, proceed to make the changes following the instructions as indicated in the Creating a Facility Map section (see *above*).

Save your map after finishing.




(4) DELETING FACILITY MAPS

To Delete a Facility Map, point the cursor on its name from the left panel list, then right-click on, select “Delete” and confirm the operation.



(5) VIEWING FACILITY MAPS




Facility Maps can be created in the VI MonitorPlus by a System Administrator to give a graphical representation of where cameras are located throughout a building or campus.

To view a Map in VI MonitorPlus, click Maps on the left navigation bar.

Opening a Map will replace the current workspace from the main view.


(6) VIEWING LIVE VIDEOS WITHIN FACILITY MAPS

To view live videos from a Facility Map, click on *any Camera icon* on the map itself, and the right panel will open automatically, displaying the view of selected camera's streaming video and its corresponding Details and Actions.




To enlarge a live video view, click on the diagonal arrow on the upper right corner of the workspace, above the minimized video view.

A new window will open on top of VI MonitorPlus, displaying the enlarged video streaming from the selected camera.



4.10.E User and Groups

To manage VI MonitorPlus operators and user groups, use the Users & Groups button on the menu toolbar. A menu in the left side of the screen will open to select active Users (and in this case, also Groups).



When a user is selected, the loaded user page appears (see left).


User data such as name, login information and e-mail are displayed and able to be edited.

Permissions are also shown in the bottom grid.

Users can also select the Resources tab, which will show the managed resources (facility maps, views, and rules).


(1) GROUPS

Groups can be assigned during creation by selecting the Group in the checkbox on the right side of the screen.



Similar to selecting a user, a group can also be selected from the left menu.

To add a user or a group, the Administrator must click on the + sign next to Users or Groups in the left side menu.



Fill in the blanks for username, full name, email address and password to setup a new user or group.

The roles of the user can be customized by selecting camera specific permissions using the table (seen left).

(2) SETUP AND CONFIGURATION


(2A) USER MANAGEMENT

VI MonitorPlus can be used to connect and add Users by way of Active Directory or LDAP. While the prerequisites vary between the two, we will cover only those associated with Active Directory.

Security will persist on the server only when “Enable Security” has been checked within the Administration > Servers > Advanced tab.


(3) PTZ PRIORITIZATION

This legacy PTZ Prioritization function allows administrators to set the priority for users on all PTZ capable cameras. The higher the listed user or group is, the higher their priority.




To enable, open VI MonitorPlus and navigate to Administration → Modules. Select PTZ Prioritization.

Here, select either Add User or Add Group, depending on the desired configuration. A new pop-up window appears.



Next, select the desired users for PTZ prioritization. Once the desired users have been selected, press OK.

If the added users are not appearing in the correct order, select one user and change its location within the list by using the Up and Down arrows. (pictured below)



To move a second user, click on the user, and again, use the up and down arrows on the right to move the users into a Top → Down hierarchical order of PTZ use prioritization. Once all users appear in the desired order, click Save.

NOTE - PTZ Prioritization is now configured. If two users or groups want to use the PTZ feature on the camera at the same time, the lower-priority user will have to wait 300 seconds after the higher-ranking member stops using the PTZ controls.

The default wait time is 5 minutes (300 seconds). The wait time can be changed in the database, but is a task recommended only for advanced users.


4.10.F Modules

(1) GUARD TOURS


Guard Tours are a select number of cameras and live views that are set to create a pop-up window during a pre-determined period. The Administrator can control who has access to a guard tour, when the pop-ups appear, which cameras are to be monitored, and if manual data entry must be performed to move on to subsequent camera views for accountability purposes. Below are the steps for creating and a new Guard Tour.

Guard Tours Setup


To setup a new Guard Tour, log in as an Administrator. Next, select Administration > Modules > Guard Tour.



Once the new window appears, select the server with the Users, Groups and Cameras that are going to be used with the new Guard Tour, then click Add.




Provide a name for the new Guard Tour.



Select the cameras to be used on the Guard Tour.

Each Camera must have the check box marked for it to appear within the Guard Tour.

Scheduling



Scheduling the Guard Tour so that it appears several times (within a specific range of time) is possible.

A maximum time limit of 1440 minutes (24 hours) is permitted when electing to populate the Guard Tour window every XXX number of minutes. Default is 60 minutes.

The Guard Tour can be configured to run once a day as a specific time, or Demand Only.

Options:

-Options

☒ All Users

☐ Specific User

☐ Administrator

☐ Specific Group

Within the Options section, this allows the admin to select specific users or groups that the guard tour will apply to. Configuring more than one tour for different needs is possible.

☐ Force User to Enter Text Before Continuing

Selecting the check box for this feature forces the user to be required to enter text within the Guard Tour window before dismissing a screen.

OK

Click OK to save the guard tour.

(2) JOYSTICK OPTIONS

Joystick Options

Step 1: Select one or more camera rows to number

Server	Camera	Number
IP Server -10.10.6.215	10.10.6.125 - Advidia - Model A-54	0
IP Server -10.10.6.215	10.10.6.130 - Advidia - Model A-34	0
IP Server -10.10.6.215	10.10.6.26 - Advidia - Model A-42	0
IP Server -10.10.6.215	10.10.6.27 - Advidia - Model A-54-OD	0
IP Server -10.10.6.215	10.10.6.28 - Advidia - Model A-14	0
IP Server -10.10.6.215	10.10.6.31 - Advidia - Model A-34	0
IP Server -10.10.6.215	10.10.6.37 - Advidia - Model A-14	0
IP Server -10.10.6.215	10.10.6.47 - Advidia - Model A-34	0


Step 2: Specify starting number, number spacing, and click "Re-Number"

Starting Number Number Spacing

Joystick Options allows the administrator to specify a camera to a designated button on the Video Insight joystick.

NOTE - For more information about the Video insight customizable joystick, please contact your Panasonic Sales representative.

(3) LANE VIEWER

The image shows the 'Lane Viewer Configuration' window. It has a title bar with a small icon and the text 'Lane Viewer Configuration'. Below the title bar is a section header 'Lane Viewer Configuration'. Underneath is a section titled 'Lane Viewer'. This section contains a 'Picture Size' group box with 'Width' and 'Height' spinners (set to 320 and 400 respectively), an 'Always show last entry' checkbox, a 'Black out picture after' spinner (set to 30 seconds), and a 'Restore' button. Below this is a 'Live Video' group box with 'View Live Video' and 'Show Live above picture' checkboxes. At the bottom is a 'Viewing Options' group box with 'Number of Lanes' (set to 3), and checkboxes for 'View Valid Accesses', 'View Invalid Accesses', 'Show User Name', 'Show Time of Entry', and 'Show Access Control Message'.

The Lane Viewer Configuration screen displays all the related settings to Lane Viewer, a function that works with Access Control servers.


The ability to modify Lane Viewer picture size (width, height and blackout), Lane Viewing options (number of lanes, valid and invalid accesses, show name, time, and message) and live video options (view live video, show live above picture).

(4) PUBLIC VIEW MONITOR

Public View Monitor is obsolete. The functionality has been transferred to VI Video WallPlus. For more details, please refer to the VI Video WallPlus documentation.

(4A) CONFIGURATION

After the installation is complete, launch VI MonitorPlus and click on Administration > Views. Create the layout you want visible in Public View Monitor Application.

The image shows the 'Add New Public View Definition' dialog box. It has a title bar with a small icon and the text 'Add New Public View Definition'. Below the title bar are three input fields: 'Name', 'Description', and 'View' (which is a dropdown menu). At the bottom are 'OK' and 'Cancel' buttons.

Once the View is created, click Administration> Modules and select Public View Monitor in the left tree.

Click Add. Create a name and description for your Public View Window and select the View you wish to display.


Click OK and then Apply in the Public View Monitor area to save your changes.

NOTE - The ONLY layouts that will appear in the Public View Monitor menu are the layouts specifically created for use in the Public View Monitor layout list, not the VI MonitorPlus layout list.

(5) TV DECODERS

IP Server can record data sent by a TV Decoder. Adding a TV Decoder to IP Server within VI MonitorPlus will allow customizing its name and adding it to the IP Server's cameras list on the left-side of the screen.

Network decoder properties: Configuration



The screenshot shows a dialog box titled "Network decoder properties" with a close button (X) in the top right corner. The dialog contains the following fields and controls:

- Decoder Name: A text input field.
- IP Address: A text input field.
- User Name: A text input field.
- Password: A text input field.
- Decoder Type: A dropdown menu currently showing "Axis 292".
- Sequence Mode: A dropdown menu currently showing "Auto".
- At the bottom, there are two buttons: "OK" and "Cancel".

Enter the IP Address, username, and password of the decoder, followed by the model number and camera sequence mode for the workspace used to display the decoder.

(6) VIDEO WALLPLUS

Video WallPlus allows monitoring a large quantity of cameras at one time, controlling the content of several TV monitors from a single console. Video WallPlus allows each TV monitor to display a single camera, a server, or a customized layout.

For more information about Video WallPlus, please refer to the supplemental documentation found in [Appendix D](#), below.

4.10.G NVR Enrollment and Integration



VI MonitorPlus supports the enrollment of the following NVR models:

- WJ-NX400
- WJ-NX300
- WJ-NX200
- WJ-ND400
- WJ-NV300
- WJ-NV200

This support allows users to access live and recorded video through the VI MonitorPlus client. To utilize this functionality, Administrators need to follow the following steps for setup and enrollment.

Select Administration -> NVR.

To add a new NVR device, click Add.




Assign a server to the NVR device by selecting a Server in the drop-down box. Next, enter IP Address and Port of the NVR (default = 80), along with User ID and Password.

Define a Name for the NVR in the Name field.

To complete, click on the Synchronize button.


The detected cameras will be displayed in the table below.

Click Save to complete the NVR enrollment.




The Add/Update Panasonic NVR interface shows:

- Number of available NVR licenses
- Option to connect camera streaming via NVR
- Limit of NVR camera stream (default=4)




Once enrolled, the left tree will refresh with a new NV Server icon along with the name of the NVR selected from enrollment.




(1) NVR INTEGRATION

NVR ARCHITECTURE UP TO V7.2



- NVR cameras are managed as normal cameras in live video.
- IP Server must be connected to the camera network.
- Dual network bandwidth needed for each camera.

NVR ARCHITECTURE STARTING FROM V7.3



- NVR camera live feed may be restricted due to NVR resources.
- IP Server does not have to be connected to the camera network.
- Single network bandwidth required for each camera.

(2) MAXIMUM NUMBER OF CONCURRENT FTP REQUESTS

The following table shows the maximum number of concurrent FTP request for each model:

Camera model	Max. concurrent FTP requests
WJ-NX400	8
WJ-NX300	8
WJ-NX200	8
WJ-ND400	8
WJ-NV300	2
WJ-NV200	2


(3) ENABLING MEDIA FOUNDATION ON WINDOWS SERVER

For certain NVR cameras (e.g. ND400), the ability to view recordings from VI MonitorPlus is not available by default.


To enable it, the Media Foundation feature must be installed on the Windows Server where NVR cameras are currently enrolled.

The procedure is as follows:

1. Execute Server Manager:
 - (Start > Administrative Tools > Server Manager)
- or:
- Type “ServerManager” in the shortcut location box and click “Next”
2. Select “Manage” and “Add Roles and Features”
3. Select “Features”
4. Check the “Media Foundation” option
5. Click “Next”




When asked to install the additional feature, click “Add Features”, then “Install”. *Restart the server.*




4.10.H User Audit Video Logging

VI Monitor Plus User Audit function now records when users start to playback and save videos. The Audit log can be shown when users exit the playback function. This can be done from a single camera or multiple cameras. The User Audit function is set to off for all users. Users will have to turn the function ON to use.

Open in playback mode.




When opened, select the time the playback was executed.



Timestamp	Client	Server Name	Server IP	Camera ID	Values	Client IP
9/13/2019 3:43:21 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Order of actions	10.0.201.200
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Play Forward (1s)	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Order of actions	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Play Forward (1s)	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Order of actions	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Play Forward (1s)	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Order of actions	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Play Forward (1s)	2019/09/13 12:28:24

Close play back mode.



Select the user, start date, due date, report type as play back, and preview data.


Timestamp	Client	Server Name	Server IP	Camera ID	Values	Client IP
9/13/2019 3:43:21 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Order of actions	10.0.201.200
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Play Forward (1s)	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Order of actions	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Play Forward (1s)	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Order of actions	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Play Forward (1s)	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Order of actions	2019/09/13 12:28:24
9/13/2019 3:43:23 PM	jeff-118-w-05	10.0.201.200	10.0.201.200	10.0.201.200	Play Forward (1s)	2019/09/13 12:28:24

4.10.I User Audit Reports

VI MonitorPlus features the User Audit reporting tool, which generates a parametrized report with data about the login sessions of a specific user or a group of users, as well as the resources utilized during said sessions.



The User Audit data will only be stored for 30 days on a first-in, first-out basis. The oldest records will be overwritten automatically with the newest ones, following the 30-days cycle. The User Audit function is set to off for all users. Users will have to turn the function ON to use.

This tool can be accessed selecting the User Audit option under the Administration tab.




In the User Audit window, select the parameters for the report:


- Report Type
- Start and End date




- Users and Groups



Once the parameters are selected, click on Preview Data.





The screenshot shows a 'User Audit' window with a 'Report Preview' section. It contains a table with the following data:


USERNAME	TIMESTAMP (CLIENT)	SERVER NAME	SERVER IP	LOGIN STATUS	LOGIN TIME (SERVER)	LOGOUT STATUS	LOGOUT TIME (SERVER)	DURATION
Administrator	10/1/2018 2:26:11 PM	IP Server -10.10.7.111	10.10.7.111	Login Successful	10/1/2018 12:26:07 PM	Not Applicable	Not Applicable	Not Applicable
administrator	10/1/2018 5:22:26 PM	IP Server -10.10.7.111	10.10.7.111	Login Successful	10/1/2018 3:23:06 PM	Logged Out	10/1/2018 3:29:21 PM	00:06:15
administrator	10/1/2018 5:29:20 PM	IP Server -10.10.7.111	10.10.7.111	Login Successful	10/1/2018 3:30:00 PM	Not Applicable	Not Applicable	Not Applicable

At the bottom of the window, there is a 'Return To Criteria' button on the left, a 'Total: 3 Record(s)' label in the center, and an 'Export' button on the right.

The Report Preview will display the output before generating the report itself. When ready, click on Export to create the report, or Return to Criteria to redefine the parameters.

The Report will be generated and downloaded to a predefined folder, in CSV format.

Click on Open to view the report or Show in Folder to retrieve the CSV file.



5. WEB CLIENT


The Web Client is a free thin client application that allows the access to live and recorded video from any web browser. An optional ActiveX control can be used when viewing the Web Client in Internet Explorer.

The Web Client requires IIS v 6.0 (or later) to be installed on the IP Server machine.

5.1 1 LOGGING IN

Access the Web Client using <http://<SERVERIP>/videoinsight> or the URL provided by the IP Server Administrator, using the browser of your choice.

Enter the User Name and Password for your account and click Login.



5.2 LIVE VIDEO

Once logged in, the Web Client will display the first 30 cameras in the Server list (where 30 or more cameras have been added to the IP Server).


To view the names of the Cameras, expand the Server Name in the left tree.

After selecting a camera from the left tree, the Web Client will only display the video for that camera.

There are 2 options to view a single camera:

1. Click on the Camera's live image.
2. Click on the Camera's name in the left tree

The image from the selected camera will be displayed over the other cameras in the visible layout.



From this view it is possible to:

- Perform a digital zoom
- Move the camera (PTZ supported cameras)
- Take a snapshot from the live video
- View the video in its true aspect ratio
- View recorded video.



5.2.A Camera Manipulation

(1) DIGITAL ZOOM


To perform a Digital Zoom:

1. Select the Digital Zoom button on the video toolbar.



2. Click and drag from left to right in your area of interest.
3. Drawing this zone will enlarge the area to full screen.


To view the full image once again, click the Reset button or double-click on the image.



NOTE - Snapshots of the zoomed image can be taken, but, unlike VI MonitorPlus, it is not possible to move within the zoomed image on the Web Client.

5.3 3FACILITY MAPS

To view Facility Maps from within the Web Client, click on the Map icon found in the left tree.




Hover the mouse cursor over a Camera Name/Icon to display its Live Video.

5.4 LAYOUT DIRECTORY

Custom Views can be accessed by clicking the Layouts button at the top of the left tree.


Similar to the default Enterprise View that appears after logging into the Web Client, clicking on a single camera view allows the user to customize the Layout.



This is accomplished by expanding the Layout camera list and checking off which cameras are desired for viewing.

5.5 RECORDED VIDEO

To access recorded video in the Web Client, click on the camera image of the camera to display the timeline video of available recorded video.




NOTE - Allow initial loading time on the first camera displayed.

The Timeline, displayed across the bottom of the image, can be used to review the footage recorded for that day.


Drag the mouse along the timeline to select the desired timeframe to view.

The Web Client will load the recorded video file for that time and start playing it back.

To view recorded video from previous days, click on the *date* in the lower left-hand corner of the image to bring up a calendar.



Areas shaded *Orange* contain playable recorded video.




5.5.A Creating Clips

To create a clip, click on the film icon at the end of the Timeline, this will display the clip/time selector



Select the time range by adjusting the blue sliders or typing into the text fields which display the time.



Next, click the Download icon.



NOTE - A progress bar will appear on the right area of the screen while downloading.

Once the download is complete, you will be asked if you would like to Open or Save the video. Opening the video will immediately start playback on the local media player, while saving will allow the server to save and store the file for review later.



Unlike VI MonitorPlus, this video is stored in the compression format which the camera is recording in, so if the camera is recording H.265 video, then the .AVI will require an H.265 codec to play. If you are unable to playback the clips saved through the Web Client, please see your System Administrator to obtain the required codecs needed for your cameras.

While VI Mobile does not directly support H.265 cameras through software or server transcoding, if Hardware coding in both VI iOS and VI Mobile Android are both turned off, H.265 cameras do work.

5.5.B Watermark Verification

To verify a Watermark for any clip created by the Web Client, follow these steps:



1. Navigate to the web-client using either IE (high or low speed mode) or Chrome
2. Select any Camera with a recording desired for downloading
3. Click the "Create Clip" icon in the lower right-hand side of the window and choose the desired clip length; make sure to check the "Include Watermark" box.
4. Click Download to the right of the time display and wait for the download to complete.
5. Save the file to a location that is easy to recall.
6. Open VI Media player and select the downloaded clip, after pausing the video.
7. Next, select File > Check Watermark. A verification message will appear (see left)

5.6 6 HIGH SPEED MODE

High Speed Mode Web Client utilizes the Active X control for Video Insight and requires Internet Explorer to run.

The benefits to using High Speed Mode are that it gives you the exact frame rate, resolution, and compression the camera is streaming to the Server. After the Active X control is loaded, the Web Client functions in the exact same manner.



In High Speed mode, you can also DPTZ in both live and recorded video when using the Digital Zoom function of the Web Client.


To start using the High-Speed mode, click the Speed button on the top right area of your screen. You will be prompted to download an ActiveX tool to install. This action usually requires Administrator privileges within your operating system.

5.7 7 ACCESS CONTROL

Limited Access Control functionality is available via the Web Client, and it is easily accessed by selecting the Custom Layout created for the IP Server.


There are 2 primary ways to access the Access Control features in Web Client:

ViewCameraLayout		Select the View from the Layout Directory icon on the left panel.
Facility Map - Door View		Select a Facility Map on the left navigation panel by selecting the Maps icon.



Select the desired map to view. If configured in VI MonitorPlus, a visual map of the facility with the doors connected in the correct locations.

Hover over the door to see a live preview of a door with an associated camera.



To access the door controls, double-click the door icon the map. Once selected, a new display menu will appear. In the menu, there are six access control specific functions made available to the user.

The controls (above) are listed from left to right are:


- Schedule: Forces device to return to any previously configured schedule.
- Unlock: Unlocks device.
- Lock: Lock device.
- Admit Entry: Temporarily unlocks device. Period of temporary unlock is often customizable in the access control application.
- View (Access) History: Views detail list of authorized access names.
- View (Alarm) History: Displays detailed list of door lock violations.

When any of the action-oriented controls (Lock, Unlock, Admit, Schedule) are selected, a confirmation box will appear to prevent an unintentional command from being executed on the device at the wrong time.

Click OK on the dialog to continue the action.



Web Client can alter access control settings for minor changes. To do so, select the Interface icon from the menu bar on the left side of the administrator's control screen.

A screenshot of a web-based configuration window titled "Access Control". The title bar is light blue. Below the title, there is a descriptive text: "Enables the interface that allows users to control access to restricted areas." Underneath this text are three radio button options: "Disabled", "Enabled", and "Admins Only". The "Admins Only" option is selected, indicated by a filled black circle next to it.






Next, three options appear as choices:

- Disable Access Control features.
- Enable Access Control features.
- Grant access for Administrator level accounts only.

Once the desired choice is selected, be sure to click Save at the top of the screen.

5.8 8ADMIN FEATURES

Web Client can perform some basic administrative tasks that affect the performance and appearance of IP Server, all within the convenience of a web page. These abilities are a way to quickly administer some of the more basic features of IP Server, without having to use the feature rich VI MonitorPlus.

	The Servers button allows the administrator to modify base configuration settings for the IP server, including adding and removing cameras, enabling Health Monitor reporting, changing port settings for VI MonitorPlus connections, and adding general support information for your own internal purposes.
	The new Cameras button, found in the left navigation bar, allows the admin to apply most of the administrative tasks to specific cameras that can also be done within VI MonitorPlus.
	The Views button allows the admin to create custom layouts of various cameras on the fly. Options are available to add a single camera view all the way up to a 36-camera view. Additionally, the ability to add a static image, create a custom tour of only specific cameras, or add a web page for display within the View area is possible.
	The Interface button allows the admin to create and define the default user experience when logging in to the Web Client.
	The Network button on the left navigation bar allows the user to create custom network profiles for use with servers that may have both a high-speed LAN connection and an open Internet connection and limited bandwidth.

To access the new Admin Features, select Admin located in the top right-hand side of the page.

Once the new page opens, you are presented with many options that will allow you to modify the server on various levels. Those options are described above, and within the following pages.


5.8.A Servers

The Servers Section is divided into five separate tabs that cover Configuration, Camera addition/removal, Health Monitor addition, Connectivity to the IP Server and general Support information.


(1) CONFIGURATION TAB

By selecting the Servers button found on the left navigation bar, the options made available include the ability to change the name of the server, change the SQL server location, alter the video location path, enable Binary Recording, and other advanced options. These functions are also available within VI MonitorPlus in the Camera Configuration settings.


(2) CAMERAS TAB



The Cameras tab allows admins and/or users the ability to search, add, and remove cameras from the IP Server, very similar to the way that adding cameras is done in the initial IP Server configuration, or within VI MonitorPlus.



To add a camera to the IP Server, select the Add Manually button. [Auto Discovery](#) of a camera is also available and works as described by following [this link](#).



A prompt appears requesting information regarding the specific camera being added.

Once the information has been entered, select Add, and the camera information screen will appear in the left column.


Next, select the camera, then click on the right arrow.

Finally, select Save.

IP server has now successfully added a camera with the web client

(3) HEALTH MONITOR TAB

The Health Monitor runs as a service in the background and monitors the receipt of messages from other video servers to ensure server uptime and reporting of any issues affecting the servers or cameras. The Health Monitor sends email alerts to the appropriate individual if messages from the servers are not received within the pre-determined time frame. The video servers also send messages to the Health Monitor on camera operation and disk storage usage.



Within the Administration page, a user can manipulate the Health Monitor server location by IP address, Server port (if modified from default), update frequency, and the details sent to the Health Monitor Server, including IP Server version number, a lost signal with configured cameras, camera information, available disk space on IP server, and recording status.

(4) CONNECTIVITY TAB

The Connectivity tab displays the ports that both IP Server and VI MonitorPlus use, as well as configure the outgoing SMTP mail server for use with mail services like Gmail, Hotmail, and Yahoo Mail.

(5) SUPPORT INFORMATION

The Support tab allows the user to update specific information about the IP Server. This information is to be updated by the Administrator and used as a guide to provide information that is useful on an as-needed basis.

5.8.B Cameras

This page, within VI MonitorPlus, is divided into four sections including the General Settings tab, Recording Options tab, Image Settings tab, and the Maintenance Tab. The general tab shows basic information such as the camera's name, manufacturer, model, IP address, and network configuration settings.

The screenshot displays the 'Cameras' management interface. On the left is a sidebar with a list of cameras, including '10.10.5.106 - Panasonic - Model: WV-SFV481', which is currently selected. The main panel shows the configuration for this camera. At the top, there are four tabs: 'General Settings' (active), 'Recording Options', 'Image Settings', and 'Maintenance'. Below the tabs, the 'General Settings' section is divided into two parts. The 'Camera Information' section contains fields for 'Camera Name' (10.10.5.106 - Panasonic - Model: WV-SFV481), 'Manufacturer' (Panasonic), and 'Model' (Panasonic WV-SFV481). The 'Network Settings' section includes fields for 'IP Address' (10.10.5.106), 'User Name' (admin), and 'Password' (masked with asterisks). There are also checkboxes for 'Shared IP Address' and 'Disable PTZ'. At the bottom, there are input fields for various protocols: HTTP (80), RTSP (554), FTP (21), and RTP (5004). A 'Use Alternate Ports' checkbox is also present.

Protocol	Port
HTTP	80
RTSP	554
FTP	21
RTP	5004


The Recording Options tab allows you to modify the Resolution, Frames PerSecond, turn On or Off Audio (if camera supports it), Recording Type, Capture Format, Image Location on the server, and set Maximum File size.

The Image Settings Tab Allows you to change Image Rotation, Color adjustments (limited to specific cameras), Various Advanced Settings (limited to specific cameras), and modify 360 view camera settings.

The Maintenance tab shows the camera's firmware information, service history, and the contact information.


5.8.C Views (formerly known as Layouts)

To create a View, type the name that you would like to use and, optionally, a description of the View. Next, select the number of cameras for the View.



After the initial naming and basic layout is completed, cameras on the left can be dragged and dropped into the desired point on the Layout View on the right.


The number of options for viewing vary, based on the construction of the previously designed custom View layout.



Once the settings are customized for the new View, select Save at the top right-hand side of the screen. You can now go back to the main page and choose the View that you have just created.

(1) INTERFACE

By accessing the Interface button, it is possible to alter and customize the appearance of the Web Client.



Some of the items that can be changed are the login screen starting in high-speed or low-speed viewing mode, limiting the number of video streams able to view at one time (saving bandwidth), navigation pages, custom login messages, and event notifications for use with access control devices.

Access Control functionality can also be enabled or disabled by Administrator users in the Interface section.

5.8.D General Settings

(1) VIDEO DISPLAY

Video Display supports changing camera video capture methods. It will require an IP Server restart once any option has been changed.

(2) NAVIGATION

This feature allows the Administrator to hide a specific feature that is not desired for users to see.

(3) SEARCH

Using this feature allows the Administrator to hide other features that would otherwise appear on the default website after logging in.

Often this is done to restrict access to viewing only specific devices across multiple servers.

(4) CONTENT

Content modification, by default, allows the maps to be stretched across a screen view, show camera labels (names), and copy links to facility maps.

Unchecking these tic-boxes prevents these capabilities from being used or manipulated by non-administrative users.


(5) LOGIN

The ability to force the HTTPS protocol for login is available.

This is a security enhancement feature and will work only with fully-qualified domain names with registered SSL certificates.

For more information on setting up HTTPS protocol for enhanced security, please contact Microsoft for support. Alternatively, using a self-signed certificate is possible.


(6) EVENT NOTIFICATIONS



The screenshot shows a configuration window titled "Event Notifications". It contains a description: "Enables client browser notification of specific events such as door alarms, camera status changes, etc." Below this are three radio button options: "Disabled", "Enabled" (which is selected), and "Admins Only". Under the heading "Alarm Prompts", there is a sub-label "When an alarm is triggered :" followed by two radio button options: "Do not prompt users" (selected) and "Prompt user with option to view".

Event notifications work with Access Control, as well as motion detection from cameras. This can be limited to administrative use only or blocked altogether.

(7) ACCESS CONTROL



The screenshot shows a configuration window titled "Access Control". It contains a description: "Enables the interface that allows users to control access to restricted areas." Below this are three radio button options: "Disabled", "Enabled" (which is selected), and "Admins Only".

This allows a quick shortcut to access control features for IP Servers that are integrated with Access Control services.

By default, this is enabled. If no Access Control services are being used by the IP Server, then this feature has no effect on the functionality of the Web Client.

(8) NETWORK

By creating a separate profile for use across the Internet on a low-speed connection, the settings can be optimized to limit the number of frames that IP server sends through the Web Client view to minimize the impact on the outgoing Internet connection.



The screenshot shows the "Client Options" configuration window within the "WebClient" interface. The window has a sidebar with icons for "Servers", "Cameras", "Video", "Interface", and "Network". The "Client Options" title is at the top, followed by a note: "*Changes to these settings will affect all users". Under "General Settings", there is a "Video Display" section with four radio button options: "High speed video (Internet Explorer only, software installation required)", "High speed video 'only' (Lowers bandwidth requirements, but only Internet Explorer users will be able to see video)" (selected), "Low speed video (MPEG)", and "Low speed video 'only' (ActiveX will not be used to display video)". Below this is a checkbox for "Preserve aspect ratio" and a text field for "Limit video streaming to" set to "3" minutes. Under "Navigation", there are four checkboxes: "Show navigation panel", "Enable Enterprise tab" (selected), "Enable Facility tab" (selected), and "Enable Layout tab" (selected). Each of the last three has a "Set as default" link. At the bottom, under "Search", there are three checkboxes: "Show servers in search results", "Show maps in search results", and "Show layouts in search results".

Best used for IP Server Admins that have the need to allow multiple people to connect to the IP Server, but only have a limited bandwidth issue.

Video Display

Default Video Display Method

- ☒ High speed video (Internet Explorer only, software installation required)
- ☐ High speed video *only* (Lowers bandwidth requirements, but only Internet Explorer users will be able to see video)
- ☐ Low speed video (MJPEG)
- ☐ Low speed video *only* (ActiveX will not be used to display video)

☒ Preserve aspect ratio

Limit video streaming to minutes (0 for unlimited streaming)

☐ Use dynamic downsampling when viewing Low Speed video. WARNING: This will reduce the bandwidth requirements on the client, but may dramatically increase server CPU usage.

This specifically reduces the overall refresh rate for each user so that other necessary services do not come into conflict with not having an internet connection on a bandwidth-laden network.

6. VIDEO INSIGHT SUPPORT RESOURCES

For demonstrations of how to complete various tasks and configurations using IP Server Enterprise Software, Video Insight has made available some YouTube Tutorials: <http://www.youtube.com/user/videoinsighttv>

To download manuals and software available for use, please visit our Downloads: <http://www.downloadvi.com>

6.1 REMOTE SUPPORT

If more personal assistance is needed, one of our Technical Support representatives is available to aid with any troubleshooting. *For remote support, Video Insight requests that the user install the TeamViewer client application prior to requesting support.*

To install TeamViewer:

- Browse to <http://www.downloadvi.com>
- Click the Remote Support link at the bottom of the page.
- Click Run at the prompt.
- Click Run again.
- Call Technical Support at 713-621-9779.
- Give the representative the ID number that appears within the VI Remote Support TeamViewer application window.
- Your ID is randomly generated every time you request remote support.

The representative will log onto your computer and work with you to resolve the issue

6.2 CONTACT US

Main Address

800 Gessner, Suite 700 Houston, Texas 77024

Hours of Operation Monday to Friday: 9:00am - 6:00pm CST

Phone 713-621-9779

Fax 713-621-7281

Technical Support

Hours of Operation Monday to Friday: 7:00am - 7:00pm CST

Saturdays and Holidays: 10:00am - 2:00pm CST

Email support.h@us.panasonic.com

Emergency Support Service # 877-743-2403 (*our Support Engineer on call will be paged to assist you.*)

NOTE - This information is made available for clients only in North America and the United States.
For Support outside of the United States, please contact your sales agent or vendor.

7. APPENDICES

7.1 APPENDIX A: IP SERVER PORT LIST

Service names officially recognized by the [Internet Assigned Numbers Authority](https://www.iana.org/) (IANA) may not appear within the listed items below. Instead, the listed name might reflect the name used throughout this document and within the software.

For more information about the official port names assigned by the IANA, please visit the website located at:

<https://www.iana.org/>

Port Number	Name	Purpose for use of port	Outbound WAN traffic required?
4010	Data Port	Sends live video streams from IP Server to VI MonitorPlus Client	No
4011	Command Port	To get and set system information by VI MonitorPlus Client	No
3010	Ovid Server	Communication between S2, IP Server and the Ovid Server for Video Insight and S2 Access Control Configuration	No
80	HTTP	IIS for serving the Web Client	No
		NOTE - Some ISPs block port 80 access. Some may need to configure IIS to use a different port than default for internet access	
2051	MonitorCast	Access control communication between Video Insight and MonitorCast	No
554	RTSP	Specific camera properties	No
21	FTP	Specific camera properties	No
11000	Health Monitor	Communication between IP Server and Health Monitor	No
636	Active Directory SSL	Active Directory configured with Secure Socket Layer (SSL)	No
389	Active Directory non-SSL	Active Directory configured without Secure Socket Layer (SSL)	No
8080	HMCloud	TCP port used to receive data on Health Monitor Cloud, located at: http://www.healthmonitorcloud.com .	Yes
4030	POS	Port used for Point of Sale customized software integration	No

7.2 APPENDIX B: .AVI FILES WRITE/MODIFY PERMISSIONS SETTINGS

VI Enterprise uses the Windows File System in order to generate *.avi* files directly onto the storage location, and it must follow Windows File Permissions rules to function properly.

When VI Enterprise is installed by default, the service which is created (IP Video Enterprise) runs under the Local System Account

NOTE - If you do not have Write permission, you cannot create a file and put data into it. Likewise, if you do not have Modify permission, you cannot delete the file from the storage location.

One solution from preventing normal video file operations is to assign a Service Account to the IP Video Enterprise service.

You need to first create a New Local Account or assign an existing Domain Account to the IP Enterprise service. This is located under Control Panel>Administrative Tools>Computer Management.

Scenario 1: Create a New Local Admin Account

- Within Computer Management, go to System Tools>Local Users and Groups.
- Create a new User and provide a valid password. Check the Password Never Expires box.
- Highlight the new user, right click, and select Properties. Navigate to the Member Of tab.
- Click Add. Add the Administrators group to this user.
- Navigate to the Services Management Console located in Control Panel>Administrative Tools>Services.
- Navigate to IP Video Enterprise service.
- Right click on IP Video Enterprise and select Properties. Navigate to the Log On tab.
- Select This Account and provide your username and password.
- Go to your Data Storage Path for VI, highlight it and right click selecting Properties.
- Navigate to the Security tab. Verify that Administrators is located in the Group or User Names and that it has Full Control.
- Restart the VI Enterprise service.

Scenario 2: Add an Existing Domain Account

- Within Computer Management, go to System Tools>Local Users and Groups.
- Double click on Groups, then Administrators.
- Click Add. Navigate to the Domain Account that you wish to be an Administrator for this computer.
- Navigate to the Services Management Console located in Control Panel>Administrative Tools>Services.
- Navigate to the IP Video Enterprise service.
- Right click on IP Video Enterprise and select Properties. Navigate to the Log On tab.
- Select This Account and provide your username and password.
- Go to your Data Storage Path for VI, highlight it and right click selecting Properties.
- Navigate to the Security tab. Verify that Administrators is located in the Group or User Names and that it has Full Control.
- Restart the VI Enterprise service.

7.3 APPENDIX C: CONFIGURING AN IQEYE CAMERA USING OPTIONAL CONTROLS

Once the camera is added to the software, access the Optional Controls tab in the Camera's Properties.

These controls change the way that the IQ Eye cameras handle different light settings and adjust the iris accordingly.

Gain Style- The autogain algorithm of your camera will set brightness to best display. The gain style setting chooses which pixels within the exposure window will be used by the autogain algorithm for setting brightness levels.

- **Peak Detect:** Uses only the brightest pixels in the exposure window, making sure they are appropriately-adjusted for bright pixels. This is a good setting for watching bright areas.
- **Backlight:** Uses only the darkest pixels in the exposure window, making sure they are appropriately-adjusted for dark pixels. This is a good setting for outdoor scenes where you want to watch a shaded region.
- **Average:** Uses all of the pixels in the exposure window. This is a good setting for indoor scenes where there are not very bright or very dark areas to skew the gain calculations.
- **Clip Average:** Uses all pixels except for the very darkest and brightest pixels. This is a good setting for outdoor scenes where you want to ignore both sky and shadows and to watch a region of intermediate brightness levels. This is also a good setting for interior scenes.
- **Undefined:** This setting turns off Gain Style

Light Grabber- Enables or disables special processing for low-light images. These values can be seen at the camera's web page under Image tab.

- **Most Frames:** Sets the Light Grabber value to 4x, which specifies "integration" of four frames, twice the low-light correction as the 2x setting which specifies the integration of two frames.
- **Medium:** Sets the Light Grabber value to 2x.
- **Undefined:** Sets the Light Grabber value to 4x
- **Disabled:** Turns Light Grabber off at the camera.

Light Behavior- This setting adjusts the electronic shutter values for the IQeye camera

- **Optimize speed:** Use this setting for fast moving subjects. This setting may cause images to appear grainy in low light conditions.
- **Optimize quality:** Use this setting for high-quality images. This setting may cause images to blur in low light conditions.
- **Auto:** This setting is ideal when there is adequate light and objects are not moving too fast.

The other values set a fixed exposure. This is useful for tuning a camera to minimally changing conditions or to capture objects moving at predictable speeds. The list of available exposures may change based on other settings like frame rate, Light Grabber, and resolution.

7.4 APPENDIX D: SECURE SYSTEM GUIDELINE


Introduction

Video Insight VMS is an application designed to be easy to use, scalable and flexible. To ensure encrypted communications within critical environments, the Secure System has been created as an additional security layer for the application. This document describes how to enable and configure Secure System for Video Insight VMS. Customers will be responsible for the required security needs of their company. The setup should be configured to meet specific business needs.

System Overview

The communication between the cameras and Video Insight IP Server can be encrypted over *HTTPS* protocol, and VI Web Client can be used over *HTTPS* to ensure data encryption on the client side. Also, recorded video files will not be readable by other systems after being created with the security layer enabled.

The basic System Structure is shown below:



Use Cases

To enable Secure System, a system Integrator must consider all possible scenarios and design specific solutions for each one of them. The following table presents typical use cases and their corresponding solutions:

Use Case	Solution	Reference
Video Insight VMS will be accessed via public internet without VPN.	Only HTTPS communication can be enabled when using Web Client/Microsoft IIS to encrypt all the data.	Setup HTTPS on Microsoft IIS.
Cameras that are managed by IP Server will be installed on public internet with anonymous access.	Video Insight supports HTTPS communications for Panasonic cameras, and Panasonic i-PRO Extreme series cameras come with pre-installed Symantec server certificate. The option can be easily configured, and IP Server can verify Symantec's certificate before data communication is established.	Setup HTTPS Camera Communication.
A Recorded Video can be leaked even when is stored on the local Server.	Use the Proprietary Format Video feature for Server File Storage to scramble the video file output, disabling its access by third-party software.	Setup Proprietary Format Video.

Setting Up HTTPS on Microsoft IIS

This section covers the steps to follow in order to enable HTTPS protocol on IIS Server.


Software Components

VI Web Client is installed over Microsoft IIS. The following is the basic software structure and expected communication interface when HTTPS communication between IP Server and VI Web Client is used by Video Insight VMS.




Enabling HTTPS

Create a CSR (Certificate Signing Request)



1. Open IIS Manager and select "Server Certificates".



2. Click on “Create Certificate Request”.

The 'Request Certificate' dialog box is shown with the 'Distinguished Name Properties' tab selected. The form contains the following fields:

- Common name: [Text box]
- Organization: [Text box]
- Organizational unit: [Text box]
- City/locality: [Text box]
- State/province: [Text box]
- Country/region: [Dropdown menu showing 'US']

At the bottom, there are buttons for 'Previous', 'Next', 'Finish', and 'Cancel'.

3. Fill out the Request Certificate form and click “Next”.

The 'Request Certificate' dialog box is shown with the 'Cryptographic Service Provider Properties' tab selected. The form contains the following fields:

- Cryptographic service provider: [Dropdown menu showing 'Microsoft RSA SChannel Cryptographic Provider']
- Bit length: [Dropdown menu showing '2048']


At the bottom, there are buttons for 'Previous', 'Next', 'Finish', and 'Cancel'.

4. Select each parameter for your server’s Certificate, then click “Next”.

Obtain a Signed Server Certificate

After submitting the CSR, you will need to request a CA certificate like DigiCert (Symantec) to issue a Signed Server Certificate based on the newly created CSR.


Complete the Request




2.6

Click “Complete Certificate Request”, then select a Certificate issued by the CA and specify the Friendly Name.

Bind HTTPS Port



1. Open the Default Web Site Home option and click on “Bindings”; in the Site Bindings window, click “Add”.




2. In the Add Site Binding window:

- Select “https” from the “Type” list box.
- Enter the value for the “Host name” field.
- Select the issued certificate from the “SSL certificate” list box.
- Click “OK” to add the site Binding.

Disable Weak SSL Ciphers

(1) Disable SSLv3.0

- Create “SSL 3.0” Key under the following Registry Key:
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\SecurityProviders\SCHANNEL\Protocols\SSL 3.0
- Create “Client” Key and Value for the following Registry Key:
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\SecurityProviders\SCHANNEL\Protocols\SSL 3.0\Client
"DisabledByDefault"=dword:00000001
- Create “Server” Key and Value for the following Registry Key:
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\SecurityProviders\SCHANNEL\Protocols\SSL 3.0\Server
"Enabled"=dword:00000000



Registry Editor – Disable SSL v3.0

(2) Disable RC4 Ciphers


- Create the “Ciphers” Key and “RC4 128/128”, “RC4 40/128” and “RC4 56/128” under “Ciphers”. Then add the following values:

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\SecurityProviders\SCHANNEL\Ciphers

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\SecurityProviders\SCHANNEL\Ciphers\RC4128/128
"Enabled"=dword:00000000

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\SecurityProviders\SCHANNEL\Ciphers\RC4 40/128
"Enabled"=dword:00000000

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\SecurityProviders\SCHANNEL\Ciphers\RC4 56/128
"Enabled"=dword:00000000



Registry Editor – Disable RC4 Ciphers

Setting Up HTTPS Camera Communications


To enable HTTPS for Camera communications, the camera must support HTTPS; if Symantec's certificate is required, the camera must also support it.

NOTE - See https://security.panasonic.com/products/functions/secure_communication/ for further information and supported models.


Camera Setup

Open the camera's Administrative Console (*see instructions for each made and model*).

In Setup -> Network -> Advanced -> HTTPS, select "HTTPS" from the Connections list box.




NOTE - If the Symantec Certificate is pre-installed on the camera, a Certificate error message will appear on the browser (*see picture below*).




This may happen because the pre-installed certificate is not associated to new environment; however, *this error message can be ignored*.

IP Server Set Up

1. Open VI MonitorPlus (*Client app*).
2. In Camera Setup -> General -> Recording Settings, the Capture Format value must be set to “H.265 (HTTPS)” or “H.264 (HTTPS)”.



3. In Server Setup -> Advanced -> Sever Options, “Symantec Certificate Validation” shall be checked.




4. Restart IP Server.

Setting Up Proprietary Format Video

The Proprietary Format feature scrambles recorded video files, making them unreadable by any standard video player software like Windows Media Player or VLC Media Player. This file scrambling capability includes *binary* level.

1.1 Activity

In Server Setup -> Advanced -> Server Options, “Use Proprietary Format for Server File Storage” option shall be checked.



7.5 APPENDIX E: THE INDEPENDENT JPEG GROUP'S JPEG SOFTWARE NOTICE

=====
README for release 6b of 27-Mar-1998
=====

This distribution contains the sixth public release of the Independent JPEG Group's free JPEG software. You are welcome to redistribute this software and to use it for any purpose, subject to the conditions under LEGAL ISSUES, below.

Serious users of this software (particularly those incorporating it into larger programs) should contact IJG at jpeg-info@uunet.uu.net to be added to our electronic mailing list. Mailing list members are notified of updates and have a chance to participate in technical discussions, etc.

This software is the work of Tom Lane, Philip Gladstone, Jim Boucher, Lee Crocker, Julian Minguillon, Luis Ortiz, George Phillips, Davide Rossi, Guido Vollbeding, Ge' Weijers, and other members of the Independent JPEG Group.

IJG is not affiliated with the official ISO JPEG standards committee.

DOCUMENTATION ROADMAP

=====

This file contains the following sections:

OVERVIEW General description of JPEG and the IJG software.

LEGAL ISSUES Copyright, lack of warranty, terms of distribution.

REFERENCES Where to learn more about JPEG.

ARCHIVE LOCATIONS Where to find newer versions of this software.

RELATED SOFTWARE Other stuff you should get.

FILE FORMAT WARS Software *not* to get.

TO DO Plans for future IJG releases.

Other documentation files in the distribution are:

User documentation:

install.doc How to configure and install the IJG software.

usage.doc Usage instructions for cjpeg, djpeg, jpegtran, rdjpgcom, and wrjpgcom.

*.1 Unix-style man pages for programs (same info as usage.doc).

wizard.doc Advanced usage instructions for JPEG wizards only.

change.log Version-to-version change highlights.

Programmer and internal documentation:

libjpeg.doc How to use the JPEG library in your own programs.

example.doc Sample code for calling the JPEG library.

structure.doc Overview of the JPEG library's internal structure.

filelist.doc Road map of IJG files.

coderrules.doc Coding style rules --- please read if you contribute code.

Please read at least the files install.doc and usage.doc. Useful information can also be found in the JPEG FAQ (Frequently Asked Questions) article. See ARCHIVE LOCATIONS below to find out where to obtain the FAQ article.

If you want to understand how the JPEG code works, we suggest reading one or more of the REFERENCES, then looking at the documentation files (in the order listed) before diving into the code.

OVERVIEW

=====

This package contains C software to implement JPEG image compression and decompression. JPEG (pronounced "jay - peg") is a standardized compression method for full-color and gray-scale images. JPEG is intended for compressing "real-world" scenes; line drawings, cartoons and other non-realistic images are not its strong suit. JPEG is lossy, meaning that the output image is not identical to the input image. Hence you must not use JPEG if you have to have identical output bits. However, on typical photographic images, very good compression levels can be obtained with no visible change, and remarkably high compression levels are possible if you can tolerate a low-quality image. For more details, see the references, or just experiment with various compression settings.

This software implements JPEG baseline, extended-sequential, and progressive compression processes. Provision is made for supporting all variants of these processes, although some uncommon parameter settings are not implemented yet. For legal reasons, we are not distributing code for the arithmetic-coding variants of JPEG; see LEGAL ISSUES. We have made no provision for supporting the hierarchical or lossless processes defined in the standard.

We provide a set of library routines for reading and writing JPEG image files, plus two sample applications "cjpeg" and "djpeg", which use the library to perform conversion between JPEG and some other popular image file formats. The library is intended to be reused in other applications.

In order to support file conversion and viewing software, we have included considerable functionality beyond the bare JPEG coding/decoding capability; for example, the color quantization modules are not strictly part of JPEG decoding, but they are essential for output to colormapped file formats or colormapped displays. These extra functions can be compiled out of the library if not required for a particular application. We have also included "jpegtran", a utility for lossless transcoding between different JPEG processes, and "rdjpgcom" and "wrjpgcom", two simple applications for inserting and extracting textual comments in JFIF files.

The emphasis in designing this software has been on achieving portability and flexibility, while also making it fast enough to be useful. In particular, the software is not intended to be read as a tutorial on JPEG. (See the REFERENCES section for introductory material.) Rather, it is intended to be reliable, portable, industrial-strength code. We do not claim to have achieved that goal in every aspect of the software, but we strive for it.

We welcome the use of this software as a component of commercial products. No royalty is required, but we do ask for an acknowledgement in product documentation, as described under LEGAL ISSUES.

LEGAL ISSUES

=====

In plain English:

1. We do not promise that this software works. (But if you find any bugs, please let us know!)
2. You can use this software for whatever you want. You do not have to pay us.
3. You may not pretend that you wrote this software. If you use it in a program, you must acknowledge somewhere in your documentation that you have used the IJG code.

In legalese:

The authors make NO WARRANTY or representation, either express or implied, with respect to this software, its quality, accuracy, merchantability, or fitness for a particular purpose. This software is provided "AS IS", and you, its user, assume the entire risk as to its quality and accuracy.

This software is copyright (C) 1991-1998, Thomas G. Lane.

All Rights Reserved except as specified below.

Permission is hereby granted to use, copy, modify, and distribute this software (or portions thereof) for any purpose, without fee, subject to these conditions:

(1) If any part of the source code for this software is distributed, then this README file must be included, with this copyright and no-warranty notice unaltered; and any additions, deletions, or changes to the original files must be clearly indicated in accompanying documentation.

(2) If only executable code is distributed, then the accompanying documentation must state that "this software is based in part on the work of the Independent JPEG Group".

(3) Permission for use of this software is granted only if the user accepts full responsibility for any undesirable consequences; the authors accept NO LIABILITY for damages of any kind.

These conditions apply to any software derived from or based on the IJG code, not just to the unmodified library. If you use our work, you ought to acknowledge us.

Permission is NOT granted for the use of any IJG author's name or company name in advertising or publicity relating to this software or products derived from it. This software may be referred to only as "the Independent JPEG Group's software".

We specifically permit and encourage the use of this software as the basis of commercial products, provided that all warranty or liability claims are assumed by the product vendor.

ansi2knr.c is included in this distribution by permission of L. Peter Deutsch, sole proprietor of its copyright holder, Aladdin Enterprises of Menlo Park, CA. ansi2knr.c is NOT covered by the above copyright and conditions, but instead by the usual distribution terms of the Free Software Foundation; principally, that you must include source code if you redistribute it. (See the file ansi2knr.c for full details.) However, since ansi2knr.c is not needed as part of any program generated from the IJG code, this does not limit you more than the foregoing paragraphs do.

The Unix configuration script "configure" was produced with GNU Autoconf. It is copyright by the Free Software Foundation but is freely distributable. The same holds for its supporting scripts (config.guess, config.sub, ltconfig, ltmain.sh). Another support script, install-sh, is copyright by M.I.T. but is also freely distributable.

It appears that the arithmetic coding option of the JPEG spec is covered by patents owned by IBM, AT&T, and Mitsubishi. Hence arithmetic coding cannot legally be used without obtaining one or more licenses. For this reason, support for arithmetic coding has been removed from the free JPEG software. (Since arithmetic coding provides only a marginal gain over the unpatented Huffman mode, it is unlikely that very many implementations will support it.)

So far as we are aware, there are no patent restrictions on the remaining code.

The IJG distribution formerly included code to read and write GIF files. To avoid entanglement with the Unisys LZW patent, GIF reading support has been removed altogether, and the GIF writer has been simplified to produce "uncompressed GIFs". This technique does not use the LZW algorithm; the resulting GIF files are larger than usual but are readable by all standard GIF decoders.

We are required to state that "The Graphics Interchange Format(c) is the Copyright property of CompuServe Incorporated. GIF(sm) is a Service Mark property of CompuServe Incorporated."

REFERENCES

=====

We highly recommend reading one or more of these references before trying to understand the innards of the JPEG software.

The best short technical introduction to the JPEG compression algorithm is Wallace, Gregory K. "The JPEG Still Picture Compression Standard", Communications of the ACM, April 1991 (vol. 34 no. 4), pp. 30-44.

(Adjacent articles in that issue discuss MPEG motion picture compression, applications of JPEG, and related topics.) If you do not have the CACM issue handy, a PostScript file containing a revised version of Wallace's article is available at <ftp://ftp.uu.net/graphics/jpeg/wallace.ps.gz>. The file (actually a preprint for an article that appeared in IEEE Trans. Consumer Electronics) omits the sample images that appeared in CACM, but it includes corrections and some added material. Note: the Wallace article is copyright ACM and IEEE, and it may not be used for commercial purposes.

A somewhat less technical, more leisurely introduction to JPEG can be found in "The Data Compression Book" by Mark Nelson and Jean-Loup Gailly, published by M&T Books (New York), 2nd ed. 1996, ISBN 1-55851-434-1. This book provides good explanations and example C code for a multitude of compression methods including JPEG. It is an excellent source if you are comfortable reading C code but do not know much about data compression in general. The book's JPEG sample code is far from industrial-strength, but when you are ready to look at a full implementation, you have got one here...

The best full description of JPEG is the textbook "JPEG Still Image Data Compression Standard" by William B. Pennebaker and Joan L. Mitchell, published by Van Nostrand Reinhold, 1993, ISBN 0-442-01272-1. Price US\$59.95, 638 pp. The book includes the complete text of the ISO JPEG standards (DIS 10918-1 and draft DIS 10918-2). This is by far the most complete exposition of JPEG in existence, and we highly recommend it.

The JPEG standard itself is not available electronically; you must order a paper copy through ISO or ITU. (Unless you feel a need to own a certified official copy, we recommend buying the Pennebaker and Mitchell book instead; it is much cheaper and includes a great deal of useful explanatory material.) In the USA, copies of the standard may be ordered from ANSI Sales at (212) 642-4900, or from Global Engineering Documents at (800) 854-7179. (ANSI does not take credit card orders, but Global does.) It is not cheap: as of 1992, ANSI was charging \$95 for Part 1 and \$47 for Part 2, plus 7% shipping/handling. The standard is divided into two parts, Part 1 being the actual specification, while Part 2 covers compliance testing methods. Part 1 is titled "Digital Compression and Coding of Continuous-tone Still Images, Part 1: Requirements and guidelines" and has document numbers ISO/IEC IS 10918-1, ITU-T T.81. Part 2 is titled "Digital Compression and Coding of Continuous-tone Still Images, Part 2: Compliance testing" and has document numbers ISO/IEC IS 10918-2, ITU-T T.83.

Some extensions to the original JPEG standard are defined in JPEG Part 3, a newer ISO standard numbered ISO/IEC IS 10918-3 and ITU-T T.84. IJG currently does not support any Part 3 extensions.

The JPEG standard does not specify all details of an interchangeable file format. For the omitted details we follow the "JFIF" conventions, revision 1.02. A copy of the JFIF spec is available from:

Literature Department
C-Cube Microsystems, Inc.
1778 McCarthy Blvd.
Milpitas, CA 95035
phone (408) 944-6300, fax (408) 944-6314

A PostScript version of this document is available by FTP at <ftp://ftp.uu.net/graphics/jpeg/jfif.ps.gz>. There is also a plain text version at <ftp://ftp.uu.net/graphics/jpeg/jfif.txt.gz>, but it is missing the figures.

The TIFF 6.0 file format specification can be obtained by FTP from <ftp://ftp.sgi.com/graphics/tiff/TIFF6.ps.gz>. The JPEG incorporation scheme found in the TIFF 6.0 spec of 3-June-92 has a number of serious problems.

IJG does not recommend use of the TIFF 6.0 design (TIFF Compression tag 6). Instead, we recommend the JPEG design proposed by TIFF Technical Note #2 (Compression tag 7). Copies of this Note can be obtained from <ftp://ftp.sgi.com> or from <ftp://ftp.uu.net/graphics/jpeg/>. It is expected that the next revision of the TIFF spec will replace the 6.0 JPEG design with the Note's design.

Although IJG's own code does not support TIFF/JPEG, the free libtiff library uses our library to implement TIFF/JPEG per the Note. libtiff is available from <ftp://ftp.sgi.com/graphics/tiff/>.

ARCHIVE LOCATIONS =====

The "official" archive site for this software is [ftp.uu.net](ftp://ftp.uu.net) (Internet address 192.48.96.9). The most recent released version can always be found there in directory [graphics/jpeg](ftp://ftp.uu.net/graphics/jpeg). This particular version will be archived as <ftp://ftp.uu.net/graphics/jpeg/jpegsrc.v6b.tar.gz>. If you don't have direct Internet access, UUNET's archives are also available via UUCP; contact help@uunet.uu.net for information on retrieving files that way.

Numerous Internet sites maintain copies of the UUNET files. However, only [ftp.uu.net](ftp://ftp.uu.net) is guaranteed to have the latest official version.

You can also obtain this software in DOS-compatible "zip" archive format from the SimTel archives (<ftp://ftp.simtel.net/pub/simtelnet/msdos/graphics/>), or on CompuServe in the Graphics Support forum (GO CIS:GRAPHSUP), library 12 "JPEG Tools". Again, these versions may sometimes lag behind the [ftp.uu.net](ftp://ftp.uu.net) release.

The JPEG FAQ (Frequently Asked Questions) article is a useful source of general information about JPEG. It is updated constantly and therefore is not included in this distribution. The FAQ is posted every two weeks to Usenet newsgroups comp.graphics.misc, news.answers, and other groups. It is available on the World Wide Web at <http://www.faqs.org/faqs/jpeg-faq/> and other news.answers archive sites, including the official news.answers archive at rtfm.mit.edu: <ftp://rtfm.mit.edu/pub/usenet/news.answers/jpeg-faq/>.

If you don't have Web or FTP access, send e-mail to mail-server@rtfm.mit.edu with body send usenet/news.answers/jpeg-faq/part1 send usenet/news.answers/jpeg-faq/part2

RELATED SOFTWARE

=====

Numerous viewing and image manipulation programs now support JPEG. (Quite a few of them use this library to do so.) The JPEG FAQ described above lists some of the more popular free and shareware viewers and tells where to obtain them on Internet.

If you are on a Unix machine, we highly recommend Jef Poskanzer's free PBMPLUS software, which provides many useful operations on PPM-format image files. In particular, it can convert PPM images to and from a wide range of other formats, thus making cjpeg/djpeg considerably more useful. The latest version is distributed by the NetPBM group, and is available from numerous sites, notably
<ftp://wuarchive.wustl.edu/graphics/graphics/packages/NetPBM/>.

Unfortunately, PBMPLUS/NETPBM is not nearly as portable as the IJG software is; you are likely to have difficulty making it work on any non-Unix machine.

A different free JPEG implementation, written by the PVRG group at Stanford, is available from <ftp://havefun.stanford.edu/pub/jpeg/>. This program is designed for research and experimentation rather than production use; it is slower, harder to use, and less portable than the IJG code, but it is easier to read and modify. Also, the PVRG code supports lossless JPEG, which we do not. (On the other hand, it does not do progressive JPEG.)

FILE FORMAT WARS

=====

Some JPEG programs produce files that are not compatible with our library. The root of the problem is that the ISO JPEG committee failed to specify a concrete file format. Some vendors "filled in the blanks" on their own, creating proprietary formats that no one else could read. (For example, none of the early commercial JPEG implementations for the Macintosh were able to exchange compressed files.)

The file format we have adopted is called JFIF (see REFERENCES). This format has been agreed to by a number of major commercial JPEG vendors, and it has become the de facto standard. JFIF is a minimal or "low end" representation. We recommend the use of TIFF/JPEG (TIFF revision 6.0 as modified by TIFF Technical Note #2) for "high end" applications that need to record a lot of additional data about an image. TIFF/JPEG is fairly new and not yet widely supported, unfortunately.

The upcoming JPEG Part 3 standard defines a file format called SPIFF. SPIFF is interoperable with JFIF, in the sense that most JFIF decoders should be able to read the most common variant of SPIFF. SPIFF has some technical advantages over JFIF, but its major claim to fame is that it is an official standard rather than an informal one. At this point it is unclear whether SPIFF will supersede JFIF or whether JFIF will remain the de-facto standard. IJG intends to support SPIFF once the standard is frozen, but we have not decided whether it should become our default output format or not. (In any case, our decoder will remain capable of reading JFIF indefinitely.) Various proprietary file formats incorporating JPEG compression also exist.

We have little or no sympathy for the existence of these formats. Indeed, one of the original reasons for developing this free software was to help force convergence on common, open format standards for JPEG files. Do not use a proprietary file format!

TO DO

=====

The major thrust for v7 will probably be improvement of visual quality.

The current method for scaling the quantization tables is known not to be very good at low Q values. We also intend to investigate block boundary smoothing, "poor man's variable quantization", and other means of improving quality-vs-file-size performance without sacrificing compatibility.

In future versions, we are considering supporting some of the upcoming JPEG

Part 3 extensions --- principally, variable quantization and the SPIFF file format. As always, speeding things up is of great interest. Please send bug reports, offers of help, etc. to jpeg-info@uunet.uu.net.